

Specifying the PCMM Classifier Type (C-Web Interface)

To specify whether or not the SAE sends to the router classifiers that comply with PCMM I03:

1. Select **Configure**, expand **Shared > SAE > Configuration > Driver**, and select **pcmm**.
2. Check or clear the **Disable PCMM I03 Policy** box, and click **Apply**.

- Related Topics**
- Before You Configure Classify-Traffic Conditions
 - Delivering QoS Services in a Cable Environment
 - Configuring Classify-Traffic Conditions (C-Web Interface)
 - Specifying the PCMM Classifier Type (SRC CLI)

Published: 2009-09-18