

Configuring Directory Monitoring Properties for the SDX SNMP Agent

Use the following configuration statements to configure directory monitoring properties for the SDX SNMP agent:

```
snmp agent initial directory-eventing {  
    eventing;  
    signature-dn signature-dn;  
    polling-interval polling-interval;  
    event-base-dn event-base-dn;  
    dispatcher-pool-size dispatcher-pool-size;  
}
```

To configure properties for the SDX SNMP agent:

1. From configuration mode, access the configuration statement that configures the SDX SNMP agent.

```
[edit]  
user@host# edit snmp agent initial directory-eventing
```

2. Specify the properties for the SDX SNMP agent.

```
[edit snmp agent initial eventing]  
user@host# set ?
```

3. (Optional) Verify your configuration.

```
[edit snmp agent initial directory-eventing]  
user@host# show  
eventing;
```

- Related Topics**
- Configuring the SDX SNMP Agent
 - Configuring Directory Monitoring Properties for the SDX SNMP Agent (C-Web Interface)
 - Configuring Directory Connection Properties for the SDX SNMP Agent
 - Monitoring the SDX SNMP Agent

Published: 2009-09-25