

Starting the SDX SNMP Agent

Before you start the SDX SNMP agent:

1. Perform the initial configuration tasks.

See [\[Unresolved xref\]](#).

2. Configure the SDX SNMP agent.

See [Configuring the SDX SNMP Agent](#).

Manually start the SDX SNMP agent the first time it runs. Thereafter, the agent automatically restarts.

To start the SNMP agent:

```
user@host> enable component agent
```

The system responds with a start message. If the SNMP agent is already running, the system responds with a warning message indicating that fact.

- Related Topics**
- [Starting the SDX SNMP Agent \(C-Web Interface\)](#)
 - [Stopping the SDX SNMP Agent](#)
 - [Monitoring the SDX SNMP Agent](#)

Published: 2009-09-25