

Configuring Subscriber IP Pools as IP Address Ranges (C-Web Interface)

To configure subscriber IP pools that are managed by the CMTS device as IP address ranges:

1. Click **Configure**, expand **Slot > Slot: 0 > JPS**, and then click **CMTS Registry**.

The CMTS Registry pane appears.

2. From the Create new list, select **CMTS**.
3. In the dialog box, type an IPv4 or IPv6 address for the new CMTS, and click **OK**.

The CMTS: *< ip address >* pane appears.

4. From the Create new list, select **Range Pool**.
5. In the dialog box, enter a number for the new Range Pool, and click **OK**.

The Range Pool: *< number >* pane appears.

6. Enter the information in the main pane as described in the Help text, and click **Apply**.

- Related Topics**
- Configuring Subscriber IP Pools as IP Address Ranges
 - Configuring Subscriber IP Pools as IP Subnets (C-Web Interface)
 - Modifying the Subscriber Configuration (C-Web Interface)

Published: 2009-09-18