

Setting the Timeout and Number of Events for SAE Directory Eventing (C-Web Interface)

To configure the directory eventing timeout and the number of simultaneous events that the SAE can receive from the directory:

1. Click **Configure**, expand **Shared > SAE > LDAP**, and then click **Directory Eventing**.

The Directory Eventing pane appears.

2. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

Related Topics ■ For information about setting up SAE groups, see [Configuring an SAE Group](#).

Published: 2009-09-18