

Configuring the SAE to Use TLS

To configure the SAE to accept TLS connections, enter a port number with the **set beep-server-port** command in the JUNOS router driver configuration.

See Configuring the SAE to Manage JUNOS Routing Platforms .

- Related Topics**
- Configuring the SAE to Use TLS
 - Configuring TLS on the SAE
 - Configuring JUNOS Routing Platforms to Interact with the SAE
 - Monitoring Interactions Between the SAE and JUNOS Routing Platforms

Published: 2009-09-15