

## Configuring the SAE to Use TLS

---

To configure the SAE to accept TLS connections:

1. Click **Configure**, expand **Shared > Network**, and then click a JUNOS router.

The Device pane appears.

2. Type a port number in the Beep Server Port box, and click **Apply**.

- Related Topics**
- Configuring the SAE to Manage JUNOS Routing Platforms (C-Web Interface)
  - Configuring TLS on the SAE
  - Configuring JUNOS Routing Platforms to Interact with the SAE
  - Monitoring Interactions Between the SAE and JUNOS Routing Platforms

---

Published: 2009-09-18