

## Configuring the SNMP Agent

---

To configure the SNMP agent to control its operation:

1. Configure information supplied by the SNMP agent, including the listening address and system information.

See [Configuring System Information for the SNMP Agent \(SRC CLI\)](#) .

2. Configure access control for the SNMP agent, including access for SNMPv3 users, SNMPv1 and SNMPv2 communities (traditional access control), and the view-based access control model (VACM).

See [Configuring Access Control for SNMPv3 Users \(C-Web Interface\)](#) .

See [Configuring Access Control for Communities](#) .

See [Configuring Access Control for the VACM](#) .

3. Configure active monitoring.

See [Configuring Notification Targets \(SRC CLI\)](#) .

- Related Topics**
- [Configuration Statements for the SNMP Agent](#)
  - [Operating the SNMP Agent](#)

---

Published: 2009-09-25