

Testing a NIC Resolution (C-Web Interface)

To test a NIC resolution:

1. Click **Diagnose > NIC > Resolve**.
2. Enter information as described in the Help text in the main pane, and click **OK**.

- Related Topics**
- Configuring a NIC Scenario (C-Web Interface)
 - Testing a NIC Resolution (SRC CLI)
 - SRC CLI Commands to View NIC Resolution Data
 - Troubleshooting NIC Data Resolution
 - Overview of the NIC Resolution Process

Published: 2009-09-18