

Copying Initialization Scripts to the C Series Controller

If you use a script that is not provided with the SRC module, you need to use the `file copy` command to copy your script to the C Series Controller. For example:

```
user@host> file copy ftp://user@myserver/routerinit.py /opt/UMC/sae/lib
Password:
```

- Related Topics**
- Specifying Initialization Scripts on the SAE
 - Setting Up Script Services
 - Developing Router Initialization Scripts for JUNOS Routers, JUNOS Routing Platforms, and Network Devices

Published: 2009-09-15