

Stopping External Subscriber Monitor with the C-Web Interface (C-Web Interface)

To stop the External Subscriber Monitor:

1. Click **Manage > Disable**.

The Disable pane appears.

2. From the Component list, select **exsubmonr**, and click **OK**.

Published: 2009-09-18