

## Viewing the State of JUNOS Device Drivers (SRC CLI)

---

**Purpose** Display the state of JUNOS drivers.

**Action** Use the following operational mode command:

```
show sae drivers <device-name device-name > < (brief) > <maximum-results  
maximum-results >
```

For example:

```
user@host> show sae drivers device-name default@jrouter
JUNOS Driver
Device name                default@jrouter
Device type                junos
Device IP                  /10.10.6.113:1879
Local IP                   10.10.6.113
TransportRouter
Device version              8.2R1.7
Start time                 Thu Mar 08 21:00:50 UTC 2007
Number of notifications    0
Number of processed added  0
Number of processed changed 0
Number of processed deleted 0
Number of provisioning attempt 0
Number of provisioning attempt failed 0
Device type                JunosRouterDriver
Job queue size             0
Number of SAP              3
Number of PAP              0
Start time                 Thu Mar 08 21:00:55 UTC 2007
End time                   Thu Mar 08 21:00:55 UTC 2007
Transaction Manager
Transaction queue size 0
Router name                 default@troll
```

- Related Topics**
- Viewing the State of JUNOS Device Drivers (C-Web Interface)
  - Troubleshooting Problems with the SRC Software Process
  - Viewing Statistics for Specific JUNOS Device Drivers (SRC CLI)
  - Viewing Statistics for All JUNOS Device Drivers (SRC CLI)

---

Published: 2009-09-15