

## Viewing Statistics for All JUNOSe Device Drivers (SRC CLI)

---

**Purpose** Display SNMP statistics for all JUNOSe device drivers.

**Action** Use the following operational mode command:

```
show sae statistics device common junose-cops
```

For example:

```
user@host> show sae statistics device common junose-cops
SNMP Statistics
Driver type          JUNOSE COPS
Number of close requests  0
Number of connections accepted 2
Number of current connections 1
Number of open requests  2
Server address        0:0:0:0:0:0:0:0
Server port           3288
Time since last redirect 186703
```

- Related Topics**
- Troubleshooting Problems with Managing JUNOSe Routers
  - Viewing Statistics for Specific JUNOSe Device Drivers (SRC CLI)
  - Viewing the State of JUNOSe Device Drivers (C-Web Interface)
  - Viewing Statistics for All JUNOSe Device Drivers (C-Web Interface)

---

Published: 2009-09-15