

Viewing Information About Policies

Purpose View information about the policies available on the SAE.

Action 1. Click **Monitor > SAE > Policies**.

The Policies pane appears.

Field	Description	Value	Legal range	Default
Policy Group	Name of a policy group.	All or part of the policy group name		No value
Maximum Results	Number of results to be displayed.		1..INF	25
Slot	Display SAE information for a specified slot.	Currently the chassis has only one slot. The valid value is 0.		0
Style	Output style.	Choices: brief: Display only policy group names		detail

2. In the Policy Group box, enter a full or partial policy name for which you want to display information, or leave the box blank to display all policies.
3. In the Maximum Results box, enter the maximum number of results that you want to receive.
4. In the Slot box, enter the number of the slot for which you want to display policy information.
5. Select an output style from the Style list.
6. Click **OK**.

The Policies pane displays the status of the policies configured on the SAE.

- Related Topics**
- Configuring Access to Policy Data
 - Viewing SNMP Information for Policies with the CLI
 - Viewing SNMP Statistics About Policies