



---

## Junos<sup>®</sup> OS

# Layer 2 Bridging, Address Learning, and Forwarding Feature Guide for Routing Devices

Release  
13.2



---

Published: 2013-08-02

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, California 94089  
USA  
408-745-2000  
[www.juniper.net](http://www.juniper.net)

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

*Junos® OS Layer 2 Bridging, Address Learning, and Forwarding Feature Guide for Routing Devices*

13.2

Copyright © 2013, Juniper Networks, Inc.  
All rights reserved.

The information in this document is current as of the date on the title page.

## YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

## END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

# Table of Contents

	About the Documentation . . . . .	ix
	Documentation and Release Notes . . . . .	ix
	Supported Platforms . . . . .	ix
	Using the Examples in This Manual . . . . .	ix
	Merging a Full Example . . . . .	x
	Merging a Snippet . . . . .	x
	Documentation Conventions . . . . .	xi
	Documentation Feedback . . . . .	xiii
	Requesting Technical Support . . . . .	xiii
	Self-Help Online Tools and Resources . . . . .	xiii
	Opening a Case with JTAC . . . . .	xiv
<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Layer 2 Bridging . . . . .</b>	<b>3</b>
	Layer 2 Bridge Domains Overview . . . . .	3
	Layer 2 Virtual Switches Overview . . . . .	4
	Layer 2 Learning and Forwarding for Bridge Domains Overview . . . . .	5
	Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports . . . . .	5
	Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances . . . . .	6
<b>Chapter 2</b>	<b>Layer 2 Address Learning and Forwarding . . . . .</b>	<b>7</b>
	Layer 2 Learning and Forwarding Overview . . . . .	7
<b>Part 2</b>	<b>Configuration</b>	
<b>Chapter 3</b>	<b>Layer 2 Bridging and Layer 3 IP Routing . . . . .</b>	<b>11</b>
	Configuring a Bridge Domain . . . . .	11
	Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances . . . . .	12
	Configuring Integrated Routing and Bridging for Bridge Domains . . . . .	17
	Configuring Bridge Domains as Switches for Layer 2 Trunk Ports . . . . .	19
<b>Chapter 4</b>	<b>Layer 2 Virtual Switches . . . . .</b>	<b>21</b>
	Configuring Integrated Routing and Bridging for a Bridge Domain in a Layer 2 Virtual Switch . . . . .	21
	Configuring VPLS Ports in a Virtual Switch . . . . .	22
	Configuring a Layer 2 Virtual Switch with a Layer 2 Trunk Port . . . . .	24
	Configuring a Layer 2 Virtual Switch . . . . .	25

<b>Chapter 5</b>	<b>Layer 2 Learning and Forwarding for Bridge Domains . . . . .</b>	<b>29</b>
	Disabling MAC Learning for a Bridge Domain or Logical Interface . . . . .	29
	Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain . . .	30
	Configuring the Size of the MAC Address Table . . . . .	31
	Limiting MAC Addresses Learned from an Interface in a Bridge Domain . . . . .	32
	Enabling MAC Accounting for a Bridge Domain . . . . .	33
<b>Chapter 6</b>	<b>Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports . . . . .</b>	<b>35</b>
	Disabling MAC Learning for a Set of Bridge Domains . . . . .	35
	Limiting the Number of MAC Addresses Learned from a Trunk Port . . . . .	35
	Configuring the Size of the MAC Address Table for a Set of Bridge Domains . . .	36
	Enabling MAC Accounting for a Set of Bridge Domains . . . . .	37
<b>Chapter 7</b>	<b>Layer 3 Tunnel Services Interfaces with a DPC . . . . .</b>	<b>39</b>
	Configuring Layer 3 Tunnel Services Interfaces on an MX Series Router with a DPC . . . . .	39
<b>Chapter 8</b>	<b>Layer 2 Address Learning and Forwarding . . . . .</b>	<b>41</b>
	Configuring the MAC Table Timeout Interval . . . . .	41
	Enabling MAC Accounting . . . . .	42
	Limiting the Number of MAC Addresses Learned from Each Logical Interface . .	42
	Disabling Layer 2 Learning and Forwarding . . . . .	43
	Example: Loop Detection Using the MAC Move Approach . . . . .	43
<b>Chapter 9</b>	<b>Configuration Statements for Bridge Domains . . . . .</b>	<b>49</b>
	[edit bridge-domains] Hierarchy Level . . . . .	49
	action-priority . . . . .	51
	bridge-domains . . . . .	52
	bridge-options . . . . .	53
	domain-type . . . . .	54
	enable-mac-move-action . . . . .	54
	interface . . . . .	55
	interface-mac-limit . . . . .	56
	mac-statistics . . . . .	58
	mac-table-size . . . . .	59
	no-irb-layer-2-copy . . . . .	60
	no-mac-learning . . . . .	61
	packet-action . . . . .	63
	routing-interface . . . . .	65
	service-id . . . . .	66
	static-mac . . . . .	67
	vlan-id (Bridge Domain or VLAN) . . . . .	68
	vlan-id-list . . . . .	70
	vlan-tags . . . . .	71
<b>Chapter 10</b>	<b>Configuration Statements for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports . . . . .</b>	<b>73</b>
	[edit switch-options] Hierarchy Level . . . . .	73
	switch-options . . . . .	74
	interface-mac-limit . . . . .	75

	mac-statistics .....	77
	mac-table-size .....	78
	no-mac-learning .....	79
	packet-action .....	81
<b>Chapter 11</b>	<b>Configuration Statements for Layer 3 Tunnel Services Interfaces with a DPC .....</b>	<b>83</b>
	tunnel-services (Chassis) .....	84
	bandwidth (Tunnel Services) .....	85
<b>Chapter 12</b>	<b>Configuration Statements for Layer 2 Address Learning and Forwarding .....</b>	<b>87</b>
	[edit protocols l2-learning] Hierarchy Level .....	87
	l2-learning .....	88
	global-mac-limit .....	89
	global-mac-statistics .....	89
	global-mac-table-aging-time .....	90
	global-no-mac-learning .....	90
	interface-mac-limit .....	91
	packet-action .....	93
<b>Part 3</b>	<b>Administration</b>	
<b>Chapter 13</b>	<b>Operational Mode Commands for Bridge Domains .....</b>	<b>97</b>
	clear bridge mac-table .....	98
	show bridge domain .....	99
	show bridge flood .....	101
	show bridge mac-table .....	108
	show bridge statistics .....	112
	show interfaces queue .....	115
<b>Chapter 14</b>	<b>Operational Mode Commands for Layer 2 Learning .....</b>	<b>153</b>
	clear l2-learning mac-move-buffer .....	154
	show l2-learning global-information .....	155
	show l2-learning global-mac-count .....	157
	show l2-learning instance .....	158
	show l2-learning interface .....	160
	show l2-learning mac-move-buffer .....	162
<b>Part 4</b>	<b>Index</b>	
	Index .....	165



# List of Tables

	<b>About the Documentation . . . . .</b>	<b>ix</b>
	Table 1: Notice Icons . . . . .	xi
	Table 2: Text and Syntax Conventions . . . . .	xi
<b>Part 2</b>	<b>Configuration</b>	
<b>Chapter 3</b>	<b>Layer 2 Bridging and Layer 3 IP Routing . . . . .</b>	<b>11</b>
	Table 3: Statement Usage and Input Rewrite Operations for VLAN Identifiers for a Bridge Domain . . . . .	16
	Table 4: Statement Usage and Output Rewrite Operations for VLAN Identifiers for a Bridge Domain . . . . .	17
<b>Part 3</b>	<b>Administration</b>	
<b>Chapter 13</b>	<b>Operational Mode Commands for Bridge Domains . . . . .</b>	<b>97</b>
	Table 5: show bridge mac-table Output fields . . . . .	109
	Table 6: Layer 2 Overhead, Transmitted Packets/Bytes . . . . .	116
	Table 7: show interfaces queue Output Fields . . . . .	119
	Table 8: Byte Count by Interface Hardware . . . . .	122
<b>Chapter 14</b>	<b>Operational Mode Commands for Layer 2 Learning . . . . .</b>	<b>153</b>
	Table 9: show l2-learning global-information Output Fields . . . . .	155
	Table 10: show l2-learning instance Output Fields . . . . .	158
	Table 11: show l2-learning interfaceOutput Fields . . . . .	160





# About the Documentation

- Documentation and Release Notes on page ix
- Supported Platforms on page ix
- Using the Examples in This Manual on page ix
- Documentation Conventions on page xi
- Documentation Feedback on page xiii
- Requesting Technical Support on page xiii

## Documentation and Release Notes

---

To obtain the most current version of all Juniper Networks<sup>®</sup> technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

## Supported Platforms

---

For the features described in this document, the following platforms are supported:

- MX Series

## Using the Examples in This Manual

---

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

## Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xml;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

## Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the **load** command, see the *CLI User Guide*.

## Documentation Conventions

Table 1 on page xi defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2 on page xi defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
<b>Bold text like this</b>	Represents text that you type.	To enter configuration mode, type the <b>configure</b> command:  user@host> <b>configure</b>
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> <b>show chassis alarms</b>  No alarms currently active

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
<i>Italic text like this</i>	<ul style="list-style-type: none"> <li>Introduces or emphasizes important new terms.</li> <li>Identifies book names.</li> <li>Identifies RFC and Internet draft titles.</li> </ul>	<ul style="list-style-type: none"> <li>A policy <i>term</i> is a named structure that defines match conditions and actions.</li> <li><i>Junos OS System Basics Configuration Guide</i></li> <li>RFC 1997, <i>BGP Communities Attribute</i></li> </ul>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name:  [edit] root@# <b>set system domain-name</b> <i>domain-name</i>
<b>Text like this</b>	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> <li>To configure a stub area, include the <b>stub</b> statement at the [edit protocols ospf area area-id] hierarchy level.</li> <li>The console port is labeled <b>CONSOLE</b>.</li> </ul>
< > (angle brackets)	Enclose optional keywords or variables.	<b>stub</b> <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	<b>broadcast   multicast</b>  ( <i>string1</i>   <i>string2</i>   <i>string3</i> )
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	<b>rsvp { # Required for dynamic MPLS only</b>
[ ] (square brackets)	Enclose a variable for which you can substitute one or more values.	<b>community name members [</b> <i>community-ids</i> <b>]</b>
Indentation and braces ( { } )	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
<b>GUI Conventions</b>		
<b>Bold text like this</b>	Represents graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> <li>In the Logical Interfaces box, select <b>All Interfaces</b>.</li> <li>To cancel the configuration, click <b>Cancel</b>.</li> </ul>
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select <b>Protocols&gt;Ospf</b> .

## Documentation Feedback

---

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net), or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

## Requesting Technical Support

---

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

## Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>

- Join and participate in the Juniper Networks Community Forum:  
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

## Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

## PART 1

# Overview

- [Layer 2 Bridging on page 3](#)
- [Layer 2 Address Learning and Forwarding on page 7](#)





## CHAPTER 1

# Layer 2 Bridging

- [Layer 2 Bridge Domains Overview on page 3](#)
- [Layer 2 Virtual Switches Overview on page 4](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)
- [Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 6](#)

### Layer 2 Bridge Domains Overview

---

You can configure one or more bridge domains on MX Series routers to perform Layer 2 bridging. The Layer 2 bridging functions of the MX Series routers include integrated routing and bridging (IRB) for support for Layer 2 bridging and Layer 3 IP routing on the same interface, and virtual switches that isolate a LAN segment with its spanning-tree protocol instance and separate its VLAN ID space.

A bridge domain is a set of logical ports that share the same flooding or broadcast characteristics. Like a virtual LAN (VLAN), a bridge domain spans one or more ports of multiple devices.

On Juniper Networks MX Series 3D Universal Edge Routers only, you can configure one or more bridge domains to perform Layer 2 bridging. Thus, MX Series routers can function as Layer 2 switches, each with multiple bridging, or broadcast, domains that participate in the same Layer 2 network. You can also configure Layer 3 routing support for a bridge domain. Integrated routing and bridging (IRB) provides support for Layer 2 bridging and Layer 3 IP routing on the same interface. IRB enables you to route packets to another routed interface or to another bridge domain that has a Layer 3 protocol configured.

You can also group one or more bridge domains within a single instance, or virtual switch. The MX Series routers also support multiple virtual switches, each of which operates independently of other virtual switches on the router. Virtual switches isolate a LAN segment with its spanning-tree protocol instance and separate its VLAN ID space. Thus, each virtual switch can participate in a different Layer 2 network.

In Junos OS Release 9.2 and later, bridge domains provide support for a Layer 2 trunk port. A Layer 2 trunk interface enables you to configure a single logical interface to represent multiple VLANs on a physical interface. You can configure a set of bridge

domains and VLAN identifiers that are automatically associated with one or more Layer 2 trunk interfaces. Packets received on a trunk interface are forwarded within a bridge domain that has the same VLAN identifier. A Layer 2 trunk interface also supports IRB within a bridge domain. In addition, you can configure Layer 2 learning and forwarding properties that apply to the entire set of bridge domains.

In Junos OS Release 9.3 and later, you can configure VPLS ports in a virtual switch instead of a dedicated routing instance of type **vpls** so that the logical interfaces of the Layer 2 bridge domains in the virtual switch can handle VPLS routing instance traffic. Packets received on a Layer 2 trunk interface are forwarded within a bridge domain that has the same VLAN identifier.

**Related  
Documentation**

- [Layer 2 Virtual Switches Overview on page 4](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)
- [Configuring a Bridge Domain on page 11](#)

---

## Layer 2 Virtual Switches Overview

---

On MX Series routers only, you can group one or more bridge domains to form a virtual switch to isolate a LAN segment with its spanning-tree protocol instance and separate its VLAN ID space. A bridge domain consists of a set of logical ports that share the same flooding or broadcast characteristics. Like a virtual LAN, a bridge domain spans one or more ports of multiple devices. You can configure multiple virtual switches, each of which operates independently of the other virtual switches on the routing platform. Thus, each virtual switch can participate in a different Layer 2 network.

You can configure a virtual switch to participate only in Layer 2 bridging and optionally to perform Layer 3 routing. In addition, you can configure one of three Layer 2 control protocols—Spanning-Tree Protocol, Rapid Spanning-Tree Protocol (RSTP), or Multiple Spanning-Tree Protocol (MSTP)—to prevent forwarding loops. For more information about how to configure Layer 2 logical ports on an interface, see the *Junos OS Network Interfaces Library for Routing Devices*.

In Junos OS Release 9.2 and later, you can associate one or more logical interfaces configured as trunk interfaces with a virtual switch. A trunk interface, or Layer 2 trunk port, enables you to configure a logical interface to represent multiple VLANs on the physical interface. Packets received on a trunk interface are forwarded within a bridge domain that has same VLAN identifier. For more information about how to configure trunk interfaces, see the *Junos OS Network Interfaces Library for Routing Devices*.

You can also configure Layer 2 forwarding and learning properties for the virtual switch as well as any bridge domains that belong to a virtual switch. .

For more information about configuring a routing instance for Layer 2 VPN, see the *Junos OS VPNs Library for Routing Devices*. For a detailed Layer 2 VPN example configuration, see the *Junos OS Feature Guides*.

**Related  
Documentation**

- [Configuring a Layer 2 Control Protocol Routing Instance](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Protocol Tunneling Through a Network Overview](#)

## Layer 2 Learning and Forwarding for Bridge Domains Overview

When you configure a bridge domain, Layer 2 address learning is enabled by default. The bridge domain learns unicast media access control (MAC) addresses to avoid flooding the packets to all the ports in the bridge domain. Each bridge domain creates a source MAC entry in its source and destination MAC tables for each source MAC address learned from packets received on the ports that belong to the bridge domain.



**NOTE:** Traffic is not flooded back onto the interface on which it was received. However, because this “split horizon” occurs at a late stage, the packet statistics displayed by commands such as `show interfaces queue` will include flood traffic.

You can optionally disable MAC learning either for the entire router or for a specific bridge domain or logical interface. You can also configure the following Layer 2 learning and forwarding properties:

- Static MAC entries for logical interfaces only
- Limit to the number of MAC addresses learned from a specific logical interface or from all the logical interfaces in a bridge domain
- Size of the MAC address table for the bridge domain
- MAC accounting for a bridge domain

**Related  
Documentation**

- [Layer 2 Learning and Forwarding Overview on page 7](#)

## Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports

Layer 2 learning is enabled by default. A set of bridge domains, configured to function as a switch with a Layer 2 trunk port, learns unicast media access control (MAC) addresses to avoid flooding packets to the trunk port.



**NOTE:** Traffic is not flooded back onto the interface on which it was received. However, because this “split horizon” occurs at a late stage, the packet statistics displayed by commands such as `show interfaces queue` will include flood traffic.

You can optionally disable Layer 2 learning for the entire set of bridge domains as well as modify the following Layer 2 learning and forwarding properties:

- Limit the number of MAC addresses learned from the Layer 2 trunk port associated with the set of bridge domains
- Modify the size of the MAC address table for the set of bridge domains
- Enable MAC accounting for the set of bridge domains

**Related  
Documentation**

- [Layer 2 Learning and Forwarding Overview on page 7](#)

## Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances

---

For a bridge domain that is performing Layer 2 switching only, you do not have to specify a VLAN identifier.

For a bridge domain that is performing Layer 3 IP routing, you must specify either a VLAN identifier or dual VLAN identifier tags.

For a VPLS routing instance, you must specify either a VLAN identifier or dual VLAN identifier tags.

**Related  
Documentation**

- [Layer 2 Learning and Forwarding Overview on page 7](#)

## CHAPTER 2

# Layer 2 Address Learning and Forwarding

- [Layer 2 Learning and Forwarding Overview on page 7](#)

## Layer 2 Learning and Forwarding Overview

---

On MX Series routers only, you can configure Layer 2 MAC address and VLAN learning and forwarding properties in support of Layer 2 bridging. The router learns unicast media access control (MAC) addresses to avoid flooding the packets to all the ports in a bridge domain. The MX Series router creates a source MAC entry in its source and destination MAC tables for each MAC address learned from packets received on ports that belong to the bridge domain. If the bridge domain receives a control protocol data unit (PDU) that does not have a corresponding protocol configured, then the control PDU is considered as an unknown multicast data packet and the packets are flooded across all the ports that are part of the same bridge domain. If the bridge domain has the protocol corresponding to the PDU configured then the control PDU is considered as a control packet and is processed by the routing engine.

By default, Layer 2 address learning is enabled. You can disable MAC learning for the router or for a specific bridge domain or logical interfaces. You can also configure the following Layer 2 forwarding properties for an MX Series router:

- Timeout interval for MAC entries
- MAC accounting
- A limit to the number of MAC addresses learned from the logical interfaces

For more information about how to configure bridge domains and virtual switches, see [“Configuring a Bridge Domain” on page 11](#) and [“Configuring a Layer 2 Virtual Switch” on page 25](#).

### Related Documentation

- [Configuring the MAC Table Timeout Interval on page 41](#)
- [Enabling MAC Accounting on page 42](#)
- [Limiting the Number of MAC Addresses Learned from Each Logical Interface on page 42](#)
- [Disabling Layer 2 Learning and Forwarding on page 43](#)



## PART 2

# Configuration

- [Layer 2 Bridging and Layer 3 IP Routing on page 11](#)
- [Layer 2 Virtual Switches on page 21](#)
- [Layer 2 Learning and Forwarding for Bridge Domains on page 29](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 35](#)
- [Layer 3 Tunnel Services Interfaces with a DPC on page 39](#)
- [Layer 2 Address Learning and Forwarding on page 41](#)
- [Configuration Statements for Bridge Domains on page 49](#)
- [Configuration Statements for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 73](#)
- [Configuration Statements for Layer 3 Tunnel Services Interfaces with a DPC on page 83](#)
- [Configuration Statements for Layer 2 Address Learning and Forwarding on page 87](#)





## CHAPTER 3

# Layer 2 Bridging and Layer 3 IP Routing

- [Configuring a Bridge Domain on page 11](#)
- [Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12](#)
- [Configuring Integrated Routing and Bridging for Bridge Domains on page 17](#)
- [Configuring Bridge Domains as Switches for Layer 2 Trunk Ports on page 19](#)

## Configuring a Bridge Domain

---

A bridge domain must include a set of logical interfaces that participate in Layer 2 learning and forwarding. You can optionally configure a VLAN identifier and a routing interface for the bridge domain to also support Layer 3 IP routing.

To enable a bridge domain, include the following statements:

```
[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    interface interface-name;
    routing-interface routing-interface-name;
    vlan-id (none | all | number);
    vlan-id-list [ vlan-id-numbers ];
    vlan-tags outer number inner number;
  }
}
```

You cannot use the slash (/) character in bridge domain names. If you do, the configuration does not commit and an error is generated.

For the **vlan-id** statement, you can specify either a valid VLAN identifier or the **none** or **all** options. For information about VLAN identifiers and VLAN tags for a bridge domain, see [“Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances” on page 6](#) and [“Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances” on page 12](#).

To include one or more logical interfaces in the bridge domain, specify an **interface-name** for an Ethernet interface you configured at the **[edit interfaces]** hierarchy level.



**NOTE:** A maximum of 4000 active logical interfaces are supported on a bridge domain or on each mesh group in a virtual private LAN service (VPLS) instance configured for Layer 2 bridging.

By default, each bridge domain maintains a Layer 2 forwarding database that contains media access control (MAC) addresses learned from packets received on the ports that belong to the bridge domain. You can modify Layer 2 forwarding properties, including disabling MAC learning for the entire system or a bridge domain, adding static MAC addresses for specific logical interfaces, and limiting the number of MAC addresses learned by the entire system, the bridge domain, or a logical interface.

You can also configure spanning tree protocols to prevent forwarding loops. For more information, see *Spanning-Tree Protocols Supported on MX Series Routers*.

In Junos OS Release 8.5 and later, you can configure IGMP snooping for a bridge domain. For more information, see the *Multicast Protocols Feature Guide for Routing Devices*.

**Related  
Documentation**

- [Configuring Integrated Routing and Bridging for Bridge Domains on page 17](#)
- [Layer 2 Learning and Forwarding Overview on page 7](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)

---

## Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances

---

You can configure VLAN identifiers for a bridge domain or a VPLS routing instance in the following ways:

- By using the **input-vlan-map** and the **output-vlan-map** statements at the **[edit interfaces interface-name]** or **[edit logical-systems logical-system-name interfaces interface-name]** hierarchy level to configure VLAN mapping. For information about configuring input and output VLAN maps to stack and rewrite VLAN tags in incoming or outgoing frames, see the *Junos OS Network Interfaces Library for Routing Devices*.
- By using either the **vlan-id** statement or the **vlan-tags** statement to configure a normalizing VLAN identifier. This topic describes how normalizing VLAN identifiers are processed and translated in a bridge domain or a VPLS routing instance.

The **vlan-id** and **vlan-tags** statements are used to specify the normalizing VLAN identifier under the bridge domain or VPLS routing instance. The normalizing VLAN identifier is used to perform the following functions:

- Translate, or normalize, the VLAN tags of received packets received into a learn VLAN identifier.
- Create multiple learning domains that each contain a learn VLAN identifier. A learning domain is a MAC address database to which MAC addresses are added based on the learn VLAN identifier.



**NOTE:** You cannot configure VLAN mapping using the `input-vlan-map` and `output-vlan-map` statements if you configure a normalizing VLAN identifier for a bridge domain or VPLS routing instance using the `vlan-id` or `vlan-tags` statements.

To configure a VLAN identifier for a bridge domain, include either the `vlan-id` or the `vlan-tags` statement at the `[edit interfaces interface-name unit logic-unit-number family bridge]` or `[edit logical-systems logical-system-name interfaces interface-name unit logic-unit-number family bridge]` hierarchy level, and then include that logical interface in the bridge domain configuration. For more information about configuring a bridge domain, see [“Configuring a Bridge Domain” on page 11](#).

For a VPLS routing instance, include either the `vlan-id` or `vlan-tags` statement at the `[edit interfaces interface-name unit logic-unit-number]` or `[edit logical-systems logical-system-name interfaces interface-name unit logic-unit-number]` hierarchy level, and then include that logical interface in the VPLS routing instance configuration. For more information about configuring a VPLS routing instance, see the *Junos OS VPNs Library for Routing Devices*.



**NOTE:** For a single bridge domain or VPLS routing instance, you can include either the `vlan-id` or the `vlan-tags` statement, but not both. If you do not configure a `vlan-id`, `vlan-tags`, or `vlan-id-list [ vlan-id-numbers ]` for the bridge domain or the VPLS routing instance, the Layer 2 packets received are forwarded to the outbound Layer 2 interface without having the VLAN tag modified unless an `output-vlan-map` is configured on the Layer 2 interface. This results in a frame being forwarded to a Layer 2 interface with a VLAN tag that is different from what is configured for the Layer 2 interface. Note that a frame received from the Layer 2 interface is still required to match the VLAN tag(s) specified in the interface configuration. The invalid configuration may cause a Layer 2 loop to occur.

The VLAN tags associated with the inbound logical interface are compared with the normalizing VLAN identifier. If the tags are different, they are rewritten as described in [Table 3 on page 16](#). The source MAC address of a received packet is learned based on the normalizing VLAN identifier.



**NOTE:** You do not have to specify a VLAN identifier for a bridge domain that is performing Layer 2 switching only. To support Layer 3 IP routing, you must specify either a VLAN identifier or a pair of VLAN tags. However, you cannot specify the same VLAN identifier for more than one bridge domain within a routing instance. Each bridge domain must have a unique VLAN identifier.

If the VLAN tags associated with the outbound logical interface and the normalizing VLAN identifier are different, the normalizing VLAN identifier is rewritten to match the VLAN tags of the outbound logical interface, as described in [Table 4 on page 17](#).

For the packets sent over the VPLS routing instance to be tagged by the normalizing VLAN identifier, include one of the following configuration statements:

- **vlan-id *number*** to tag all packets that are sent over the VPLS virtual tunnel (VT) interfaces with the VLAN identifier.
- **vlan-tags outer *number* inner *number*** to tag all packets sent over the VPLS VT interfaces with dual outer and inner VLAN tags.

Use the **vlan-id none** statement to have the VLAN tags removed from packets associated with an inbound logical interface when those packets are sent over VPLS VT interfaces. Note that those packets might still be sent with other customer VLAN tags.

The **vlan-id all** statement enables you to configure bridging for several VLANs with a minimum amount of configuration. Configuring this statement creates a learning domain for:

- Each inner VLAN, or learn VLAN, identifier of a logical interface configured with two VLAN tags
- Each VLAN, or learn VLAN, identifier of a logical interface configured with one VLAN tag

We recommend that you do not use customer VLAN IDs in a VPLS routing instance because customer VLAN IDs are used for learning only.

You should use the service VLAN ID in a VPLS routing instance, as in the following configuration:

```
[edit]
interface ge-1/1/1 {
  vlan-tagging;
  unit 1 {
    vlan-id s1; /* Service vlan */
    encapsulation vlan-vpls;
    input-vlan-map pop; /* Pop the service vlan on input */
    output-vlan-map push; /* Push the service vlan on output */
  }
}
interface ge-1/1/2 {
  encapsulation ethernet-vpls;
  unit 0;
}
routing-instance {
  V1 {
    instance-type vpls;
    vlan-id all;
    interface ge-1/1/1.1;
    interface ge-1/1/2.0;
  }
}
```



**NOTE:** If you configure the `vlan-id all` statement in a VPLS routing instance, we recommend using the `input-vlan-map pop` and `output-vlan-map push` statements on the logical interface to pop the service VLAN ID on input and push the service VLAN ID on output and in this way limit the impact of doubly-tagged frames on scaling. You cannot use the native `vlan-id` statement when the `vlan-id all` statement is included in the configuration.

The `vlan-id-list [ vlan-id-numbers ]` statement enables you to configure bridging for multiple VLANs on a trunk interface. Configuring this statement creates a learning domain for:

- Each VLAN listed: `vlan-id-list [ 100 200 300 ]`
- Each VLAN in a range: `vlan-id-list [ 100-200 ]`
- Each VLAN in a list and range combination: `vlan-id-list [ 50, 100-200, 300 ]`

The following steps outline the process for bridging a packet received over a Layer 2 logical interface when you specify a normalizing VLAN identifier using either the `vlan-id number` or `vlan-tags` statement for a bridge domain or a VPLS routing instance:

1. When a packet is received on a physical port, it is accepted only if the VLAN identifier of the packet matches the VLAN identifier of one of the logical interfaces configured on that port.
2. The VLAN tags of the received packet are then compared with the normalizing VLAN identifier. If the VLAN tags of the packet are different from the normalizing VLAN identifier, the VLAN tags are rewritten as described in [Table 3 on page 16](#).
3. If the source MAC address of the received packet is not present in the source MAC table, it is learned based on the normalizing VLAN identifier.
4. The packet is then forwarded toward one or more outbound Layer 2 logical interfaces based on the destination MAC address. A packet with a known unicast destination MAC address is forwarded only to one outbound logical interface. For each outbound Layer 2 logical interface, the normalizing VLAN identifier configured for the bridge domain or VPLS routing instance is compared with the VLAN tags configured on that logical interface. If the VLAN tags associated with an outbound logical interface do not match the normalizing VLAN identifier configured for the bridge domain or VPLS routing instance, the VLAN tags are rewritten as described in [Table 4 on page 17](#).

The tables below show how VLAN tags are applied for traffic sent to and from the bridge domain, depending on how the `vlan-id` and `vlan-tags` statements are configured for the bridge domain and on how VLAN identifiers are configured for the logical interfaces in a bridge domain or VPLS routing instance. Depending on your configuration, the following rewrite operations are performed on VLAN tags:

- **pop**—Remove a VLAN tag from the top of the VLAN tag stack.
- **pop-pop**—Remove both the outer and inner VLAN tags of the frame.
- **pop-swap**—Remove the outer VLAN tag of the frame and replace the inner VLAN tag of the frame.

- **swap**—Replace the VLAN tag of the frame.
- **push**—Add a new VLAN tag to the top of the VLAN stack.
- **push-push**—Push two VLAN tags in front of the frame.
- **swap-push**—Replace the VLAN tag of the frame and add a new VLAN tag to the top of the VLAN stack.
- **swap-swap**—Replace both the outer and inner VLAN tags of the frame.

Table 3 on page 16 shows specific examples of how the VLAN tags for packets sent to the bridge domain are processed and translated, depending on your configuration. “–” means that the statement is not supported for the specified logical interface VLAN identifier. “No operation” means that the VLAN tags of the received packet are not translated for the specified input logical interface.

**Table 3: Statement Usage and Input Rewrite Operations for VLAN Identifiers for a Bridge Domain**

VLAN Identifier of Logical Interface	VLAN Configurations for Bridge Domain			
	vlan-id none	vlan-id 200	vlan-id all	vlan tags outer 100 inner 300
none	No operation	push 200	–	push 100, push 300
200	pop 200	No operation	No operation	swap 200 to 300, push 100
1000	pop 1000	swap 1000 to 200	No operation	swap 1000 to 300, push 100
vlan-tags outer 2000 inner 300	pop 2000, pop 300	pop 2000, swap 300 to 200	pop 2000	swap 2000 to 100
vlan-tags outer 100 inner 400	pop 100, pop 400	pop 100, swap 400 to 200	pop 100	swap 400 to 300
vlan-id-range 10-100	–	–	No operation	–
vlan-tags outer 200 inner-range 10-100	–	–	pop 200	–

Table 4 on page 17 shows specific examples of how the VLAN tags for packets sent from the bridge domain are processed and translated, depending on your configuration. “–” means that the statement is not supported for the specified logical interface VLAN identifier. “No operation” means that the VLAN tags of the outbound packet are not translated for the specified output logical interface.

Table 4: Statement Usage and Output Rewrite Operations for VLAN Identifiers for a Bridge Domain

VLAN Identifier of Logical Interface	VLAN Configurations for Bridge Domain			
	vlan-id none	vlan-id 200	vlan-id all	vlan tags outer 100 inner 300
none	no operation	pop 200	–	pop 100, pop 300
200	push 200	No operation	No operation	pop 100, swap 300 to 200
1000	push 1000	swap 200 to 1000	No operation	pop 100, swap 300 to 1000
vlan-tags outer 2000 inner 300	push 2000, push 300	swap 200 to 300, push 2000	push 2000	swap 100 to 2000
vlan-tags outer 100 inner 400	push 100, push 400	swap 200 to 400, push 100	push 100	swap 300 to 400
vlan-id-range 10-100	–	–	No operation	–
vlan-tags outer 200 inner-range 10-100	–	–	push 200	–

**Related Documentation**

- [Configuring Integrated Routing and Bridging for Bridge Domains on page 17](#)
- [Layer 2 Learning and Forwarding Overview on page 7](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)

## Configuring Integrated Routing and Bridging for Bridge Domains

Integrated routing and bridging (IRB) provides simultaneous support for Layer 2 bridging and Layer 3 routing on the same interface. IRB enables you to route packets to another routed interface or to another bridge domain that has an IRB interface configured. You configure a logical routing interface by including the **irb** statement at the **[edit interfaces]** hierarchy level and include that interface in the bridge domain. For more information about how to configure a routing interface, see the *Junos OS Network Interfaces Library for Routing Devices*.



**NOTE:** You can include only one routing interface in a bridge domain.

To configure a bridge domain with IRB support, include the following statements:

```
[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    interface interface-name;
    routing-interface routing-interface-name;
    service-id number;
    vlan-id (none | number);
    vlan-tags outer number inner number;
  }
}
```

For each bridge domain that you configure, specify a **bridge-domain-name**. You must also specify the value **bridge** for the **domain-type** statement.

For the **vlan-id** statement, you can specify either a valid VLAN identifier or the **none** option.



**NOTE:** If you configure a routing interface to support IRB in a bridge domain, you cannot use the **all** option for the **vlan-id** statement.

The **vlan-tags** statement enables you to specify a pair of VLAN identifiers; an **outer** tag and an **inner** tag.



**NOTE:** For a single bridge domain, you can include either the **vlan-id** statement or the **vlan-tags** statement, but not both.

For MC-LAG bridge domains, when the VLAN identifier is **none**, use the **service-id** statement to facilitate media access control (MAC) and Address Resolution Protocol (ARP) synchronization among MC-LAG peers.

To include one or more logical interfaces in the bridge domain, specify the interface name for each Ethernet interface to include that you configured at the **[edit interfaces]** hierarchy level.



**NOTE:** A maximum of 4000 active logical interfaces are supported on a bridge domain or on each mesh group in a VPLS routing instance configured for Layer 2 bridging.

To associate a routing interface with a bridge domain, include the **routing-interface routing-interface-name** statement and specify a **routing-interface-name** you configured at the **[edit interfaces irb]** hierarchy level. You can configure only one routing interface for each bridge domain. For more information about how to configure logical and routing interfaces, see the *Junos OS Network Interfaces Library for Routing Devices*.



In Junos OS Release 9.0 and later, IRB interfaces are supported for multicast snooping. For more information about multicast snooping, see the *Multicast Protocols Feature Guide for Routing Devices*.

In Junos 11.4 and later, IP multicast is supported on Layer 2 trunk ports through IRB interfaces using the Trio chipset.

In Junos OS Release 9.6 and later, in multihomed VPLS configurations, you can configure VPLS to keep a VPLS connection up if only an IRB interface is available by configuring the **irb** option for the **connectivity-type** statement at the **[edit routing-instances routing-instance-name protocols vpls]** hierarchy level. The **connectivity-type** statement has two options, **ce** and **irb**. The **ce** option is the default and specifies that a CE interface is required to maintain the VPLS connection. By default, if only an IRB interface is available, the VPLS connection is brought down. For more information about configuring VPNs, see the *Junos VPN Configuration Guide*.



**NOTE:** When you configure IRB interfaces in more than one logical system on a device, all of the of the IRB logical interfaces share the same MAC address.

**Related Documentation**

- [Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 6](#)
- [Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12](#)

## Configuring Bridge Domains as Switches for Layer 2 Trunk Ports

You can configure a set of bridge domains that are associated with a Layer 2 trunk port. The set of bridge domains function as a switch. Packets received on a trunk interface are forwarded within a bridge domain that has the same VLAN identifier. A trunk interface also provides support for IRB, which provides support for Layer 2 bridging and Layer 3 IP routing on the same interface.

To configure a Layer 2 trunk port and set of bridge domains, include the following statements:

```
[edit interfaces]
interface-name {
  unit number {
    family bridge {
      interface-mode access;
      vlan-id number;
    }
  }
}
interface-name {
  native-vlan-id number;
  unit number {
    family bridge {
      interface-mode trunk;
```

```
        vlan-id-list [ vlan-id-numbers ];
    }
}
[edit bridge-domains]
bridge-domain-name {
    vlan-id number;
    vlan-id-list [ vlan-id-numbers ];
    ....
}
```

For **interface-mode trunk**, you can include the **vlan-id-list** statement.

You must configure a bridge domain and VLAN identifier for each VLAN associated with the trunk interface. You can configure one or more trunk or access interfaces at the **[edit interfaces]** hierarchy level. An access interface enables you to accept packets with no VLAN identifier. For more information about configuring trunk and access interfaces, see the *Junos OS Network Interfaces Library for Routing Devices*.

**Related Documentation**

- [Configuring a Bridge Domain on page 11](#)

## CHAPTER 4

# Layer 2 Virtual Switches

- [Configuring Integrated Routing and Bridging for a Bridge Domain in a Layer 2 Virtual Switch on page 21](#)
- [Configuring VPLS Ports in a Virtual Switch on page 22](#)
- [Configuring a Layer 2 Virtual Switch with a Layer 2 Trunk Port on page 24](#)
- [Configuring a Layer 2 Virtual Switch on page 25](#)

## Configuring Integrated Routing and Bridging for a Bridge Domain in a Layer 2 Virtual Switch

---

Integrated routing and bridging (IRB) provides simultaneous support for Layer 2 bridging and Layer 3 IP routing on the same interface. IRB enables you to route local packets to another routed interface or to another bridge domain that has a Layer 3 protocol configured. You configure a logical routing interface by including the **irb** statement at **[edit interfaces]** hierarchy level and include that interface in the bridge domain. For more information about how to configure a routing interface, see the *Junos OS Network Interfaces Library for Routing Devices*.



**NOTE:** You can include only one routing interface in a bridge domain.

To configure a virtual switch with IRB support, include the following statements:

```
[edit]
routing-instances {
  routing-instance-name {
    instance-type virtual-switch;
    bridge-domains {
      bridge-domain-name {
        domain-type bridge;
        interface interface-name;
        routing-interface routing-interface-name;
        vlan-id (none | number);
        vlan-tags outer number inner number;
      }
    }
  }
}
```

To enable a virtual switch, you must specify **virtual-switch** as the **instance-type**. The **instance-type virtual-switch** statement is not supported at the **[edit logical-systems logical-system-name]** hierarchy level.

For each bridge domain that you configure for the virtual switch, specify a **bridge-domain-name**. You must also specify the value **bridge** for the **domain-type** statement.

For the **vlan-id** statement, you can specify either a valid VLAN identifier or the **none** option.



**NOTE:** For a single bridge domain, you can include either the **vlan-id** statement or the **vlan-tags** statement, but not both.

To include one or more logical interfaces in the bridge domain, specify the **interface-name** for each Ethernet interface to include that you configured at the **[edit interfaces irb]** hierarchy level.

To associate a routing interface with a bridge domain, include the **routing-interface routing-interface-name** statement and specify a **routing-interface-name** you configured at the **[edit interfaces irb]** hierarchy level. You can configure only one routing interface for each bridge domain. For more information about how to configure logical and routing interfaces, see the *Junos OS Network Interfaces Library for Routing Devices*.



**NOTE:** If you configure a routing interface to support IRB in a bridge domain, you cannot use the **all** option for the **vlan-id** statement.

**Related  
Documentation**

- [Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 6](#)
- [Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12](#)

---

## Configuring VPLS Ports in a Virtual Switch

In Junos OS Release 9.3 and later, you can configure VPLS ports in a virtual switch so that the logical interfaces of the Layer 2 bridge domains in the virtual switch can handle VPLS routing instance traffic. VPLS configuration no longer requires a dedicated routing instance of type **vpls**. Packets received on a Layer 2 trunk interface are forwarded within a bridge domain that has the same VLAN identifier.

A trunk interface is implicitly associated with bridge domains based on VLAN membership. Whereas access interfaces can be part of one VLAN only, trunk interfaces multiplex traffic from multiple VLANs and usually interconnect switches. A Layer 2 trunk port also supports IRB.

To configure VPLS ports in a virtual switch, perform the following tasks:

1. To configure the Layer 2 trunk ports that you will associate with the bridge domains in the virtual switch, include the following statements in the configuration:

```
[edit]
interfaces {
  interface-name {
    unit logical-unit-number { # Call this 'L2-trunk-port-A'
      family bridge {
        interface-mode trunk;
        vlan-id-list [ vlan-id-numbers ] ; # Trunk mode VLAN membership for this
        interface
      }
    }
  }
  .
  .
  .
  interface-name {
    unit logical-unit-number { # Call this 'L2-trunk-port-B'
      family bridge {
        interface-mode trunk;
        vlan-id-list [ vlan-id-numbers ] ; # Trunk mode VLAN membership for this
        interface
      }
    }
  }
}
```

To configure a logical interface as a trunk port, include the **interface-mode** statement and the **trunk** option at the **[edit interfaces interface-name unit logical-unit-number family bridge]** hierarchy level.

To configure all the VLAN identifiers to associate with a Layer 2 trunk port, include the **vlan-id-list [ vlan-id-numbers ]** statement at the **[edit interfaces interface-name unit logical-unit-number family bridge]** hierarchy level.

Each of the logical interfaces “**L2-trunk-port-A**” and “**L2-trunk-port-B**” accepts packets tagged with any VLAN ID specified in the respective **vlan-id-list** statements.

2. To configure a virtual switch consisting of a set of bridge domains that are associated with one or more logical interfaces configured as a trunk ports, include the following statements in the configuration:

```
[edit]
routing-instance {
  routing-instance-name
  instance-type virtual-switch;
  interface L2-trunk-port-A; # Include one trunk port
  interface L2-trunk-port-B; # Include the other trunk port
  bridge-domains {
    bridge-domain-name-0 {
      domain-type bridge;
      vlan-id number;
    }
    bridge-domain-name-1 {
```

```
        domain-type bridge;
        vlan-id number;
    }
}
protocols {
    vpls {
        vpls-id number;
        ... vpls-configuration ...
    }
}
}
```

To begin configuring a virtual switch, include the **instance-type** statement and the **virtual-switch** option at the **[edit routing-instances routing-instance-name]** hierarchy level.

To configure a virtual switch consisting of a set of bridge domains that are associated with one or more logical interfaces configured as a trunk ports, you must identify each logical interface by including the **interface interface-name** statement at the **[edit routing-instances routing-instance-name]** hierarchy level.

For each VLAN configured for a trunk port, you must configure a bridge-domain that includes the trunk port logical interface and uses a VLAN identifier within the range carried by that trunk interface. To configure, include the **domain-type bridge**, **vlan-id number**, and statements at the **[edit routing-instances routing-instance-name bridge-domain bridge-domain-name]** hierarchy level.

**Related Documentation**

- [Configuring a Bridge Domain on page 11](#)

---

## Configuring a Layer 2 Virtual Switch with a Layer 2 Trunk Port

---

You can associate one or more Layer 2 trunk interfaces with a virtual switch. A Layer 2 trunk interface enables you to configure a logical interface to represent multiple VLANs on the physical interface. Within the virtual switch, you configure a bridge domain and VLAN identifier for each VLAN identifier configured on the trunk interfaces. Packets received on a trunk interface are forwarded within a bridge domain that has the same VLAN identifier. Each virtual switch you configure operates independently and can participate in a different Layer 2 network.

A virtual switch configured with a Layer 2 trunk port also supports IRB within a bridge domain. IRB provides simultaneous support for Layer 2 bridging and Layer 3 IP routing on the same interface. Only an interface configured with the **interface-mode (access | trunk)** statement can be associated with a virtual switch. An access interface enables you to accept packets with no VLAN identifier. For more information about configuring trunk and access interfaces, see the *Junos OS Network Interfaces Library for Routing Devices*.

In addition, you can configure Layer 2 learning and forwarding properties for the virtual switch.

To configure a virtual switch with a Layer 2 trunk interface, include the following statements:

```
[edit]
routing-instances {
  routing-instance-name {
    instance-type virtual-switch;
    interface interface-name;
    bridge-domains {
      bridge-domain-name {
        vlan-id number;
      }
    }
  }
}
```



**NOTE:** You must configure a bridge domain and VLAN identifier for each VLAN identifier configured for the trunk interface.

#### Related Documentation

- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)

## Configuring a Layer 2 Virtual Switch

A Layer 2 virtual switch, which isolates a LAN segment with its spanning-tree protocol instance and separates its VLAN ID space, filters and forwards traffic only at the data link layer. Layer 3 routing is not performed. Each bridge domain consists of a set of logical ports that participate in Layer 2 learning and forwarding. A virtual switch represents a Layer 2 network.

Two main types of interfaces are used in virtual switch hierarchies:

- **Layer 2 logical interface**—This type of interface uses the VLAN-ID as a virtual circuit identifier and the scope of the VLAN-ID is local to the interface port. This type of interface is often used in service-provider-centric applications.
- **Access or trunk interface**—This type of interface uses a VLAN-ID with global significance. The access or trunk interface is implicitly associated with bridge domains based on VLAN membership. Access or trunk interfaces are typically used in enterprise-centric applications.



**NOTE:** The difference between access interfaces and trunk interfaces is that access interfaces can be part of one VLAN only and the interface is normally attached to an end-user device (packets are implicitly associated with the configured VLAN). In contrast, trunk interfaces multiplex traffic from multiple VLANs and usually interconnect switches.

To configure a Layer 2 virtual switch, include the following statements:

```
[edit]
routing-instances {
  routing-instance-name (
    instance-type virtual-switch;
    bridge-domains {
      bridge-domain-name {
        domain-type bridge;
        interface interface-name;
        vlan-id (all | none | number); # Cannot be used with 'vlan-tags' statement
        vlan-id-list [ vlan-id-numbers ];
        vlan-tags outer number inner number; # Cannot be used with 'vlan-id' statement
      }
    }
  }
  protocols {
    mstp {
      ...mstp-configuration ...
    }
  }
}
```

To enable a virtual switch, you must specify **virtual-switch** as the **instance-type**.

For each bridge domain that you configure for the virtual switch, specify a **bridge-domain-name**. You must also specify the value **bridge** for the **domain-type** statement.

For the **vlan-id** statement, you can specify either a valid VLAN identifier or the **none** or **all** options. If you specify a valid VLAN identifier, you cannot also use the **none** option. These statements are mutually exclusive.

The **all** option is not supported with IRB.



**NOTE:** You do not have to specify a VLAN identifier for a bridge domain. However, you cannot specify the same VLAN identifier for more than one bridge domain within a virtual switch. Each bridge domain within a virtual switch must have a unique VLAN identifier.



**NOTE:** For a single bridge domain, you can include either the **vlan-id** statement or the **vlan-tags** statement, but not both.

To specify one or more logical interfaces to include in the bridge domain, specify an **interface-name** for an Ethernet interface you configured at the **[edit interfaces]** hierarchy level. For more information, see the *Junos OS Network Interfaces Library for Routing Devices*.

For information about how to configure spanning tree protocols, see the *Junos OS Feature Guides*.



**Related  
Documentation**

- [Guidelines for Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 6](#)
- [Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12](#)
- [Configuring Integrated Routing and Bridging for a Bridge Domain in a Layer 2 Virtual Switch on page 21](#)



## CHAPTER 5

# Layer 2 Learning and Forwarding for Bridge Domains

- [Disabling MAC Learning for a Bridge Domain or Logical Interface on page 29](#)
- [Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain on page 30](#)
- [Configuring the Size of the MAC Address Table on page 31](#)
- [Limiting MAC Addresses Learned from an Interface in a Bridge Domain on page 32](#)
- [Enabling MAC Accounting for a Bridge Domain on page 33](#)

### Disabling MAC Learning for a Bridge Domain or Logical Interface

---

You can disable MAC learning for all logical interfaces in a specified bridge domain, or for a specific logical interface in a bridge domain. Disabling dynamic MAC learning prevents the specified interfaces from learning source MAC addresses.

To disable MAC learning for all logical interfaces in a bridge domain in a virtual switch, include the **no-mac-learning** statement at the **[edit bridge-domains *bridge-domain-name* bridge-options]** hierarchy level:

```
[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    interface interface-name;
    bridge-options {
      no-mac-learning;
    }
  }
}
```

To disable MAC learning for a specific logical interface in a bridge domain, include the **no-mac-learning** statement at the **[edit bridge-domains *bridge-domain-name* bridge-options interface *interface-name*]** hierarchy level.

```
[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    interface interface-name;
    bridge-options {
```

```

interface interface-name {
    no-mac-learning;
}
}
}

```



**NOTE:** When you disable MAC learning, source MAC addresses are not dynamically learned, and any packets sent to these source addresses are flooded into the bridge domain.



**NOTE:** When you gather interfaces into a bridge domain, the `no-mac-learn-enable` statement at the [edit interfaces *interface-name* *gigether-options* ethernet-switch-profile] hierarchy level is not supported. You must use the `no-mac-learning` statement at the [edit bridge-domains *bridge-domain-name* bridge-options interface *interface-name*] hierarchy level to disable MAC learning on an interface in a bridge domain.



**NOTE:** When MAC learning is disabled for a VPLS routing instance, traffic is not load balanced and only one of the equal-cost next hops is used.

#### Related Documentation

- [Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain on page 30](#)
- [Configuring the Size of the MAC Address Table on page 31](#)
- [Limiting MAC Addresses Learned from an Interface in a Bridge Domain on page 32](#)
- [Enabling MAC Accounting for a Bridge Domain on page 33](#)

## Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain

You can manually add static MAC entries for the logical interfaces in a bridge domain. You can specify one or more static MAC addresses for each logical interface.

To add a static MAC address for a logical interface in a bridge domain, include the `static-mac` *mac-address* statement at the [edit bridge-domains *bridge-domain-name* bridge-options interface *interface-name*] hierarchy level.

```

[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    bridge-options {
      interface interface-name {
        static-mac mac-address {
          <vlan-id number>;
        }
      }
    }
  }
}

```

```

    }
  }
}

```

You can optionally specify a VLAN identifier for the static MAC address by using the **vlan-id** statement. To specify a VLAN identifier for a static MAC address, you must use the **all** option when configuring a VLAN identifier for the bridge domain.



**NOTE:** If a static MAC address you configure for a logical interface appears on a different logical interface, packets sent to that interface are dropped.

#### Related Documentation

- [Disabling MAC Learning for a Bridge Domain or Logical Interface on page 29](#)
- [Configuring the Size of the MAC Address Table on page 31](#)
- [Limiting MAC Addresses Learned from an Interface in a Bridge Domain on page 32](#)
- [Enabling MAC Accounting for a Bridge Domain on page 33](#)

## Configuring the Size of the MAC Address Table

You can modify the size of the MAC address table for each bridge domain. The default table size is 5120 addresses. The minimum you can configure is 16 addresses, and the maximum is 1,048,575 addresses.

If the MAC table limit is reached, new addresses can no longer be added to the table. Unused MAC addresses are removed from the MAC address table automatically. This frees space in the table, allowing new entries to be added.

To modify the size of the MAC table, include the **mac-table-size limit** statement at the **[edit bridge-domains *bridge-domain-name* bridge-options]** hierarchy level:

```

[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    bridge-options {
      mac-table-size limit {
        packet-action drop;
      }
    }
  }
}

```

#### Related Documentation

- [Disabling MAC Learning for a Bridge Domain or Logical Interface on page 29](#)
- [Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain on page 30](#)
- [Limiting MAC Addresses Learned from an Interface in a Bridge Domain on page 32](#)
- [Enabling MAC Accounting for a Bridge Domain on page 33](#)

## Limiting MAC Addresses Learned from an Interface in a Bridge Domain

---

You can configure a limit on the number of MAC addresses learned from a specific bridge domain or from a specific logical interface that belongs to a bridge domain.

To configure a limit for the number of MAC addresses learned from each logical interface in a bridge domain, include the **interface-mac-limit** *limit* statement at the **[edit bridge-domains *bridge-domain-name* bridge-options]** hierarchy level:

```
[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    interface interface-name;
    bridge-options {
      interface-mac-limit limit;
    }
  }
}
```

To limit the number of MAC addresses learned from a specific logical interface in a bridge domain or an entire bridge domain, include the **interface-mac-limit** *limit* statement at the **[edit bridge-domains *bridge-domain-name* bridge-options interface *interface-name*]** or **[edit bridge-domains *bridge-domain-name* bridge-options]** hierarchy level:

```
[edit]
bridge-domains {
  bridge-domain-name {
    domain-type bridge;
    interface interface-name;
    bridge-options {
      interface-mac-limit limit{
        packet-action drop;
      }
    }
  }
  interface interface-name {
    interface-mac-limit limit{
      packet-action drop;
    }
  }
}
```

The value you configure for a specific logical interface overrides any value you specify for the entire bridge domain at the **[edit bridge-domains *bridge-domain-name* bridge-options]** hierarchy level.

The default limit to the number of MAC addresses that can be learned on a logical interface is 1024. The range that you can configure for a specific logical interface is 1 through 131,071.

After the MAC address limit is reached, the default is for any incoming packets with a new source MAC address to be forwarded. You can specify that the packets be dropped by including the **packet-action drop** statement. To specify that packets be dropped for the entire bridge domain, include the **packet-action drop** statement at the **[edit bridge-domains *bridge-domain-name* bridge-options interface-mac-limit *limit*]** hierarchy level:

```
[edit bridge-domains bridge-domain-name bridge-options interface-mac-limit limit]
packet-action drop;
```

To specify that the packets be dropped for a specific logical interface in a bridge domain, include the **packet-action drop** statement at the **[edit bridge-domains *bridge-domain-name* bridge-options interface *interface-name* interface-mac-limit *limit*]** hierarchy level:

```
[edit bridge-domains bridge-domain-name bridge-options interface interface-name
interface-mac-limit limit]
packet-action drop;
```

You can also configure a limit to the number of MAC addresses learned for an MX Series router.

#### Related Documentation

- [Disabling MAC Learning for a Bridge Domain or Logical Interface on page 29](#)
- [Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain on page 30](#)
- [Configuring the Size of the MAC Address Table on page 31](#)
- [Enabling MAC Accounting for a Bridge Domain on page 33](#)

## Enabling MAC Accounting for a Bridge Domain

By default, MAC accounting is disabled. You can enable packet counting for a bridge domain. When you enable packet accounting, the Junos OS maintains packet counters for each MAC address learned on the interfaces in the bridge domain.

To enable MAC accounting for a bridge domain, include the **mac-statistics** statement at the **[edit bridge-domains *bridge-domain-name* bridge-options]** hierarchy level:

```
[edit bridge-domains bridge-domain-name bridge-options]
mac-statistics;
```

#### Related Documentation

- [Disabling MAC Learning for a Bridge Domain or Logical Interface on page 29](#)
- [Configuring Static MAC Addresses for Logical Interfaces in a Bridge Domain on page 30](#)
- [Configuring the Size of the MAC Address Table on page 31](#)
- [Limiting MAC Addresses Learned from an Interface in a Bridge Domain on page 32](#)





## CHAPTER 6

# Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports

- [Disabling MAC Learning for a Set of Bridge Domains on page 35](#)
- [Limiting the Number of MAC Addresses Learned from a Trunk Port on page 35](#)
- [Configuring the Size of the MAC Address Table for a Set of Bridge Domains on page 36](#)
- [Enabling MAC Accounting for a Set of Bridge Domains on page 37](#)

### Disabling MAC Learning for a Set of Bridge Domains

---

You can disable MAC learning for a set of bridge domains. Disabling dynamic MAC learning prevents the Layer 2 trunk port associated with the set of bridge domains from learning source and destination MAC addresses. When you disable MAC learning, source MAC addresses are not dynamically learned, and any packets sent to these source addresses are flooded into the switch.

To disable MAC learning for a set of bridge domains, include the **no-mac-learning** statement at the **[edit switch-options]** hierarchy level:

```
[edit switch-options]  
no-mac-learning;
```

#### Related Documentation

- [Limiting the Number of MAC Addresses Learned from a Trunk Port on page 35](#)
- [Configuring the Size of the MAC Address Table for a Set of Bridge Domains on page 36](#)
- [Enabling MAC Accounting for a Set of Bridge Domains on page 37](#)

### Limiting the Number of MAC Addresses Learned from a Trunk Port

---

You can configure a limit on the number of MAC addresses learned from a trunk port or from a specific trunk or access interface.

To limit the number of MAC addresses learned through a trunk port associated with a set of bridge domains, include the **interface-mac-limit** *limit* statement at the **[edit switch-options]** hierarchy level:

```
[edit]
switch-options {
  interface-mac-limit limit;
}
```

To limit the number of MAC addresses learned from a specific logical interface configured as an access interface or a trunk interface, include the **interface-mac-limit** *limit* statement at the **[edit switch-options interface *interface-name*]** hierarchy level:

```
[edit]
switch-options {
  interface interface-name {
    interface-mac-limit limit;
  }
}
```

The default value for the number MAC addresses that can be learned from a logical interface is 1024. You can specify a limit either for a set of bridge domains or for a specific logical interface in the range from 1 through 131,071. The value you configure for a specific logical interface overrides any value you specify for the set of bridge domains.

After the specified MAC address limit is reached, the default is for any incoming packets with a new source MAC address to be forwarded. You can specify that the packets be dropped for the entire virtual switch after the MAC address limit is reached by including the **packet-action drop** statement at the **[edit switch-options interface-mac-limit *limit*]** hierarchy level:

```
[edit switch-options interface interface-name interface-mac-limit limit]
packet-action drop;
```

To specify that the packets be dropped from a specific logical interface in a set of bridge domains with a trunk port after the MAC address limit is reached, include the **packet-action drop** statement at the **[edit routing-instances *routing-instance-name* interface *interface-name* interface-mac-limit *limit*]** hierarchy level:

```
[edit routing-instances routing-instance-name interface interface-name interface-mac-limit
limit]
packet-action drop;
```

#### Related Documentation

- [Disabling MAC Learning for a Set of Bridge Domains on page 35](#)
- [Configuring the Size of the MAC Address Table for a Set of Bridge Domains on page 36](#)
- [Enabling MAC Accounting for a Set of Bridge Domains on page 37](#)

---

## Configuring the Size of the MAC Address Table for a Set of Bridge Domains

You can modify the size of the MAC address table for a set of bridge domains. The minimum you can configure is 16 addresses, and the maximum is 1,048,575 addresses. The default table size is 5120 addresses.

If the MAC table limit is reached, new addresses can no longer be added to the table. Unused MAC addresses are removed from the MAC address table automatically. This frees space in the table, allowing new entries to be added to the table.

To modify the size of the MAC table for a set of bridge domains, include the **mac-table-size** statement at the **[edit switch-options]** hierarchy level:

```
[edit switch-options]  
mac-table-size limit;
```

**Related  
Documentation**

- [Disabling MAC Learning for a Set of Bridge Domains on page 35](#)
- [Limiting the Number of MAC Addresses Learned from a Trunk Port on page 35](#)
- [Enabling MAC Accounting for a Set of Bridge Domains on page 37](#)

---

## Enabling MAC Accounting for a Set of Bridge Domains

---

By default, MAC accounting is disabled. You can enable packet counting for a set of bridge domains. After you enable packet accounting, the Junos OS maintains packet counters for each MAC address learned on the trunk port associated with the set of bridge domains.

To enable MAC accounting for a set of bridge domains, include the **mac-statistics** statement at the **[edit switch-options]** hierarchy level:

```
[edit switch-options]  
mac-statistics;
```

**Related  
Documentation**

- [Disabling MAC Learning for a Set of Bridge Domains on page 35](#)
- [Limiting the Number of MAC Addresses Learned from a Trunk Port on page 35](#)
- [Configuring the Size of the MAC Address Table for a Set of Bridge Domains on page 36](#)



## CHAPTER 7

# Layer 3 Tunnel Services Interfaces with a DPC

- [Configuring Layer 3 Tunnel Services Interfaces on an MX Series Router with a DPC on page 39](#)

### Configuring Layer 3 Tunnel Services Interfaces on an MX Series Router with a DPC

The MX Series routers support Dense Port Concentrators (DPCs) with built-in Ethernet ports, which do not support Tunnel Services PICs. To create tunnel interfaces on an MX Series router with a DPC, you configure the DPC and the corresponding Packet Forwarding Engine to use for tunneling services at the **[edit chassis]** hierarchy level. You also configure the amount of bandwidth reserved for tunnel services. The Junos OS creates tunnel interfaces on the Packet Forwarding Engine.

To create tunnel interfaces on MX Series routers, include the following statements at the **[edit chassis]** hierarchy level:

```
[edit chassis]
fpc slot-number {
  pic number {
    tunnel-services {
      bandwidth bandwidth-value;
    }
  }
}
```

Include the **fpc slot-number** statement to specify the slot number of the DPC. If two SCBs are installed, the range is 0 through . If three SCBs are installed, the range is 0 through 5 and 7 through .

Include the **pic number** statement to specify the number of the Packet Forwarding Engine on the DPC. The range is 0 through 3.

You can also specify the amount of bandwidth to allocate for tunnel traffic on each Packet Forwarding Engine by including the **bandwidth bandwidth-value** statement at the **[edit chassis fpc slot-number pic pic-number]** hierarchy level:

- **1g** indicates that 1 Gbps of bandwidth is reserved for tunnel traffic. Configure this option only for a Packet Forwarding Engine on a Gigabit Ethernet 40-port DPC.

- **10g** indicates that 10 Gbps of bandwidth is reserved for tunnel traffic. Configure this option only for a Packet Forwarding Engine on a 10-Gigabit Ethernet 4-port DPC.
- **20g or 40g**—Configure 20 gigabits per second or 40 gigabits per second only on an MX Series router with the MPC3E and the 100-Gigabit CFP MIC.

If you specify a bandwidth that is not compatible with the type of DPC and Packet Forwarding Engine, tunnel services are not activated. For example, you cannot specify a bandwidth of 1 Gbps for a Packet Forwarding Engine on a 10-Gigabit Ethernet 4-port DPC.

When you configure tunnel interfaces on the Packet Forwarding Engine of a 10-Gigabit Ethernet 4-port DPC, the Ethernet interfaces for that port are removed from service and are no longer visible in the command-line interface (CLI). The Packet Forwarding Engine of a 10-Gigabit Ethernet 4-port DPC supports either tunnel interfaces or Ethernet interfaces, but not both. Each port on the 10-Gigabit Ethernet 4-port DPC includes two LEDs, one for tunnel services and one for Ethernet services, to indicate which type of service is being used. On the Gigabit Ethernet 40-port DPC, you can configure both tunnel and Ethernet interfaces at the same time.

To verify that the tunnel interfaces have been created, issue the **show interfaces terse** operational mode command. For more information, see the *Junos OS Operational Mode Commands*.

For additional information about tunnel services, see the “Tunnel Services” chapter in the *Junos OS Services Interfaces Library for Routing Devices*.

**Related  
Documentation**

- *MX Series Router Architecture*
- *MX Series Router Packet Forwarding and Data Flow*
- *Line Cards Supported on MX Series Routers*

## CHAPTER 8

# Layer 2 Address Learning and Forwarding

- [Configuring the MAC Table Timeout Interval on page 41](#)
- [Enabling MAC Accounting on page 42](#)
- [Limiting the Number of MAC Addresses Learned from Each Logical Interface on page 42](#)
- [Disabling Layer 2 Learning and Forwarding on page 43](#)
- [Example: Loop Detection Using the MAC Move Approach on page 43](#)

## Configuring the MAC Table Timeout Interval

---

By default, the timeout interval for all entries in the MAC table is 300 seconds. You can modify the timeout interval for MAC table entries on an MX Series router. You cannot modify the timeout interval only for specific MAC table entries, such as for a bridge domain or a virtual switch.



**NOTE:** The timeout interval applies only to dynamically learned MAC addresses. This value does not apply to configured static MAC addresses, which never time out.

To modify the timeout interval for the MAC table for the entire routing platform, include the **global-mac-table-aging-time** *seconds* statement at the **[edit protocols l2-learning]** hierarchy level:

```
[edit protocols l2-learning]  
global-mac-table-aging-time seconds;
```

The range for *seconds* is from 10 through 1,000,0000.

### Related Documentation

- [Layer 2 Learning and Forwarding Overview on page 7](#)
- [Enabling MAC Accounting on page 42](#)
- [Limiting the Number of MAC Addresses Learned from Each Logical Interface on page 42](#)
- [Disabling Layer 2 Learning and Forwarding on page 43](#)

## Enabling MAC Accounting

---

By default, MAC accounting is disabled. On MX Series routers, you can enable packet accounting either for the router as a whole or for a specific bridge domain. After you enable packet accounting, the Junos OS maintains packet counters for each MAC address learned.

To enable MAC accounting for an MX Series router, include the **global-mac-statistics** statement at the **[edit protocols l2-learning]** hierarchy level:

```
[edit protocols l2-learning]
global-mac-statistics;
```

### Related Documentation

- [Layer 2 Learning and Forwarding Overview on page 7](#)
- [Configuring the MAC Table Timeout Interval on page 41](#)
- [Limiting the Number of MAC Addresses Learned from Each Logical Interface on page 42](#)
- [Disabling Layer 2 Learning and Forwarding on page 43](#)

## Limiting the Number of MAC Addresses Learned from Each Logical Interface

---

You can configure a limit to the number of MAC addresses learned from the logical interfaces on an MX Series router.

To configure a limit to the total number of MAC addresses that can be learned from the logical interfaces, include the **global-mac-limit limit** statement at the **[edit protocols l2-learning]** hierarchy level:

```
[edit]
protocols {
  l2-learning {
    global-mac-limit limit;
  }
}
```

The default limit to the number of MAC addresses that can be learned the router as a whole is 393,215. The range that you can configure for the router as a whole is 20 through 1,048,575.

After the configured MAC address limit is reached, the default is for packets to be forwarded. You can specify that the packets be dropped by including the **packet-action drop** statement at the **[edit protocols l2-learning global-mac-limit]** hierarchy level:

```
[edit]
protocols {
  l2-learning {
    global-mac-limit limit {
      packet-action drop;
    }
  }
}
```



You can also configure a limit to the number of MAC address learned from all the interfaces in a bridge domain or from a specific logical interface only. For more information, see “[Layer 2 Learning and Forwarding for Bridge Domains Overview](#)” on page 5.



**NOTE:** On MX Series routers running Junos OS Release 8.4 and later, statistics for an aged destination MAC entry are not retained. In addition, source and destination statistics are reset during a MAC move. In previous releases, only source statistics were reset during a MAC move.

**Related Documentation**

- [Layer 2 Learning and Forwarding Overview on page 7](#)
- [Configuring the MAC Table Timeout Interval on page 41](#)
- [Enabling MAC Accounting on page 42](#)
- [Disabling Layer 2 Learning and Forwarding on page 43](#)

## Disabling Layer 2 Learning and Forwarding

Disabling dynamic MAC learning on an MX Series router or an EX Series switch prevents all the logical interfaces on the router or switch from learning source and destination MAC addresses.

To disable MAC learning for an MX Series router or an EX Series switch, include the **global-no-mac-learning** statement at the **[edit protocols l2-learning]** hierarchy level:

```
[edit protocols l2-learning]
global-no-mac-learning;
```

For information about how to configure a virtual switch, see “[Configuring a Layer 2 Virtual Switch](#)” on page 25.

**Related Documentation**

- [Layer 2 Learning and Forwarding Overview on page 7](#)
- [Configuring the MAC Table Timeout Interval on page 41](#)
- [Enabling MAC Accounting on page 42](#)
- [Limiting the Number of MAC Addresses Learned from Each Logical Interface on page 42](#)

## Example: Loop Detection Using the MAC Move Approach

This example shows how to detect loops using the MAC move approach.

- [Requirements on page 44](#)
- [Overview on page 44](#)
- [Configuration on page 44](#)
- [Verification on page 46](#)

## Requirements

This example requires the following hardware and software components:

- MX Series 3D Universal Edge Routers
- Junos OS Release 13.2 running on all the devices

## Overview

When a MAC address appears on a different physical interface or within a different unit of the same physical interface and if this behavior occurs frequently, it is considered a MAC move.

Configuration errors at the network can force traffic into never ending circular paths. Once there are loops in the Layer 2 network, one of the symptoms is frequent MAC moves, which can be used for rectification of the problem. When it is observed that a source MAC address is moving among the ports, interface is blocked based on the configured **action-priority** for the interface. If the **action-priority** value configured for interfaces is the same, the last interface for the bridge domain on which the MAC address move occurred is blocked.

## Configuration

### CLI Quick Configuration

To quickly configure this example, copy the following commands, paste them into a text file, remove any line breaks, change any details necessary to match your network configuration, and then copy and paste the commands into the CLI at the **[edit]** hierarchy level.

```
set interfaces ge-1/0/4 vlan-tagging
set interfaces ge-1/0/4 encapsulation flexible-ethernet-services
set interfaces ge-1/0/4 unit 10 encapsulation vlan-bridge
set interfaces ge-1/0/4 unit 10 vlan-id 10
set interfaces ge-1/0/4 unit 11 encapsulation vlan-bridge
set interfaces ge-1/0/4 unit 11 vlan-id 11
set interfaces ge-1/0/5 unit 0 family bridge interface-mode trunk
set interfaces ge-1/0/5 unit 0 family bridge vlan-id-list 10-12
set interfaces ge-1/0/6 unit 0 family bridge interface-mode trunk
set interfaces ge-1/0/6 unit 0 family bridge vlan-id-list 10-12
set bridge-domains bd10 vlan-id 10
set bridge-domains bd10 enable-mac-move-action
set bridge-domains bd10 bridge-options interface ge-1/0/5.0 action-priority 1
set bridge-domains bd10 bridge-options interface ge-1/0/6.0 action-priority 5
set bridge-domains bd11 vlan-id 11
set bridge-domains bd11 enable-mac-move-action
set bridge-domains bd12 vlan-id 12
```

In the previous example, all the interfaces, including the trunk interfaces in bd10 and bd11 will be monitored. If there are frequent MAC moves detected within interfaces ge-1/0/5 and ge-1/0/6, interface ge-1/0/5 is blocked. The blocking for trunk interfaces is such that data traffic only for a VLAN (on which the MAC move is detected) will be blocked and not for all the VLANs in the trunk. No action will be taken if a frequent MAC move is observed in **bd12**.

### Configuring Loop Detection Using the MAC Move Approach

**Step-by-Step Procedure** The following example requires you to navigate various levels in the configuration hierarchy. For information about navigating the CLI, see *Using the CLI Editor in Configuration Mode*.

To configure loop detection using the MAC address move approach:

1. Configure the interfaces.

```
[edit interfaces]
user@host# set ge-1/0/4 vlan-tagging
user@host# set ge-1/0/4 encapsulation flexible-ethernet-services
user@host# set ge-1/0/4 unit 10 encapsulation vlan-bridge
user@host# set ge-1/0/4 unit 10 vlan-id 10
user@host# set ge-1/0/4 unit 11 encapsulation vlan-bridge
user@host# set ge-1/0/4 unit 11 vlan-id 11
```

```
user@host# set ge-1/0/5 unit 0 family bridge interface-mode trunk
user@host# set ge-1/0/5 unit 0 family bridge vlan-id-list 10-12
```

```
user@host# set ge-1/0/6 unit 0 family bridge interface-mode trunk
user@host# set ge-1/0/6 unit 0 family bridge vlan-id-list 10-12
```

2. Configure the bridge domain parameters.

```
[edit bridge-domains]
user@host# set bd10 vlan-id 10
user@host# set bd10 enable-mac-move-action
user@host# set bd10 bridge-options interface ge-1/0/5.0 action-priority 1
user@host# set bd10 bridge-options interface ge-1/0/6.0 action-priority 5
```

```
user@host# set bd11 vlan-id 11
user@host# set bd11 enable-mac-move-action
```

```
user@host# set bd12 vlan-id 12
```

### Results

From configuration mode, confirm your configuration by entering **show interfaces** and **show bridge-domains** commands. If the output does not display the intended configuration, repeat the instructions in this example to correct the configuration.

```
user@host# show interfaces
ge-1/0/4 {
  vlan-tagging;
  encapsulation flexible-ethernet-services;
  unit 10 {
    encapsulation vlan-bridge;
    vlan-id 10;
  }
  unit 11 {
    encapsulation vlan-bridge;
```

```
        vlan-id 11;
    }
}
ge-1/0/5 {
    unit 0 {
        family bridge {
            interface-mode trunk;
            vlan-id-list 10-12;
        }
    }
}
ge-1/0/6 {
    unit 0 {
        family bridge {
            interface-mode trunk;
            vlan-id-list 10-12;
        }
    }
}

user@host# show bridge-domains
bridge-domains {
    bd10 {
        vlan-id 10;
        bridge-options {
            interface ge-1/0/5.0 {
                action-priority 1;
            }
            interface ge-1/0/6.0 {
                action-priority 5;
            }
        }
        enable-mac-move-action;
    }
    bd11 {
        vlan-id 11;
        enable-mac-move-action;
    }
    bd12 {
        vlan-id 12;
    }
}
```

If you are done configuring the device, enter **commit** from configuration mode.

## Verification

### Verifying That the Logical Interfaces Blocked Due to MAC Move Are Displayed

**Purpose** Ensure that the current set of logical interfaces blocked due to a MAC move, if any, are displayed.

**Action** From operational mode, enter the **show l2-learning mac-move-buffer active** command.

```
user@host# show l2-learning mac-move-buffer active
MAC Address: 00:00:00:00:01:01, VLAN Id: 0
  Time Rec : 2012-06-25 06:23:41   Bridge Domain: bd10
  Prev IFL : ge-1/0/5.0             New IFL: ge-1/0/6.0
  IFBD      : ge-1/0/6.0:10         Blocked   : YES
```

**Meaning** As a result of MAC move detection, one of the involved interface bridge domains will be blocked. The output shows that the ge-1/0/6 logical interface is blocked.

- Related Documentation**
- [bridge-domains on page 52](#)
  - [Layer 2 Learning and Forwarding Overview on page 7](#)



## CHAPTER 9

# Configuration Statements for Bridge Domains

- [\[edit bridge-domains\] Hierarchy Level on page 49](#)

### [\[edit bridge-domains\] Hierarchy Level](#)

---

```
bridge-domains {  
  bridge-domain-name {  
    bridge-options {  
      ... the bridge-options subhierarchy appears after the main [edit bridge-domains  
        bridge-domain-name] hierarchy ...  
    }  
    description text-description;  
    domain-type bridge;  
    forwarding-options {  
      dhcp-relay {  
        ... same statements as in [edit forwarding-options dhcp-relay] Hierarchy Level ...  
      }  
      filter {  
        input filter-name;  
      }  
      flood {  
        input filter-name;  
      }  
    }  
  }  
  interface interface-name;  
  multicast-snooping-options {  
    ... same statements as in [edit multicast-snooping-options] Hierarchy Level ...  
  }  
  no-irb-layer-2-copy;  
  no-local-switching;  
  protocols {  
    ... the protocols subhierarchy appears after the main [edit bridge-domains  
      bridge-domain-name] hierarchy ...  
  }  
  routing-interface irb-interface-name;  
  vlan-id (all | none | number);  
  service-id  
  enable-mac-move-action ;  
  vlan-id-list [ vlan-id-numbers ];  
  vlan-tags outer <tpid.>vlan-id <inner <tpid.>vlan-id>;
```

```

}

bridge-domain-name {
  bridge-options {
    interface interface-name {
      action-priority number;
      interface-mac-limit {
        limit;
        packet-action drop;
      }
      no-mac-learning;
      static-mac mac-address {
        vlan-id number;
      }
    }
  }
  interface-mac-limit {
    limit;
    packet-action drop;
  }
  mac-statistics;
  mac-table-size {
    number-of-addresses;
    packet-action drop;
  }
  no-mac-learning;
}

}

bridge-domain-name {
  protocols {
    igmp-snooping {
      immediate-leave;
      interface interface-name {
        group-limit number;
        host-only-interface;
        immediate-leave;
        multicast-router-interface;
        static {
          group multicast-ip-address {
            source multicast-ip-address;
          }
        }
      }
    }
    proxy {
      source-address ip-address;
    }
    query-interval seconds;
    query-last-member-interval seconds;
    query-response-interval seconds;
    robust-count number;
    traceoptions {
      file filename <files number> <size maximum-file-size> <world-readable |
        no-world-readable>;
      flag flag <flag-modifier> <disable>;
    }
    vlan vlan-id {

```



```

... same statements as at the [edit bridge-domains bridge-domain-name protocols
  igmp-snooping] hierarchy level that appears in this topic, EXCEPT FOR ...
  traceoptions {...} # NOT valid at this level
  vlan vlan-id {...} # NOT valid at this level
}
}
}
}
}

```

**Related Documentation**

- [Notational Conventions Used in Junos OS Configuration Hierarchies](#)

## action-priority

<b>Syntax</b>	<code>action-priority <i>number</i>;</code>
<b>Hierarchy Level</b>	[edit <a href="#">bridge-domains bridge-domain-name bridge-options</a> interface <i>interface-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.2.
<b>Description</b>	Configure the action priority value for an interface in a bridge domain on MAC move detection. This priority value is used to determine which interface should be blocked when a throttled MAC move is detected between two interfaces. The priority value can be between 0 and 7 inclusive. A higher value means lower priority. For example, if a MAC address move occurs between two interfaces with the action priority value set to 5 and 6, the interface with value 5 as the action priority value is blocked.
<b>Default</b>	4
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Configuring a Bridge Domain on page 11</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li> <li>• <a href="#">Example: Configuring E-LINE and E-LAN Services for a PBB Network on MX Series Routers</a></li> </ul>

## bridge-domains

**Syntax**

```
bridge-domains {
  bridge-domain-name {
    bridge-options {
      ...bridge-options-configuration...
    }
    domain-type bridge;
    interface interface-name;
    no-irb-layer-2-copy;
    routing-interface routing-interface-name;
    vlan-id (all | none | number);
    service-id number;
    enable-mac-move-action;
    vlan-id-list [ vlan-id-numbers ];
    vlan-tags outer number inner number;
    bridge-options {
      interface interface-name {
        static-mac mac-address;
        action-priority number;
      }
      interface-mac-limit limit;
      mac-statistics;
      mac-table-size limit;
      no-mac-learning;
    }
  }
}
```

**Hierarchy Level** [edit],  
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name*],  
[edit routing-instances *routing-instance-name*]

**Release Information** Statement introduced in Junos OS Release 8.4.  
Support for logical systems added in Junos OS Release 9.6.  
Support for the **no-irb-layer-2-copy** statement added in Junos OS Release 10.2.  
Support for **enable-mac-move-action** and **action-priority** added in Junos OS Release 13.2.  
Support for **service-id** statement added in Junos OS Release 13.2.

**Description** (MX Series routers only) Configure a domain that includes a set of logical ports that share the same flooding or broadcast characteristics in order to perform Layer 2 bridging.

**Options** *bridge-domain-name*—Name of the bridge domain.



**NOTE:** You cannot use the slash (/) character as part of the bridge domain name. If you do, the configuration will not commit.

The remaining statements are explained separately.

<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Configuring a Bridge Domain on page 11</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li> <li>• <i>Example: Configuring E-LINE and E-LAN Services for a PBB Network on MX Series Routers</i></li> </ul>

## bridge-options

<b>Syntax</b>	<pre>bridge-options {   interface <i>interface-name</i>;     <b>static-mac</b> <i>static-mac-address</i>;   }   <b>interface-mac-limit</b> <i>limit</i>;     <b>packet-action</b> drop;   }   <b>mac-statistics</b>;   <b>mac-table-size</b> <i>limit</i>;   <b>no-mac-learning</b>; }</pre>
<b>Hierarchy Level</b>	[edit <b>bridge-domains</b> <i>bridge-domain-name</i> ], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> ], [edit routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.4. Support for logical systems added in Junos OS Release 9.6.
<b>Description</b>	(MX Series routers only) Configure Layer 2 learning and forwarding properties for a bridge domain or a virtual switch.  The remaining statements are explained separately.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li> </ul>

## domain-type

---

<b>Syntax</b>	domain-type bridge;
<b>Hierarchy Level</b>	[edit <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ], [edit vlans <i>vlan-name</i> ] [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ], [edit routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.4. Support for logical systems added in Junos OS Release 9.6. Statement introduced in Junos OS Release 12.3R2 for EX Series switches.
<b>Description</b>	Define the type of domain for a Layer 2 bridge domain or VLAN.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Bridge Domain on page 11</a></li><li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li><li>• <a href="#">Configuring a Layer 2 Virtual Switch</a></li></ul>

## enable-mac-move-action

---

<b>Syntax</b>	enable-mac-move-action;
<b>Hierarchy Level</b>	[edit <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 13.2.
<b>Description</b>	Enable the MAC move action feature at the bridge domain level. This statement blocks the logical interface for the bridge domain when a MAC move is detected on the interface.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Bridge Domain on page 11</a></li></ul>

## interface

<b>Syntax</b>	<code>interface <i>interface-name</i>;</code>
<b>Hierarchy Level</b>	[edit <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ], [edit routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> ], [edit vlans <i>vlan-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.4. Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch. Support for logical systems added in Junos OS Release 9.6. Statement introduced in Junos OS Release 12.3R2 for EX Series switches.
<b>Description</b>	(MX Series routers and EX Series switches only) Specify the logical interfaces to include in the bridge domain, VLAN, VPLS instance, or virtual switch.
<b>Options</b>	<i>interface-name</i> —Name of a logical interface. For more information about how to configure logical interfaces, see the <i>Junos OS Network Interfaces Library for Routing Devices</i> .
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Configuring a Bridge Domain on page 11</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch</a></li> </ul>

## interface-mac-limit

<b>Syntax</b>	<pre>interface-mac-limit <i>limit</i> {     packet-action drop; }</pre>
<b>Hierarchy Level</b>	<pre>[edit bridge-domains <i>bridge-domain-name</i> bridge-options], [edit bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> switch-options interface <i>interface-name</i>], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit routing-instances <i>routing-instance-name</i> switch-options], [edit routing-instances <i>routing-instance-name</i> switch-options interface <i>interface-name</i>], [edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>]</pre>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], and [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
<b>Description</b>	<p>(MX Series routers or EX Series switches only) Configure a limit to the number of MAC addresses that can be learned from a bridge domain, VLAN, virtual switch, or set of bridge domains or VLANs.</p>
<b>Default</b>	1024 MAC addresses for each logical interface.

**Options**    *limit*—Maximum number of MAC addresses learned from an interface.

**Range:** 1 through 131,071 MAC addresses per interface

The remaining statement is explained separately.

**Required Privilege**    routing—To view this statement in the configuration.

**Level**    routing-control—To add this statement to the configuration.

**Related  
Documentation**

- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for VLANs Overview](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)
- [Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port](#)

## mac-statistics

<b>Syntax</b>	mac-statistics;
<b>Hierarchy Level</b>	<p>[edit <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">switch-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> <a href="#">switch-options</a>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <a href="#">switch-options</a>],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols evpn],</p> <p>[edit <a href="#">switch-options</a>],</p> <p>[edit switch-options],</p> <p>[edit vlans <i>vlan-name</i> switch-options]</p>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options] and [edit vlans <i>vlan-name</i> switch-options] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p> <p>Support for EVPNs added in Junos OS Release 13.2 for MX 3D Series routers.</p>
<b>Description</b>	(MX Series routers and EX Series switches only) For bridge domains or VLANs, enable MAC accounting either for a specific bridge domain or VLAN, or for a set of bridge domains or VLANs associated with a Layer 2 trunk port.
<b>Default</b>	disabled
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Overview</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</a></li> <li>• <a href="#">Configuring EVPN Routing Instances</a></li> </ul>



## mac-table-size

<b>Syntax</b>	<pre>mac-table-size <i>limit</i> {     packet-action drop; }</pre>
<b>Hierarchy Level</b>	<pre>[edit bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> switch-options], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit routing-instances <i>routing-instance-name</i> switch-options], [edit switch-options], [edit vlans <i>vlan-name</i> switch-options]</pre>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options] and [edit vlans <i>vlan-name</i> switch-options] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
<b>Description</b>	<p>Modify the size of the MAC address table for the bridge domain or VLAN, a set of bridge domains or VLANs associated with a trunk port, or a virtual switch. The default is 5120 MAC addresses.</p>
<b>Options</b>	<p><b>limit</b>—Specify the maximum number of addresses in the MAC address table.</p> <p><b>Range:</b> 16 through 1,048,575 MAC addresses</p> <p><b>Default:</b> 5120 MAC addresses</p> <p>The remaining statement is explained separately.</p>
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Overview</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</a></li> </ul>

## no-irb-layer-2-copy

---

<b>Syntax</b>	no-irb-layer-2-copy;
<b>Hierarchy Level</b>	[edit <a href="#">bridge-domains</a> ], [edit logical-routers <i>logical-router-name</i> <a href="#">bridge-domains</a> ], [edit routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.2.
<b>Description</b>	If you include this statement when using port mirroring with Integrated Routing and Bridging (IRB), then the packet is mirrored as a Layer 3 packet. By default, the packet is mirrored as a Layer 2 packet. This statement is also supported if a routing instance is set to type VPLS.
<b>Usage Guidelines</b>	See <a href="#">"Configuring a Bridge Domain" on page 11</a>
<b>Required Privilege Level</b>	view-level—To view this statement in the configuration. control-level—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li></ul>

## no-mac-learning

<b>Syntax</b>	no-mac-learning;
<b>Hierarchy Level</b>	<p>[edit <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b>],</p> <p>[edit <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b>],</p> <p>[edit logical-systems <i>logical-system-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <b>switch-options</b>],</p> <p>[edit logical-systems <i>logical-system-name</i> <b>switch-options</b>],</p> <p>[edit <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols evpn],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols evpn interface <i>interface-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <b>switch-options</b>],</p> <p>[edit <b>switch-options</b>],</p> <p>[edit switch-options],</p> <p>[edit switch-options interface <i>interface-name</i>],</p> <p>[edit vlans <i>vlan-name</i> switch-options],</p> <p>[edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>]</p>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], and [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>] hierarchy levels introduced in Junos OS Release 12.3 R2 for EX Series switches.</p> <p>Support for EVPNs added in Junos OS Release 13.2 for MX 3D Series routers.</p>
<b>Description</b>	(MX Series routers and EX Series switches only) Disable MAC learning for a virtual switch, for a bridge domain or VLAN, for a specific logical interface in a bridge domain or VLAN, for a set of bridge domains or VLANs associated with a Layer 2 trunk port, or for an EVPN.



**NOTE:** When MAC learning is disabled for a VPLS routing instance, traffic is not load balanced and only one of the equal-cost next hops is used.

<b>Default</b>	MAC learning is enabled. Use <b>no-mac-learning</b> to disable MAC learning.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring EVPN Routing Instances</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</i></li></ul>

## packet-action

**Syntax** packet-action drop;

**Hierarchy Level** [edit **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit protocols **l2-learning** **global-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* protocols evpn interface-mac-limit],  
 [edit routing-instances *routing-instance-name* protocols evpn interface *interface-name* interface-mac-limit],  
 [edit routing-instances *routing-instance-name* protocols evpn mac-table-size *limit*],  
 [edit routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options **interface-mac-limit** *limit*],  
 [edit switch-options **mac-table-size** *limit*],  
 [edit vlans *vlan-name* switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit vlans *vlan-name* switch-options **interface-mac-limit** *limit*],  
 [edit vlans *vlan-name* switch-options **mac-table-size** *limit*]


**Release Information** Statement introduced in Junos OS Release 8.4.  
 Support for the **switch-options** statement added in Junos OS Release 9.2.  
 Support for top-level configuration for the **virtual-switch** type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.  
 Support for logical systems added in Junos OS Release 9.6.  
 [edit switch-options interface *interface-name* interface-mac-limit *limit*], [edit switch-options interface-mac-limit *limit*], [edit switch-options mac-table-size *limit*], [edit vlans *vlan-name* switch-options interface *interface-name* interface-mac-limit *limit*],

[edit vlans *vlan-name* switch-options interface-mac-limit *limit*], and [edit vlans *vlan-name* switch-options mac-table-size *limit*] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.

Support for EVPNs introduced in Junos OS Release 13.2 on MX 3D Series routers.


<b>Description</b>	Specify that packets for new source MAC addresses be dropped after the MAC address limit is reached. If this statement is not configured, packets for new source MAC addresses are forwarded by default.
<b>Default</b>	Disabled. The default is for packets for new source MAC addresses to be forwarded after the MAC address limit is reached.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring EVPN Routing Instances</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</i></li></ul>

## routing-interface

<b>Syntax</b>	<code>routing-interface <i>routing-interface-name</i>;</code>
<b>Hierarchy Level</b>	<p>[edit <b>bridge-domains</b> <i>bridge-domain-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i>]</p>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p>
<b>Description</b>	<p>(MX Series routers only) Specify a routing interface to include in a bridge domain or a VPLS routing instance.</p> <p>When you configure <b>routing-interface irb.x</b>, the VPLS connection comes up, even if no customer edge (CE) interfaces are configured. This works with one site configured, but not when multiple sites (multisite) are configured.</p>
<b>Options</b>	<p><b><i>routing-interface-name</i></b>—Name of the routing interface to include in the bridge domain or the VPLS routing instance. The format of the routing interface name is <b>irb.x</b>, where <b>x</b> is the unit number of the routing interface you configured at the [edit <b>interfaces irb</b>] hierarchy level. For more information about how to configure a routing interface, see the <i>Junos OS Network Interfaces Library for Routing Devices</i>.</p>
<div>  <p><b>NOTE:</b> You can specify only one routing interface for each bridge domain or VPLS instance.</p> </div>	
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Configuring a Bridge Domain on page 11</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li> </ul>

## service-id

---

<b>Syntax</b>	<code>service-id <i>number</i>;</code>
<b>Hierarchy Level</b>	<code>[edit bridge-domains <i>bridge-domain-name</i>]</code>
<b>Release Information</b>	Statement introduced in Junos OS Release 13.2
<b>Description</b>	Specify a service identifier to include in the packets sent to and from the multichassis link aggregation (MC-LAG) bridge domain when the VLAN identifier is set to <b>none</b> . This configuration facilitates media access control (MAC) and Address Resolution Protocol (ARP) synchronization among MC-LAG peers.
<div> <b>NOTE:</b> The VLAN identifier none is supported only for IPv4 traffic.</div>	
<b>Options</b>	<b><i>number</i></b> —A valid service identifier. You must configure the same service identifier within the bridge domains of MC-LAG peers.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Bridge Domain on page 11</a></li><li>• <a href="#">Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12</a></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <a href="#">bridge-domains on page 52</a></li></ul>



## static-mac

<b>Syntax</b>	<pre>static-mac mac-address {     vlan-id number; }</pre>
<b>Hierarchy Level</b>	<p>[edit <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i> <b>bridge-options</b> interface <i>interface-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols evpn interface <i>interface-name</i>]</p> <p>[edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>]</p>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit vlans <i>vlan-name</i> switch-options interface <i>interface name</i>] hierarchy level introduced in Junos OS Release 12.3R2 for EX Series switches.</p> <p>Support for EVPNs added in Junos OS Release 13.2 for MX 3D Series routers. The <b>vlan-id</b> option is not available for EVPNs.</p>
<b>Description</b>	<p>Configure a static MAC address for a logical interface in a bridge domain or VLAN.</p> <p>The <b>vlan-id</b> option can be specified for <b>static-macs</b> only if <b>vlan-id all</b> is configured for the bridging domain or VLAN.</p>
<b>Options</b>	<p><b>mac-address</b>—MAC address</p> <p><b>vlan-id number</b>—(Optional) VLAN identifier to associate with static MAC address.</p>
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <i>Configuring EVPN Routing Instances</i></li> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li> <li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li> </ul>

## vlan-id (Bridge Domain or VLAN)

<b>Syntax</b>	<code>vlan-id (all   none   <i>number</i>);</code>
<b>Hierarchy Level</b>	<code>[edit bridge-domains <i>bridge-domain-name</i>],</code> <code>[edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i>],</code> <code>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i></code> <code>bridge-domains <i>bridge-domain-name</i>],</code> <code>[edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i>]</code> <code>[edit vlans <i>vlan-name</i>]</code>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for Layer 2 trunk ports added in Junos OS Release 9.2.</p> <p>Support for SRX 3400, SRX 3600, SRX 5600, and SRX 5800 devices added in Junos OS Release 9.6.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>Statement introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
<b>Description</b>	Specify a VLAN identifier (VID) to include in the packets sent to and from the bridge domain or VLAN, or a VPLS routing instance.



**NOTE:** When configuring a VLAN identifier for provider backbone bridge (PBB) routing instances, dual-tagged VIDs and the none option are not permitted.

**Options** *number*—A valid VLAN identifier. If you configure multiple bridge domains or VLANs with a valid VLAN identifier, you must specify a unique VLAN identifier for each. However, you can use the same VLAN identifier for bridge domains or VLANs that belong to different virtual switches. Use this option to send single tagged frames with the specified VLAN identifier over VPLS VT interfaces.



**NOTE:** If you specify a VLAN identifier, you cannot also use the all option. They are mutually exclusive.

**all**—Specify that the bridge domain or VLAN spans all the VLAN identifiers configured on the member logical interfaces.



**NOTE:** You cannot specify the all option if you include a routing interface in the bridge domain or VLAN.

**none**—Specify to enable shared VLAN learning or to send untagged frames over VPLS VT interfaces.




**NOTE:** Multichassis link aggregation (MC-LAG) does not support the `none` option with the `vlan-id` statement with bridge domains or VLANs.

<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Bridge Domain on page 11</a></li><li>• <a href="#">Configuring a VLAN</a></li><li>• <a href="#">Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12</a></li><li>• <a href="#">Configuring VLAN Identifiers for VLANs and VPLS Routing Instances</a></li><li>• <a href="#">Configuring Bridge Domains as Switches for Layer 2 Trunk Ports on page 19</a></li><li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25</a></li><li>• <a href="#">Configuring a Layer 2 Virtual Switch</a></li><li>• <a href="#">Example: Configuring E-LINE and E-LAN Services for a PBB Network on MX Series Routers</a></li><li>• <a href="#">Example: Configuring Interfaces and Routing Instances for a User Logical System</a></li><li>• <a href="#">bridge-domains on page 52</a></li><li>• <a href="#">vlans</a></li></ul>

## vlan-id-list

---

<b>Syntax</b>	<code>vlan-id-list [ <i>vlan-id-numbers</i> ];</code>
<b>Hierarchy Level</b>	<code>[edit <b>bridge-domains</b> <i>bridge-domain-name</i>],</code> <code>[edit logical-systems <i>logical-system-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i>],</code> <code>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i></code> <code>    <b>bridge-domains</b> <i>bridge-domain-name</i>],</code> <code>[edit routing-instances <i>routing-instance-name</i> <b>bridge-domains</b> <i>bridge-domain-name</i>]</code> <code>[edit interfaces <i>interface-name</i> unit 0],</code> <code>[edit vlans <i>vlan-name</i>]</code>
<b>Release Information</b>	Statement introduced in Junos OS Release 9.4. Support for logical systems added in Junos OS Release 9.6. Statement introduced in Junos OS Release 12.3R2 for EX Series switches.
<b>Description</b>	<p>Specify a VLAN identifier list to use for a bridge domain or VLAN in trunk mode.</p> <p>Specify the <b>trunk</b> option in the <b>interface-mode</b> statement to accept packets with a VLAN ID that matches the list of VLAN IDs specified in the <b>vlan-id-list</b> statement to forward the packet within the bridge domain or VLAN configured with the matching VLAN ID. Specify the <b>access</b> option to accept packets with no VLAN ID to forward the packet within the bridge domain or VLAN configured with the VLAN ID that matches the VLAN ID specified in the <b>vlan-id</b> statement.</p>
<b>Options</b>	<p><b><i>vlan-id-numbers</i></b>—Valid VLAN identifiers. You can combine individual numbers with range lists including a hyphen.</p> <p><b>Range:</b> 0 through 4095</p>
<div> <b>NOTE:</b> On EX Series switches, the range is 0 through 4094.</div>	
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring a Bridge Domain on page 11</a></li><li>• <a href="#">Configuring a VLAN</a></li><li>• <a href="#">Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12</a></li><li>• <a href="#">Configuring VLAN Identifiers for VLANs and VPLS Routing Instances</a></li></ul>

## vlan-tags

<b>Syntax</b>	<code>vlan-tags outer <i>number</i> inner <i>number</i>;</code>
<b>Hierarchy Level</b>	<p>[edit <a href="#">bridge-domains</a> <i>bridge-domain-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i>]</p> <p>[edit vlans <i>vlan-name</i>]</p>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>Statement introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
<b>Description</b>	Specify dual VLAN identifier tags for a bridge domain, VLAN, or VPLS routing instance.
<b>Options</b>	<p><b>outer <i>number</i></b>—A valid VLAN identifier.</p> <p><b>inner <i>number</i></b>—A valid VLAN identifier.</p>
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Configuring a Bridge Domain on page 11</a></li> <li>• <a href="#">Configuring a VLAN</a></li> <li>• <a href="#">Configuring VLAN Identifiers for Bridge Domains and VPLS Routing Instances on page 12</a></li> <li>• <a href="#">Configuring VLAN Identifiers for VLANs and VPLS Routing Instances</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch on page 25.</a></li> <li>• <a href="#">Configuring a Layer 2 Virtual Switch</a></li> </ul>



## CHAPTER 10

# Configuration Statements for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports

- [\[edit switch-options\] Hierarchy Level on page 73](#)

### [\[edit switch-options\] Hierarchy Level](#)

---

```
switch-options {  
  interface interface-name {  
    interface-mac-limit {  
      number-of-addresses;  
      packet-action drop;  
    }  
    no-mac-learning;  
  }  
  interface-mac-limit {  
    number-of-addresses;  
    packet-action drop;  
  }  
  mac-statistics;  
  mac-table-size {  
    number-of-addresses;  
    packet-action drop;  
  }  
  no-mac-learning;  
}
```

#### Related Documentation

- [Notational Conventions Used in Junos OS Configuration Hierarchies](#)

## switch-options

---

Syntax	<pre>switch-options {   interface <i>interface-name</i> {     interface-mac-limit <i>limit</i>;   }   interface-mac-limit <i>limit</i> {     packet-action drop;   }   mac-statistics;   mac-table-size <i>limit</i> {     packet-action drop;   }   no-mac-learning; }</pre>
Hierarchy Level	[edit], [edit logical-systems <i>logical-system-name</i> ], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> ], [edit routing-instances <i>routing-instance-name</i> ]
Release Information	Statement introduced in Junos OS Release 9.2. Support for logical systems added in Junos OS Release 9.6.
Description	Configure Layer 2 learning and forwarding properties for a set of bridge domains.
Options	The remaining statements are explained separately.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports</a> on page 5</li></ul>



## interface-mac-limit

<b>Syntax</b>	<pre>interface-mac-limit <i>limit</i> {     packet-action drop; }</pre>
<b>Hierarchy Level</b>	<pre>[edit bridge-domains <i>bridge-domain-name</i> bridge-options], [edit bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> switch-options interface <i>interface-name</i>], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit routing-instances <i>routing-instance-name</i> switch-options], [edit routing-instances <i>routing-instance-name</i> switch-options interface <i>interface-name</i>], [edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>]</pre>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], and [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
<b>Description</b>	<p>(MX Series routers or EX Series switches only) Configure a limit to the number of MAC addresses that can be learned from a bridge domain, VLAN, virtual switch, or set of bridge domains or VLANs.</p>
<b>Default</b>	1024 MAC addresses for each logical interface.

**Options**    *limit*—Maximum number of MAC addresses learned from an interface.

**Range:** 1 through 131,071 MAC addresses per interface

The remaining statement is explained separately.

**Required Privilege**    routing—To view this statement in the configuration.

**Level**    routing-control—To add this statement to the configuration.

**Related  
Documentation**

- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for VLANs Overview](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)
- [Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port](#)

## mac-statistics

<b>Syntax</b>	mac-statistics;
<b>Hierarchy Level</b>	<p>[edit <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <a href="#">switch-options</a>],</p> <p>[edit logical-systems <i>logical-system-name</i> <a href="#">switch-options</a>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <a href="#">bridge-domains</a> <i>bridge-domain-name</i> <a href="#">bridge-options</a>],</p> <p>[edit routing-instances <i>routing-instance-name</i> <a href="#">switch-options</a>],</p> <p>[edit routing-instances <i>routing-instance-name</i> protocols evpn],</p> <p>[edit <a href="#">switch-options</a>],</p> <p>[edit switch-options],</p> <p>[edit vlans <i>vlan-name</i> switch-options]</p>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options] and [edit vlans <i>vlan-name</i> switch-options] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p> <p>Support for EVPNs added in Junos OS Release 13.2 for MX 3D Series routers.</p>
<b>Description</b>	(MX Series routers and EX Series switches only) For bridge domains or VLANs, enable MAC accounting either for a specific bridge domain or VLAN, or for a set of bridge domains or VLANs associated with a Layer 2 trunk port.
<b>Default</b>	disabled
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Overview</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li> <li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</a></li> <li>• <a href="#">Configuring EVPN Routing Instances</a></li> </ul>

## mac-table-size

---

Syntax	<code>mac-table-size <i>limit</i> {     <code>packet-action</code> drop; }</code>
Hierarchy Level	<code>[edit <code>bridge-domains</code> <i>bridge-domain-name</i> <code>bridge-options</code>],</code> <code>[edit logical-systems <i>logical-system-name</i> <code>bridge-domains</code> <i>bridge-domain-name</i> <code>bridge-options</code>],</code> <code>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <code>bridge-domains</code> <i>bridge-domain-name</i> <code>bridge-options</code>],</code> <code>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> <code>switch-options</code>],</code> <code>[edit logical-systems <i>logical-system-name</i> <code>switch-options</code>],</code> <code>[edit routing-instances <i>routing-instance-name</i> <code>bridge-domains</code> <i>bridge-domain-name</i> <code>bridge-options</code>],</code> <code>[edit routing-instances <i>routing-instance-name</i> <code>switch-options</code>],</code> <code>[edit <code>switch-options</code>],</code> <code>[edit vlans <i>vlan-name</i> <code>switch-options</code>]</code>
Release Information	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <code>switch-options</code> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <code>virtual-switch</code> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p><code>[edit switch-options]</code> and <code>[edit vlans <i>vlan-name</i> <code>switch-options</code>]</code> hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
Description	Modify the size of the MAC address table for the bridge domain or VLAN, a set of bridge domains or VLANs associated with a trunk port, or a virtual switch. The default is 5120 MAC addresses.
Options	<p><b>limit</b>—Specify the maximum number of addresses in the MAC address table.</p> <p><b>Range:</b> 16 through 1,048,575 MAC addresses</p> <p><b>Default:</b> 5120 MAC addresses</p> <p>The remaining statement is explained separately.</p>
Required Privilege Level	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Overview</a></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li><li>• <a href="#">Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</a></li></ul>

## no-mac-learning

<b>Syntax</b>	no-mac-learning;
<b>Hierarchy Level</b>	<pre> [edit bridge-domains bridge-domain-name bridge-options], [edit bridge-domains bridge-domain-name bridge-options interface interface-name], [edit logical-systems logical-system-name bridge-domains bridge-domain-name   bridge-options], [edit logical-systems logical-system-name bridge-domains bridge-domain-name   bridge-options interface interface-name], [edit logical-systems logical-system-name routing-instances routing-instance-name   bridge-domains bridge-domain-name bridge-options], [edit logical-systems logical-system-name routing-instances routing-instance-name   bridge-domains bridge-domain-name bridge-options interface interface-name], [edit logical-systems logical-system-name routing-instances routing-instance-name   switch-options], [edit logical-systems logical-system-name switch-options], [edit bridge-domains bridge-domain-name bridge-options interface interface-name], [edit routing-instances routing-instance-name bridge-domains bridge-domain-name   bridge-options], [edit routing-instances routing-instance-name bridge-domains bridge-domain-name   bridge-options interface interface-name], [edit routing-instances routing-instance-name protocols evpn], [edit routing-instances routing-instance-name protocols evpn interface interface-name], [edit routing-instances routing-instance-name switch-options], [edit switch-options], [edit switch-options interface interface-name], [edit vlans vlan-name switch-options], [edit vlans vlan-name switch-options interface interface-name] </pre>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], and [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>] hierarchy levels introduced in Junos OS Release 12.3 R2 for EX Series switches.</p> <p>Support for EVPNs added in Junos OS Release 13.2 for MX 3D Series routers.</p>
<b>Description</b>	(MX Series routers and EX Series switches only) Disable MAC learning for a virtual switch, for a bridge domain or VLAN, for a specific logical interface in a bridge domain or VLAN, for a set of bridge domains or VLANs associated with a Layer 2 trunk port, or for an EVPN.



**NOTE:** When MAC learning is disabled for a VPLS routing instance, traffic is not load balanced and only one of the equal-cost next hops is used.

<b>Default</b>	MAC learning is enabled. Use <b>no-mac-learning</b> to disable MAC learning.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring EVPN Routing Instances</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</i></li></ul>

## packet-action

**Syntax** packet-action drop;

**Hierarchy Level** [edit **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit **bridge-domains** *bridge-domain-name* **bridge-options** interface-mac-limit *limit*],  
 [edit logical-systems *logical-system-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface-mac-limit *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface-mac-limit *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **switch-options** interface-mac-limit *limit*],  
 [edit logical-systems *logical-system-name* **switch-options** interface-mac-limit *limit*],  
 [edit protocols **l2-learning** global-mac-limit *limit*],  
 [edit routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface-mac-limit *limit*],  
 [edit routing-instances *routing-instance-name* protocols evpn interface-mac-limit],  
 [edit routing-instances *routing-instance-name* protocols evpn interface *interface-name* interface-mac-limit],  
 [edit routing-instances *routing-instance-name* protocols evpn mac-table-size *limit*],  
 [edit routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **switch-options** interface-mac-limit *limit*],  
 [edit **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options **interface-mac-limit** *limit*],  
 [edit switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options **interface-mac-limit** *limit*],  
 [edit switch-options **mac-table-size** *limit*],  
 [edit vlans *vlan-name* switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit vlans *vlan-name* switch-options **interface-mac-limit** *limit*],  
 [edit vlans *vlan-name* switch-options **mac-table-size** *limit*]

**Release Information** Statement introduced in Junos OS Release 8.4.  
 Support for the **switch-options** statement added in Junos OS Release 9.2.  
 Support for top-level configuration for the **virtual-switch** type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.  
 Support for logical systems added in Junos OS Release 9.6.  
 [edit switch-options interface *interface-name* interface-mac-limit *limit*], [edit switch-options interface-mac-limit *limit*], [edit switch-options mac-table-size *limit*], [edit vlans *vlan-name* switch-options interface *interface-name* interface-mac-limit *limit*],

[edit vlans *vlan-name* switch-options interface-mac-limit *limit*], and [edit vlans *vlan-name* switch-options mac-table-size *limit*] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.

Support for EVPNs introduced in Junos OS Release 13.2 on MX 3D Series routers.


<b>Description</b>	Specify that packets for new source MAC addresses be dropped after the MAC address limit is reached. If this statement is not configured, packets for new source MAC addresses are forwarded by default.
<b>Default</b>	Disabled. The default is for packets for new source MAC addresses to be forwarded after the MAC address limit is reached.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring EVPN Routing Instances</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</i></li></ul>



## CHAPTER 11

# Configuration Statements for Layer 3 Tunnel Services Interfaces with a DPC

## tunnel-services (Chassis)

<b>Syntax</b>	<pre>tunnel-services {     bandwidth (1g   10g   20g   40g);     tunnel-only; }</pre>
<b>Hierarchy Level</b>	[edit chassis fpc <i>slot-number</i> pic <i>number</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.2.
<b>Description</b>	<p>For MX Series 3D Universal Edge Routers, configure the amount of bandwidth for tunnel services.</p> <p>For M7i, M10i, M120, M320, T Series and TX Matrix routers with IQ2 PICs and IQ2E PICs, configure support for per unit scheduling for GRE tunnels. You can specify the IQ2 and IQ2E PICs to work exclusively in tunnel mode or as a regular PIC. The default setting uses IQ2 and IQ2E PICs as a regular PIC. If you do not configure the <b>tunnel-only</b> option, the IQ2 and IQ2E PICs operate as regular PICs. For M7i, M10i, M120, M320, T Series and TX Matrix routers with IQ2 PICs and IQ2E PICs, you can use the <b>tunnel-only</b> option to specify that an IQ2 or IQ2E PIC work in tunnel mode only.</p>
	<div>  <p><b>NOTE:</b> Bandwidth rates of 20 gigabits per second and 40 gigabits per second require use of an MX Series router with the 100-Gigabit Ethernet Modular Port Concentrator (MPC) and the 100-Gigabit CFP MIC.</p> </div>
<b>Options</b>	<p><b>tunnel-only</b> (Optional)—For M7i, M10i, M120, M320, T Series and TX Matrix routers with IQ2 PICs and IQ2E PICs, specify that an IQ2 or IQ2E PIC work in tunnel mode only.</p> <p>The remaining statements are explained separately.</p>
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <i>Example: Configuring Tunnel Interfaces on a Gigabit Ethernet 40-Port DPC</i></li> <li>• <i>Example: Configuring Tunnel Interfaces on a 10-Gigabit Ethernet 4-Port DPC</i></li> <li>• <i>Example: Configuring Tunnel Interfaces on the MPC3E</i></li> <li>• <a href="#">bandwidth (Tunnel Services) on page 85</a></li> <li>• <i>[edit chassis] Hierarchy Level</i></li> <li>• <a href="#">Configuring Layer 3 Tunnel Services Interfaces on an MX Series Router with a DPC on page 39</a></li> </ul>

## bandwidth (Tunnel Services)

<b>Syntax</b>	<code>bandwidth <i>bandwidth-value</i>;</code>
<b>Hierarchy Level</b>	<code>[edit chassis fpc <i>slot-number</i> pic <i>number</i> <a href="#">tunnel-services</a>]</code>
<b>Release Information</b>	Statement introduced in Junos OS Release 8.2.
<b>Description</b>	(MX Series 3D Universal Edge Routers and T4000 Core Routers only) Specify the amount of bandwidth in gigabits per second to reserve for tunnel services.
<b>Options</b>	<i>bandwidth-value</i> —Define the amount of bandwidth in gigabits per second to reserve for tunnel services. On MX Series routers, the bandwidth values can be <b>1g</b> , <b>10g</b> , <b>20g</b> , or <b>40g</b> . On T4000 routers, the bandwidth values are multiples of <b>10g</b> up to <b>100g</b> .



**NOTE:** If you specify a bandwidth that is not compatible with the type of DPCs or MPCs and their respective Packet Forwarding Engine, tunnel services are not activated. For example, you cannot specify 1 gigabit per second bandwidth for a Packet Forwarding Engine on a 10-Gigabit Ethernet 4-port DPC or 16x10GE 3D MPC.



**NOTE:** Bandwidth rates of 20 gigabits per second and 40 gigabits per second require use of an MX Series router with the MPC3E and the 100-Gigabit CFP MIC.

<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Example: Configuring Tunnel Interfaces on a Gigabit Ethernet 40-Port DPC</a></li> <li>• <a href="#">Configuring Tunnel Interfaces on MX Series Routers</a></li> <li>• <a href="#">Configuring Tunnel Interfaces on T4000 Routers</a></li> <li>• <a href="#">Example: Configuring Tunnel Interfaces on a 10-Gigabit Ethernet 4-Port DPC</a></li> <li>• <a href="#">Example: Configuring Tunnel Interfaces on the MPC3E</a></li> <li>• <a href="#">Configuring Layer 3 Tunnel Services Interfaces on an MX Series Router with a DPC on page 39</a></li> <li>• <a href="#">tunnel-services (Chassis) on page 84</a></li> <li>• <a href="#">[edit chassis] Hierarchy Level</a></li> </ul>



## CHAPTER 12

# Configuration Statements for Layer 2 Address Learning and Forwarding

- [\[edit protocols l2-learning\]](#) Hierarchy Level on page 87

### [\[edit protocols l2-learning\]](#) Hierarchy Level

---

```
protocols {
  l2-learning {
    global-mac-limit {
      limit;
      packet-action drop;
    }
    global-mac-statistics;
    global-mac-table-aging-time seconds;
    global-no-mac-learning;
  }
}
```

#### Related Documentation

- *Notational Conventions Used in Junos OS Configuration Hierarchies*
- [\[edit protocols\]](#) Hierarchy Level

## l2-learning

---

<b>Syntax</b>	<pre>l2-learning {     global-mac-limit <i>limit</i>;     global-mac-statistics;     global-mac-table-aging-time <i>seconds</i>;     global-no-mac-learning; }</pre>
<b>Hierarchy Level</b>	[edit protocols]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.4.
<b>Description</b>	<p>(MX Series routers and EX Series switches only) Configure Layer 2 address learning and forwarding properties globally.</p> <p>The statements are explained separately.</p>
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Layer 2 Learning and Forwarding Overview on page 7</a></li></ul>

## global-mac-limit

---

<b>Syntax</b>	<code>global-mac-limit <i>limit</i> {     <code>packet-action</code> drop; }</code>
<b>Hierarchy Level</b>	[edit protocols <a href="#">l2-learning</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 8.4. Support for logical systems added in Junos OS Release 9.6.
<b>Description</b>	(MX Series routers and EX Series switches only) Limit the number of media access control (MAC) addresses learned from the logical interfaces on the router.
<b>Default</b>	393,215 MAC addresses
<b>Options</b>	<i>limit</i> —Number of MAC addresses that can be learned systemwide. <b>Range:</b> 20 through 1,048,575  The remaining statement is explained separately in the “Summary of Bridge Domain Configuration Statements” chapter.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Limiting the Number of MAC Addresses Learned from Each Logical Interface on page 42</a></li> </ul>

## global-mac-statistics

---

<b>Syntax</b>	<code>global-mac-statistics;</code>
<b>Hierarchy Level</b>	[edit protocols <a href="#">l2-learning</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 9.2. Support for logical systems added in Junos OS Release 9.6.
<b>Description</b>	(MX Series routers and EX Series switches only) Enable MAC accounting for the entire router or switch.
<b>Default</b>	disabled
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Enabling MAC Accounting on page 42</a></li> </ul>

## global-mac-table-aging-time

---

<b>Syntax</b>	global-mac-table-aging-time <i>seconds</i> ;
<b>Hierarchy Level</b>	[edit protocols <a href="#">l2-learning</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 9.2. Support for logical systems added in Junos OS Release 9.6.
<b>Description</b>	(MX Series routers and EX Series switches only) Configure the timeout interval for entries in the MAC table.
<b>Default</b>	300 seconds
<b>Options</b>	<b><i>seconds</i></b> —Time elapsed before MAC table entries are timed out and entries are deleted from the table. <b>Range:</b> 10 through 1 million
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Configuring the MAC Table Timeout Interval on page 41</a></li></ul>

## global-no-mac-learning

---

<b>Syntax</b>	global-no-mac-learning;
<b>Hierarchy Level</b>	[edit protocols <a href="#">l2-learning</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 9.2. Support for logical systems added in Junos OS Release 9.6.
<b>Description</b>	(MX Series routers and EX Series switches only) Disable MAC learning for the entire router or switch.
<b>Default</b>	MAC learning is enabled.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Disabling Layer 2 Learning and Forwarding on page 43</a></li></ul>



## interface-mac-limit

<b>Syntax</b>	<pre>interface-mac-limit <i>limit</i> {     packet-action drop; }</pre>
<b>Hierarchy Level</b>	<pre>[edit bridge-domains <i>bridge-domain-name</i> bridge-options], [edit bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> switch-options interface <i>interface-name</i>], [edit logical-systems <i>logical-system-name</i> switch-options], [edit logical-systems <i>logical-system-name</i> switch-options interface <i>interface-name</i>], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options], [edit routing-instances <i>routing-instance-name</i> bridge-domains <i>bridge-domain-name</i> bridge-options interface <i>interface-name</i>], [edit routing-instances <i>routing-instance-name</i> switch-options], [edit routing-instances <i>routing-instance-name</i> switch-options interface <i>interface-name</i>], [edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>]</pre>
<b>Release Information</b>	<p>Statement introduced in Junos OS Release 8.4.</p> <p>Support for the <b>switch-options</b> statement added in Junos OS Release 9.2.</p> <p>Support for top-level configuration for the <b>virtual-switch</b> type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.</p> <p>Support for logical systems added in Junos OS Release 9.6.</p> <p>[edit switch-options], [edit switch-options interface <i>interface-name</i>], [edit vlans <i>vlan-name</i> switch-options], and [edit vlans <i>vlan-name</i> switch-options interface <i>interface-name</i>] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.</p>
<b>Description</b>	<p>(MX Series routers or EX Series switches only) Configure a limit to the number of MAC addresses that can be learned from a bridge domain, VLAN, virtual switch, or set of bridge domains or VLANs.</p>
<b>Default</b>	1024 MAC addresses for each logical interface.

**Options**    *limit*—Maximum number of MAC addresses learned from an interface.

**Range:** 1 through 131,071 MAC addresses per interface

The remaining statement is explained separately.

**Required Privilege**    routing—To view this statement in the configuration.

**Level**    routing-control—To add this statement to the configuration.

**Related  
Documentation**

- [Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5](#)
- [Layer 2 Learning and Forwarding for VLANs Overview](#)
- [Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5](#)
- [Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port](#)

## packet-action

**Syntax** packet-action drop;

**Hierarchy Level** [edit **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit **bridge-domains** *bridge-domain-name* **bridge-options** interface **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* **switch-options** interface **interface-mac-limit** *limit*],  
 [edit logical-systems *logical-system-name* **switch-options** interface **interface-mac-limit** *limit*],  
 [edit protocols **l2-learning** **global-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **bridge-domains** *bridge-domain-name* **bridge-options** interface **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* protocols evpn interface-mac-limit],  
 [edit routing-instances *routing-instance-name* protocols evpn interface *interface-name* interface-mac-limit],  
 [edit routing-instances *routing-instance-name* protocols evpn mac-table-size *limit*],  
 [edit routing-instances *routing-instance-name* **switch-options** interface *interface-name* **interface-mac-limit** *limit*],  
 [edit routing-instances *routing-instance-name* **switch-options** interface **interface-mac-limit** *limit*],  
 [edit switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options **interface-mac-limit** *limit*],  
 [edit switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit switch-options **interface-mac-limit** *limit*],  
 [edit switch-options **mac-table-size** *limit*],  
 [edit vlans *vlan-name* switch-options interface *interface-name* **interface-mac-limit** *limit*],  
 [edit vlans *vlan-name* switch-options **interface-mac-limit** *limit*],  
 [edit vlans *vlan-name* switch-options **mac-table-size** *limit*]

**Release Information** Statement introduced in Junos OS Release 8.4.  
 Support for the **switch-options** statement added in Junos OS Release 9.2.  
 Support for top-level configuration for the **virtual-switch** type of routing instance added in Junos OS Release 9.2. In Junos OS Release 9.1 and earlier, the routing instances hierarchy supported this statement only for a VPLS instance or a bridge domain configured within a virtual switch.  
 Support for logical systems added in Junos OS Release 9.6.  
 [edit switch-options interface *interface-name* interface-mac-limit *limit*], [edit switch-options interface-mac-limit *limit*], [edit switch-options mac-table-size *limit*], [edit vlans *vlan-name* switch-options interface *interface-name* interface-mac-limit *limit*],

[edit vlans *vlan-name* switch-options interface-mac-limit *limit*], and [edit vlans *vlan-name* switch-options mac-table-size *limit*] hierarchy levels introduced in Junos OS Release 12.3R2 for EX Series switches.

Support for EVPNs introduced in Junos OS Release 13.2 on MX 3D Series routers.

<b>Description</b>	Specify that packets for new source MAC addresses be dropped after the MAC address limit is reached. If this statement is not configured, packets for new source MAC addresses are forwarded by default.
<b>Default</b>	Disabled. The default is for packets for new source MAC addresses to be forwarded after the MAC address limit is reached.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <i>Configuring EVPN Routing Instances</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Overview on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <a href="#">Layer 2 Learning and Forwarding for Bridge Domains Functioning as Switches with Layer 2 Trunk Ports on page 5</a></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Overview</i></li><li>• <i>Layer 2 Learning and Forwarding for VLANs Acting as a Switch for a Layer 2 Trunk Port</i></li></ul>

## PART 3

# Administration

- [Operational Mode Commands for Bridge Domains on page 97](#)
- [Operational Mode Commands for Layer 2 Learning on page 153](#)



## CHAPTER 13

# Operational Mode Commands for Bridge Domains

## clear bridge mac-table

---

<b>Syntax</b>	<code>clear bridge mac-table &lt;bridge-domain (all   <i>bridge-domain-name</i>)&gt; &lt;instance <i>instance-name</i>&gt; &lt;interface <i>interface-name</i>&gt; &lt;learning-vlan id (all-vlan   <i>learning-vlan-id</i>)&gt; &lt;<i>mac-address</i>&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Clear learned Layer 2 address information from the media access control (MAC) address table.
<b>Options</b>	<p><b>none</b>—Clear all learned Layer 2 address information from the MAC address table.</p> <p><b>bridge-domain (all   <i>bridge-domain-name</i>)</b>—(Optional) Clear learned Layer 2 MAC addresses for all bridging domains or for the specified bridging domain.</p> <p><b>instance <i>instance-name</i></b>—(Optional) Clear learned Layer 2 MAC addresses for the specified routing instance.</p> <p><b>interface <i>interface-name</i></b>—(Optional) Clear learned Layer 2 MAC addresses for the specified interface.</p> <p><b>learning-vlan-id (all-vlan   <i>learning-vlan-id</i>)</b>—(Optional) Clears learned Layer 2 MAC addresses for all VLANs or for the specified VLAN.</p> <p><b><i>mac-address</i></b>—(Optional) Clear the specified learned Layer 2 address from the MAC address table.</p>
<b>Required Privilege Level</b>	clear
<b>List of Sample Output</b>	<a href="#">clear bridge mac-table on page 98</a>
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

#### clear bridge mac-table

```
user@host> clear bridge mac-table
```



## show bridge domain

<b>Syntax</b>	<pre>show bridge domain &lt;brief   detail   extensive&gt; &lt;bridge-domain (all   domain-name)&gt; &lt;instance instance-name&gt; &lt;operational&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Display bridge domain information.
<b>Options</b>	<p><b>none</b>—Display information for all bridge domains.</p> <p><b>brief   detail   extensive</b>—(Optional) Display the specified level of output.</p> <p><b>bridge-domain (all   domain-name)</b>— (Optional) Display information about all bridge domains or the specified bridge domain.</p> <p><b>instance instance-name</b>—(Optional) Display information for the specified routing instance.</p> <p><b>operational</b>—(Optional) Display information for the operational routing instances.</p>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show bridge domain on page 99</a> <a href="#">show bridge domain brief on page 99</a> <a href="#">show bridge domain detail on page 99</a>

## Sample Output

### show bridge domain

```
user@host> show bridge domain
Instance      Primary Table  Bridging Domain  Type      Active
vs1           bridge.0       vlan100          bridge    2
vs1           bridge.0       vlan200          bridge    0
```

### show bridge domain brief

```
user@host> show bridge domain brief
Instance      Primary Table  Bridging Domain  Type      Active
vs1           bridge.0       vlan100          bridge    2
vs1           bridge.0       vlan200          bridge    0
```

### show bridge domain detail

```
user@host> show bridge domain detail
```

```

Routing Instance:vs1
  Bridging Domain:vlan100
  Router ID: 0.0.0.0
  Type: bridge                      State: Active
  Interfaces:
    ge-11/0/3.0
    ge-11/1/4.100
    ge-11/1/1.100
    ge-11/1/0.100
    xe-10/2/0.100
    xe-10/0/0.100
  Tables:
    bridge.0                        : 2 macs (2 active)
Routing Instance:vs1
  Bridging Domain:vlan200
  Router ID: 0.0.0.0
  Type: bridge                      State: Active
  Interfaces:
    ge-11/1/0.200
    ge-11/1/1.200
    ge-11/1/4.200
    xe-10/0/0.200
    xe-10/2/0.200
  Tables:
    bridge.0                        : 0 macs (0 active)

```

## show bridge flood

<b>Syntax</b>	<pre>show bridge flood &lt;brief   detail   extensive&gt; &lt;bridge-domain <i>domain-name</i>&gt; &lt;event-queue&gt; &lt;instance <i>instance-name</i>&gt; &lt;route (all-ce-flood   all-ve-flood   alt-root-flood   bd-flood   mlp-flood   re-flood)&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Display bridging flooding information.
<b>Options</b>	<p><b>none</b>—Display all bridging flooding information for all bridging domains.</p> <p><b>brief   detail   extensive</b>—(Optional) Display the specified level of output.</p> <p><b>bridge-domain <i>domain-name</i></b>—(Optional) Display bridging flooding information for the specified bridge domain.</p> <p><b>event-queue</b>—(Optional) Display the queue of pending bridge flood events.</p> <p><b>instance <i>instance-name</i></b>—(Optional) Display bridging flooding information for the specified routing instance.</p> <p><b>route (all-ce-flood   all-ve-flood   alt-root-flood   bd-flood   mlp-flood   re-flood)</b>—(Optional) Display the following:</p> <ul style="list-style-type: none"> <li><b>all-ce-flood</b>—Display the route for flooding traffic to all customer edge routers if <b>no-local-switching</b> is enabled.</li> <li><b>all-ve-flood</b>—Display the route for flooding traffic to all VPLS edge routers if <b>no-local-switching</b> is enabled.</li> <li><b>alt-root-flood</b>—Display the Spanning Tree Protocol (STP) alt-root flooding route used for the interface.</li> <li><b>bd-flood</b>—Display the route for flooding traffic of a bridge domain if <b>no-local-switching</b> is not enabled.</li> <li><b>mlp-flood</b>—Display the route for flooding traffic to MAC learning chips.</li> <li><b>re-flood</b>—Display the route for Routing Engine flooding to all interfaces.</li> </ul>
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show bridge flood on page 102</a> <a href="#">show bridge flood brief on page 102</a> <a href="#">show bridge flood detail on page 102</a> <a href="#">show bridge flood extensive on page 103</a>
<b>Output Fields</b>	to be provided

## Sample Output

### show bridge flood

```

user@host> show bridge flood
Name: __juniper_private1__
CEs: 0
VEs: 0
Flood Routes:
  Prefix    Type        Owner                NhType    NhIndex
  0x36/16   MLP_FLOOD   __vs1+vlan100__     flood     426
  0x3a/16   MLP_FLOOD   __vs1+vlan200__     flood     428
Name: vs1::vlan100
CEs: 6
VEs: 0
Flood Routes:
  Prefix    Type        Owner                NhType    NhIndex
  0x35/16   ALL_FLOOD   __vs1+vlan100__     flood     425
  0x35/16   RE_FLOOD    __vs1+vlan100__     flood     425
  0x3780/17 ALT_ROOT_RT ge-11/0/3.0         flood     425
  0x3b80/17 ALT_ROOT_RT ge-11/1/4.100       flood     425
  0x3c80/17 ALT_ROOT_RT ge-11/1/1.100       flood     425
  0x3d80/17 ALT_ROOT_RT ge-11/1/0.100       flood     425
  0x3e80/17 ALT_ROOT_RT xe-10/2/0.100       flood     425
  0x3f80/17 ALT_ROOT_RT xe-10/0/0.100       flood     425
Name: vs1::vlan200
CEs: 5
VEs: 0
Flood Routes:
  Prefix    Type        Owner                NhType    NhIndex
  0x39/16   ALL_FLOOD   __vs1+vlan200__     flood     427
  0x39/16   RE_FLOOD    __vs1+vlan200__     flood     427
  0x4180/17 ALT_ROOT_RT ge-11/1/0.200       flood     427
  0x4080/17 ALT_ROOT_RT ge-11/1/1.200       flood     427
  0x4280/17 ALT_ROOT_RT ge-11/1/4.200       flood     427
  0x4480/17 ALT_ROOT_RT xe-10/0/0.200       flood     427
  0x4380/17 ALT_ROOT_RT xe-10/2/0.200       flood     427

```

### show bridge flood brief

```

user@host> show bridge flood brief
Name                Active CEs    Active VEs
__juniper_private1__ 0              0
vs1::vlan100         6              0
vs1::vlan200         5              0

```

### show bridge flood detail

```

user@host> show bridge flood detail
Name: __juniper_private1__
CEs: 0
VEs: 0
Flood Routes:
  Prefix    Type        Owner                NhType    NhIndex
  0x36/16   MLP_FLOOD   __vs1+vlan100__     flood     426
  0x3a/16   MLP_FLOOD   __vs1+vlan200__     flood     428
Name: vs1::vlan100
CEs: 6
VEs: 0
Flood Routes:
  Prefix    Type        Owner                NhType    NhIndex

```

```

0x35/16  ALL_FLOOD    __vs1+vlan100__  flood    425
0x35/16  RE_FLOOD     __vs1+vlan100__  flood    425
0x3780/17 ALT_ROOT_RT ge-11/0/3.0      flood    425
0x3b80/17 ALT_ROOT_RT ge-11/1/4.100    flood    425
0x3c80/17 ALT_ROOT_RT ge-11/1/1.100    flood    425
0x3d80/17 ALT_ROOT_RT ge-11/1/0.100    flood    425
0x3e80/17 ALT_ROOT_RT xe-10/2/0.100     flood    425
0x3f80/17 ALT_ROOT_RT xe-10/0/0.100     flood    425
Name: vs1::vlan200
CEs: 5
VEs: 0
Flood Routes:
  Prefix  Type      Owner          NhType  NhIndex
  0x39/16  ALL_FLOOD __vs1+vlan200__ flood    427
  0x39/16  RE_FLOOD  __vs1+vlan200__ flood    427
  0x4180/17 ALT_ROOT_RT ge-11/1/0.200    flood    427
  0x4080/17 ALT_ROOT_RT ge-11/1/1.200    flood    427
  0x4280/17 ALT_ROOT_RT ge-11/1/4.200    flood    427
  0x4480/17 ALT_ROOT_RT xe-10/0/0.200     flood    427
  0x4380/17 ALT_ROOT_RT xe-10/2/0.200     flood    427

```

### show bridge flood extensive

```

user@host> show bridge flood extensive
Name: __juniper_private1__
CEs: 0
VEs: 0
Flood route prefix: 0x36/16
Flood route type: MLP_FLOOD
Flood route owner: __vs1+vlan100__
Nexthop type: flood
Nexthop index: 426
  Interfaces Flooding to:
    Name          Type      NhType      Index
    1c-11/0/0.32769 LC
    1c-10/2/0.32769 LC
    1c-10/0/0.32769 LC
    1c-11/1/0.32769 LC

Flood route prefix: 0x3a/16
Flood route type: MLP_FLOOD
Flood route owner: __vs1+vlan200__
Nexthop type: flood
Nexthop index: 428
  Interfaces Flooding to:
    Name          Type      NhType      Index
    1c-10/0/0.32769 LC
    1c-10/2/0.32769 LC
    1c-11/1/0.32769 LC
Name: vs1::vlan100
CEs: 6
VEs: 0

Flood route prefix: 0x35/16
Flood route type: ALL_FLOOD
Flood route owner: __vs1+vlan100__
Nexthop type: flood
Nexthop index: 425
  Interfaces Flooding to:
    Name          Type      NhType      Index
    ge-11/0/3.0    CE

```

```

ge-11/1/4.100    CE
ge-11/1/1.100    CE
ge-11/1/0.100    CE
xe-10/2/0.100    CE
xe-10/0/0.100    CE

```

```

Flood route prefix: 0x35/16
Flood route type: RE_FLOOD
Flood route owner: __vs1+vlan100__
Nexthop type: flood
Nexthop index: 425

```

```

Interfaces Flooding to:
Name          Type          NhType          Index
ge-11/0/3.0   CE
ge-11/1/4.100 CE
ge-11/1/1.100 CE
ge-11/1/0.100 CE
xe-10/2/0.100 CE
xe-10/0/0.100 CE

```

```

Flood route prefix: 0x3780/17
Flood route type: ALT_ROOT_RT
Flood route owner: ge-11/0/3.0
Nexthop type: flood
Nexthop index: 425

```

```

Interfaces Flooding to:
Name          Type          NhType          Index
ge-11/0/3.0   CE
ge-11/1/4.100 CE
ge-11/1/1.100 CE
ge-11/1/0.100 CE
xe-10/2/0.100 CE
xe-10/0/0.100 CE

```

```

Flood route prefix: 0x3b80/17
Flood route type: ALT_ROOT_RT
Flood route owner: ge-11/1/4.100
Nexthop type: flood
Nexthop index: 425

```

```

Interfaces Flooding to:
Name          Type          NhType          Index
ge-11/0/3.0   CE
ge-11/1/4.100 CE
ge-11/1/1.100 CE
ge-11/1/0.100 CE
xe-10/2/0.100 CE
xe-10/0/0.100 CE

```

```

Flood route prefix: 0x3c80/17
Flood route type: ALT_ROOT_RT
Flood route owner: ge-11/1/1.100
Nexthop type: flood
Nexthop index: 425

```

```

Interfaces Flooding to:
Name          Type          NhType          Index
ge-11/0/3.0   CE
ge-11/1/4.100 CE
ge-11/1/1.100 CE
ge-11/1/0.100 CE
xe-10/2/0.100 CE
xe-10/0/0.100 CE

```

Flood route prefix: 0x3d80/17  
 Flood route type: ALT\_ROOT\_RT  
 Flood route owner: ge-11/1/0.100  
 Nexthop type: flood  
 Nexthop index: 425

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/0/3.0	CE		
ge-11/1/4.100	CE		
ge-11/1/1.100	CE		
ge-11/1/0.100	CE		
xe-10/2/0.100	CE		
xe-10/0/0.100	CE		

Flood route prefix: 0x3e80/17  
 Flood route type: ALT\_ROOT\_RT  
 Flood route owner: xe-10/2/0.100  
 Nexthop type: flood  
 Nexthop index: 425

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/0/3.0	CE		
ge-11/1/4.100	CE		
ge-11/1/1.100	CE		
ge-11/1/0.100	CE		
xe-10/2/0.100	CE		
xe-10/0/0.100	CE		

Flood route prefix: 0x3f80/17  
 Flood route type: ALT\_ROOT\_RT  
 Flood route owner: xe-10/0/0.100  
 Nexthop type: flood  
 Nexthop index: 425

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/0/3.0	CE		
ge-11/1/4.100	CE		
ge-11/1/1.100	CE		
ge-11/1/0.100	CE		
xe-10/2/0.100	CE		
xe-10/0/0.100	CE		

Name: vs1::vlan200

CEs: 5

VEs: 0

Flood route prefix: 0x39/16  
 Flood route type: ALL\_FLOOD  
 Flood route owner: \_\_vs1+vlan200\_\_  
 Nexthop type: flood  
 Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		
xe-10/2/0.200	CE		

Flood route prefix: 0x39/16  
 Flood route type: RE\_FLOOD

Flood route owner: \_\_vs1+vlan200\_\_

Nexthop type: flood

Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		
xe-10/2/0.200	CE		

Flood route prefix: 0x4180/17

Flood route type: ALT\_ROOT\_RT

Flood route owner: ge-11/1/0.200

Nexthop type: flood

Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		
xe-10/2/0.200	CE		

Flood route prefix: 0x4080/17

Flood route type: ALT\_ROOT\_RT

Flood route owner: ge-11/1/1.200

Nexthop type: flood

Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		
xe-10/2/0.200	CE		

Flood route prefix: 0x4280/17

Flood route type: ALT\_ROOT\_RT

Flood route owner: ge-11/1/4.200

Nexthop type: flood

Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		
xe-10/2/0.200	CE		

Flood route prefix: 0x4480/17

Flood route type: ALT\_ROOT\_RT

Flood route owner: xe-10/0/0.200

Nexthop type: flood

Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		



xe-10/2/0.200 CE

Flood route prefix: 0x4380/17

Flood route type: ALT\_ROOT\_RT

Flood route owner: xe-10/2/0.200

Nexthop type: flood

Nexthop index: 427

Interfaces Flooding to:

Name	Type	NhType	Index
ge-11/1/0.200	CE		
ge-11/1/1.200	CE		
ge-11/1/4.200	CE		
xe-10/0/0.200	CE		
xe-10/2/0.200	CE		

## show bridge mac-table

---

<b>Syntax</b>	<code>show bridge mac-table</code> <code>&lt;brief   count   detail   extensive&gt;</code> <code>&lt;bridge-domain (all   <i>bridge-domain-name</i>)&gt;</code> <code>&lt;global-count&gt;</code> <code>&lt;interface <i>interface-name</i>&gt;</code> <code>&lt;mac-address&gt;</code> <code>&lt;vlan-id (all-vlan   <i>vlan-id</i>)&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Display Layer 2 MAC address information.
<b>Options</b>	<p><b>none</b>—Display all learned Layer 2 MAC address information.</p> <p><b>brief   count   detail   extensive</b>—(Optional) Display the specified level of output.</p> <p><b>bridge-domain (all   <i>bridge-domain-name</i>)</b>—(Optional) Display learned Layer 2 MAC addresses for all bridging domains or for the specified bridging domain.</p> <p><b>global-count</b>—(Optional) Display the total number of learned Layer 2 MAC addresses on the system.</p> <p><b>instance <i>instance-name</i></b>—(Optional) Display learned Layer 2 MAC addresses for the specified routing instance.</p> <p><b>interface <i>interface-name</i></b>—(Optional) Display learned Layer 2 MAC addresses for the specified interface.</p> <p><b>mac-address</b>—(Optional) Display the specified learned Layer 2 MAC address information.</p> <p><b>vlan-id (all-vlan   <i>vlan-id</i>)</b>—(Optional) Display learned Layer 2 MAC addresses for all VLANs or for the specified VLAN.</p>
<b>Additional Information</b>	When Layer 2 protocol tunneling is enabled, the tunneling MAC address 01:00:0c:cd:cd:d0 is installed in the MAC table. When the Cisco Discovery Protocol (CDP), Spanning Tree Protocol (STP), or VLAN Trunk Protocol (VTP) is configured for Layer 2 protocol tunneling on an interface, the corresponding protocol MAC address is installed in the MAC table.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show bridge mac-table on page 109</a> <a href="#">show bridge mac-table brief on page 110</a> <a href="#">show brief mac-table count on page 110</a> <a href="#">show bridge mac-table detail on page 110</a>
<b>Output Fields</b>	<a href="#">Table 5 on page 109</a> describes the output fields for the <b>show bridge mac-table</b> command. Output fields are listed in the approximate order in which they appear.

Table 5: show bridge mac-table Output fields

Field Name	Field Description
Routing instance	Name of the routing instance.
Bridging domain	Name of the bridging domain.
MAC address	MAC address or addresses learned on a logical interface.
MAC flags	Status of MAC address learning properties for each interface: <ul style="list-style-type: none"> <li>• S—Static MAC address is configured.</li> <li>• D—Dynamic MAC address is configured.</li> <li>• SE—MAC accounting is enabled.</li> <li>• NM—Non-configured MAC.</li> </ul>
Logical interface	Name of the logical interface.
MAC count	Number of MAC addresses learned on the specific routing instance or interface.
Learning interface	Name of the logical interface on which the MAC address was learned.
Learning VLAN	VLAN ID of the routing instance or bridge domain in which the MAC address was learned.
Layer 2 flags	Debugging flags signifying that the MAC address is present in various lists.
Epoch	Spanning Tree Protocol epoch number identifying when the MAC address was learned. Used for debugging.
Sequence number	Sequence number assigned to this MAC address. Used for debugging.
Learning mask	Mask of the Packet Forwarding Engines where this MAC address was learned. Used for debugging.
IPC generation	Creation time of the logical interface when this MAC address was learned. Used for debugging.

## Sample Output

### show bridge mac-table

```

user@host> show bridge mac-table
MAC flags (S -static MAC, D -dynamic MAC,
          SE -Statistics enabled, NM -Non configured MAC)

Routing instance : vs1
Bridging domain : vlan100, VLAN : 100
  Learning MAC      MAC      Logical
  VLAN   address    flags   interface
    00:00:00:19:1c:db D      ge-11/0/3.0
    00:00:00:59:3a:2f D      xe-10/2/0.100

```

**show bridge mac-table brief**

```

user@host> show bridge mac-table brief
MAC flags (S -static MAC, D -dynamic MAC,
          SE -Statistics enabled, NM -Non configured MAC)

Routing instance : vs1
  Bridging domain : vlan100, VLAN : 100
    Learning MAC          MAC          Logical
    VLAN      address      flags      interface
      00:00:00:19:1c:db    D          ge-11/0/3.0
      00:00:00:59:3a:2f    D          xe-10/2/0.100

```

**show brief mac-table count**

```

user@host> show bridge mac-table count
2 MAC address learned in routing instance vs1 bridge domain vlan100

MAC address count per interface within routing instance:
  Logical interface      MAC count
  ge-11/0/3.0            1
  ge-11/1/4.100          0
  ge-11/1/1.100          0
  ge-11/1/0.100          0
  xe-10/2/0.100          1
  xe-10/0/0.100          0

MAC address count per learn VLAN within routing instance:
  Learn VLAN ID          MAC count
  0                       2

0 MAC address learned in routing instance vs1 bridge domain vlan200

MAC address count per interface within routing instance:
  Logical interface      MAC count
  ge-11/1/0.200          0
  ge-11/1/1.200          0
  ge-11/1/4.200          0
  xe-10/0/0.200          0
  xe-10/2/0.200          0

MAC address count per learn VLAN within routing instance:
  Learn VLAN ID          MAC count
  0                       0

```

**show bridge mac-table detail**

```

user@host> show bridge mac-table detail
MAC address: 00:00:00:19:1c:db
  Routing instance: vs1
  Bridging domain: vlan100
  Learning interface: ge-11/0/3.0   Learning VLAN: 0
  Layer 2 flags: in_ifd, in_ifl, in_vlan, kernel
  Epoch: 4                          Sequence number: 0
  Learning mask: 0x800               IPC generation: 0

MAC address: 00:00:00:59:3a:2f
  Routing instance: vs1
  Bridging domain: vlan100
  Learning interface: xe-10/2/0.100   Learning VLAN: 0
  Layer 2 flags: in_ifd, in_ifl, in_vlan, kernel

```

Epoch: 7  
Learning mask: 0x400

Sequence number: 0  
IPC generation: 0

## show bridge statistics

<b>Syntax</b>	<b>show bridge statistics</b> <b>&lt;bridge-domain <i>domain-name</i>&gt;</b> <b>&lt;instance <i>instance-name</i>&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Display bridge statistics.
<b>Options</b>	<b>none</b> —Display bridge statistics for all bridge domains in all routing instances.  <b>bridge-domain <i>domain-name</i></b> —(Optional) Display statistics for the specified bridge domain.  <b>instance <i>instance-name</i></b> —(Optional) Display statistics for the specified routing instance.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show bridge statistics on page 112</a>

### Sample Output

#### show bridge statistics

```

user@host> show bridge statistics
Information for routing instance:

Routing instance : __juniper_private1__
  Index: 1                      Sequence number: 0
  MAC limit: 5000                MACs learned: 0
  Static MACs learned: 0         Non config Static MACs learned: 0
  Handle: 0x829e800

Information for routing instance:

Routing instance : vs1
  Bridging domain : vlan100
  Index: 3                      Sequence number: 0
  MAC limit: 5120                MACs learned: 2
  Static MACs learned: 0         Non config Static MACs learned: 0
  Handle: 0x829e400
  Flags: Bridge instance, Config defined, VLAN : 100
  Local interface: ge-11/0/3.0, Index: 79
    Broadcast packets: 1
    Broadcast bytes : 65
    Multicast packets: 0
    Multicast bytes : 0
    Flooded packets : 0
    Flooded bytes : 0
    Unicast packets : 358624489
    Unicast bytes : 23310592305
    Current MAC count: 1 (Limit 1024)
  Local interface: ge-11/1/4.100, Index: 84
    Broadcast packets: 0
    Broadcast bytes : 0
    Multicast packets: 0
    Multicast bytes : 0

```

```

Flooded packets : 0
Flooded bytes : 0
Unicast packets : 0
Unicast bytes : 0
Current MAC count: 0 (Limit 1024)
Local interface: ge-11/1/1.100, Index: 86
Broadcast packets: 0
Broadcast bytes : 0
Multicast packets: 0
Multicast bytes : 0
Flooded packets : 0
Flooded bytes : 0
Unicast packets : 0
Unicast bytes : 0
Current MAC count: 0 (Limit 1024)
Local interface: ge-11/1/0.100, Index: 87
Broadcast packets: 0
Broadcast bytes : 0
Multicast packets: 0
Multicast bytes : 0
Flooded packets : 0
Flooded bytes : 0
Unicast packets : 0
Unicast bytes : 0
Current MAC count: 0 (Limit 1024)
Local interface: xe-10/2/0.100, Index: 88
Broadcast packets: 0
Broadcast bytes : 0
Multicast packets: 0
Multicast bytes : 0
Flooded packets : 0
Flooded bytes : 0
Unicast packets : 358627393
Unicast bytes : 23310781065
Current MAC count: 1 (Limit 1024)
Local interface: xe-10/0/0.100, Index: 89
Broadcast packets: 0
Broadcast bytes : 0
Multicast packets: 0
Multicast bytes : 0
Flooded packets : 0
Flooded bytes : 0
Unicast packets : 0
Unicast bytes : 0
Current MAC count: 0 (Limit 1024)

```

#### Information for routing instance:

```

Routing instance : vs1
Bridging domain : vlan200
Index: 4                      Sequence number: 0
MAC limit: 5120              MACs learned: 0
Static MACs learned: 0      Non config Static MACs learned: 0
Handle: 0x829e600
Flags: Bridge instance, Config defined, VLAN : 200
Local interface: ge-11/1/0.200, Index: 90
Broadcast packets: 0
Broadcast bytes : 0
Multicast packets: 0
Multicast bytes : 0
Flooded packets : 0

```

```
Flooded bytes      : 0
Unicast packets    : 0
Unicast bytes      : 0
Current MAC count: 0 (Limit 1024)
Local interface: ge-11/1/1.200, Index: 91
Broadcast packets: 0
Broadcast bytes    : 0
Multicast packets: 0
Multicast bytes    : 0
Flooded packets   : 0
Flooded bytes     : 0
Unicast packets   : 0
Unicast bytes     : 0
Current MAC count: 0 (Limit 1024)
Local interface: ge-11/1/4.200, Index: 92
Broadcast packets: 0
Broadcast bytes    : 0
Multicast packets: 0
Multicast bytes    : 0
Flooded packets   : 0
Flooded bytes     : 0
Unicast packets   : 0
Unicast bytes     : 0
Current MAC count: 0 (Limit 1024)
Local interface: xe-10/0/0.200, Index: 93
Broadcast packets: 0
Broadcast bytes    : 0
Multicast packets: 0
Multicast bytes    : 0
Flooded packets   : 0
Flooded bytes     : 0
Unicast packets   : 0
Unicast bytes     : 0
Current MAC count: 0 (Limit 1024)
Local interface: xe-10/2/0.200, Index: 94
Broadcast packets: 4
Broadcast bytes    : 260
Multicast packets: 0
Multicast bytes    : 0
Flooded packets   : 0
Flooded bytes     : 0
Unicast packets   : 0
Unicast bytes     : 0
Current MAC count: 0 (Limit 1024)
```



## show interfaces queue

<b>Syntax</b>	<pre>show interfaces queue &lt;aggregate   remaining-traffic&gt; &lt;both-ingress-egress&gt; &lt;egress&gt; &lt;forwarding-class forwarding-class&gt; &lt;ingress&gt; &lt;interface-name interface-name&gt; &lt;l2-statistics&gt;</pre>
<b>Release Information</b>	<p>Command introduced before Junos OS Release 7.4.</p> <p><b>both-ingress-egress</b>, <b>egress</b>, and <b>ingress</b> options introduced in Junos OS Release 7.6.</p> <p>Command introduced in Junos OS Release 11.1 for the QFX Series.</p> <p><b>l2-statistics</b> option introduced in Junos OS Release 12.1.</p>
<b>Description</b>	Display class-of-service (CoS) queue information for physical interfaces.
<b>Options</b>	<p><b>none</b>—Show detailed CoS queue statistics for all physical interfaces.</p> <p><b>aggregate</b>—(Optional) Display the aggregated queuing statistics of all logical interfaces that have traffic-control profiles configured. (Not on the QFX Series.)</p> <p><b>both-ingress-egress</b>—(Optional) On Gigabit Ethernet Intelligent Queuing 2 (IQ2) PICs, display both ingress and egress queue statistics. (Not on the QFX Series.)</p> <p><b>egress</b>—(Optional) Display egress queue statistics.</p> <p><b>forwarding-class forwarding-class</b>—(Optional) Forwarding class name for this queue. Shows detailed CoS statistics for the queue associated with the specified forwarding class.</p> <p><b>ingress</b>—(Optional) On Gigabit Ethernet IQ2 PICs, display ingress queue statistics. (Not on the QFX Series.)</p> <p><b>interface-name interface-name</b>—(Optional) Show detailed CoS queue statistics for the specified interface.</p> <p><b>l2-statistics</b>—(Optional) Display Layer 2 statistics for MLPPP, FRF.15, and FRF.16 bundles</p> <p><b>remaining-traffic</b>—(Optional) Display the remaining-traffic queue statistics of all logical interfaces that have traffic-control profiles configured.</p>

### Overhead for Layer 2 Statistics

Transmitted packets and transmitted byte counts are displayed for the Layer 2 level with the addition of encapsulation overheads applied for fragmentation, as shown in [Table 6 on page 116](#). Others counters, such as packets and bytes queued (input) and drop counters, are displayed at the Layer 3 level. In the case of link fragmentation and interleaving (LFI) for which fragmentation is not applied, corresponding Layer 2 overheads are added, as shown in [Table 6 on page 116](#).

Table 6: Layer 2 Overhead, Transmitted Packets/Bytes

Protocol	Fragmentation		LFI
	First fragmentation	Second to n fragmentations	
	Bytes	Bytes	
MLPPP (Long)	13	12	8
MLPPP (short)	11	10	8
MLFR (FRF15)	12	10	8
MFR (FRF16)	10	8	-
MCMLPPP(Long)	13	12	-
MCMLPPP(Short)	11	10	-

## Layer 2 Statistics - Fragmentation Overhead Calculation

## MLPPP/MC-MLPPP Overhead details:

=====

## Fragment 1:

```

Outer PPP header           : 4 bytes
Long or short sequence MLPPP header : 4 bytes or 2 bytes
Inner PPP header           : 1 byte
HDLC flag and FCS bytes    : 4 bytes

```

## Fragments 2 .. n :

```

Outer PPP header           : 4 bytes
Long or short sequence MLPPP header : 4 bytes or 2 bytes
HDLC flag and FCS bytes    : 4 bytes

```

## MLFR (FRF15) Overhead details:

=====

## Fragment 1:

```

Framereelay header        : 2 bytes
Control,NLPID             : 2 bytes
Fragmentaion header       : 2 bytes
Inner proto               : 2 bytes
HDLC flag and FCS         : 4 bytes

```

## Fragments 2 ...n :

```

Framereelay header        : 2 bytes
Control,NLPID             : 2 bytes
Fragmentaion header       : 2 bytes
HDLC flag and FCS         : 4 bytes

```

## MFR (FRF16) Overhead details:

=====

```

Fragment 1:
  Fragmentation header : 2 bytes
  Framereelay header   : 2 bytes
  Inner proto          : 2 bytes
  HDLC flag and FCS    : 4 bytes

Fragments 2 ...n :
  Fragmentation header : 2 bytes
  Framereelay header   : 2 bytes
  HDLC flag and FCS    : 4 bytes

```

## Overhead with LFI

```

MLPPP(Long & short sequence):
=====
  Outer PPP header : 4 bytes
  HDLC flag and FCS : 4 bytes

MLFR (FRF15):
=====
  Framereelay header : 2 bytes
  Control,NLPID      : 2 bytes
  HDLC flag and FCS  : 4 bytes

```

The following examples show overhead for different cases:

- A 1000-byte packet is sent to a mlppp bundle without any fragmentation. At the Layer 2 level, bytes transmitted is 1013 in 1 packet. This overhead is for MLPPP long sequence encap.
- A 1000-byte packet is sent to a mlppp bundle with a fragment threshold of 250byte. At the Layer 2 level, bytes transmitted is 1061 bytes in 5 packets.
- A 1000-byte LFI packet is sent to an mlppp bundle. At the Layer 2 level, bytes transmitted is 1008 in 1 packet.

**remaining-traffic**—(Optional) Display the queuing statistics of all logical interfaces that do not have traffic-control profiles configured. (Not on the QFX Series.)

## Additional Information

For rate-limited interfaces hosted on Modular Interface Cards (MICs) or Modular Port Concentrators (MPCs), rate-limit packet-drop operations occur *before* packets are queued for transmission scheduling. For such interfaces, the statistics for queued traffic do not include the packets that have already been dropped due to rate limiting, and consequently the displayed statistics for queued traffic are the same as the displayed statistics for transmitted traffic.



**NOTE:** For rate-limited interfaces hosted on other types of hardware, rate-limit packet-drop operations occur *after* packets are queued for transmission scheduling. For these other interface types, the statistics for queued traffic include the packets that are later dropped due to rate limiting, and consequently the displayed statistics for queued traffic equals the sum of the statistics for transmitted and rate-limited traffic.

On M Series routers (except for the M320 and M120 routers), this command is valid only for a PIC installed on an enhanced Flexible PIC Concentrator (FPC).

Queue statistics for aggregated interfaces are supported on the M Series and T Series routers only. Statistics for an aggregated interface are the summation of the queue statistics of the child links of that aggregated interface. You can view the statistics for a child interface by using the **show interfaces statistics** command for that child interface.

When you configure tricolor marking on a 10-port 1-Gigabit Ethernet PIC, for queues 6 and 7 only, the output does not display the number of queued bytes and packets, or the number of bytes and packets dropped because of RED. If you do not configure tricolor marking on the interface, these statistics are available for all queues.

For the 4-port Channelized OC12 IQE PIC and 1-port Channelized OC48 IQE PIC, the **Packet Forwarding Engine Chassis Queues** field represents traffic bound for a particular physical interface on the PIC. For all other PICs, the **Packet Forwarding Engine Chassis Queues** field represents the total traffic bound for the PIC.

For Gigabit Ethernet IQ2 PICs, the **show interfaces queue** command output does not display the number of tail-dropped packets. This limitation does not apply to Packet Forwarding Engine chassis queues.

When fragmentation occurs on the egress interface, the first set of packet counters shows the postfragmentation values. The second set of packet counters (under the **Packet Forwarding Engine Chassis Queues** field) shows the prefragmentation values.

The behavior of the **egress** queues for the **Routing Engine-Generated Traffic** is not same as the configured queue for MLPPP and MFR configurations.

For information about how to configure CoS, see the *Junos OS Network Interfaces Library for Routing Devices*. For related CoS operational mode commands, see the *Junos OS Operational Mode Commands*.

**Required Privilege Level**

view

**List of Sample Output**

[show interfaces queue \(Rate-Limited Interface on a Gigabit Ethernet MIC in an MPC\) on page 123](#)  
[show interfaces queue \(Aggregated Ethernet on a T320 Router\) on page 124](#)  
[show interfaces queue \(Fast Ethernet on a J4300 Router\) on page 126](#)  
[show interfaces queue \(Gigabit Ethernet on a T640 Router\) on page 126](#)  
[show interfaces queue aggregate \(Gigabit Ethernet Enhanced DPC\) on page 127](#)  
[show interfaces queue \(Gigabit Ethernet IQ2 PIC\) on page 131](#)  
[show interfaces queue both-ingress-egress \(Gigabit Ethernet IQ2 PIC\) on page 134](#)  
[show interfaces queue ingress \(Gigabit Ethernet IQ2 PIC\) on page 136](#)  
[show interfaces queue egress \(Gigabit Ethernet IQ2 PIC\) on page 137](#)  
[show interfaces queue remaining-traffic \(Gigabit Ethernet Enhanced DPC\) on page 138](#)  
[show interfaces queue \(Channelized OC12 IQE Type 3 PIC in SONET Mode\) on page 141](#)  
[show interfaces queue \(QFX Series\) on page 151](#)  
[show interfaces queue l2-statistics \(lsq interface\) on page 152](#)

**Output Fields** Table 7 on page 119 lists the output fields for the **show interfaces queue** command. Output fields are listed in the approximate order in which they appear.

**Table 7: show interfaces queue Output Fields**

Field Name	Field Description
Physical interface	Name of the physical interface.
Enabled	State of the interface. Possible values are described in the “Enabled Field” section under <i>Common Output Fields Description</i> .
Interface index	Physical interface's index number, which reflects its initialization sequence.
SNMP ifIndex	SNMP index number for the interface.
Forwarding classes supported	Total number of forwarding classes supported on the specified interface.
Forwarding classes in use	Total number of forwarding classes in use on the specified interface.
Ingress queues supported	On Gigabit Ethernet IQ2 PICs only, total number of ingress queues supported on the specified interface.
Ingress queues in use	On Gigabit Ethernet IQ2 PICs only, total number of ingress queues in use on the specified interface.
Output queues supported	Total number of output queues supported on the specified interface.
Output queues in use	Total number of output queues in use on the specified interface.
Egress queues supported	Total number of egress queues supported on the specified interface.
Egress queues in use	Total number of egress queues in use on the specified interface.
Queue counters (Ingress)	CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces. <ul style="list-style-type: none"> <li>• <b>Queued packets</b>—Number of queued packets.</li> <li>• <b>Transmitted packets</b>—Number of transmitted packets.</li> <li>• <b>Dropped packets</b>—Number of packets dropped by the ASIC's RED mechanism.</li> </ul>
Burst size	(Logical interfaces on IQ PICs only) Maximum number of bytes up to which the logical interface can burst. The burst size is based on the shaping rate applied to the interface.
The following output fields are applicable to both interface component and Packet Forwarding component in the <b>show interfaces queue</b> command:	
Queue	Queue number.
Forwarding classes	Forwarding class name.

Table 7: show interfaces queue Output Fields (*continued*)

Field Name	Field Description
<b>Queued Packets</b>	<p>Number of packets queued to this queue.</p> <p><b>NOTE:</b> For Gigabit Ethernet IQ2 interfaces, the Queued Packets count is calculated by the Junos OS interpreting one frame buffer as one packet. If the queued packets are very large or very small, the calculation might not be completely accurate for transit traffic. The count is completely accurate for traffic terminated on the router.</p> <p>For rate-limited interfaces hosted on MICs or MPCs only, this statistic does not include traffic dropped due to rate limiting. For more information, see <a href="#">“Additional Information” on page 117</a>.</p>
<b>Queued Bytes</b>	<p>Number of bytes queued to this queue. The byte counts vary by interface hardware. For more information, see <a href="#">Table 8 on page 122</a>.</p> <p>For rate-limited interfaces hosted on MICs or MPCs only, this statistic does not include traffic dropped due to rate limiting. For more information, see <a href="#">“Additional Information” on page 117</a>.</p>
<b>Transmitted Packets</b>	<p>Number of packets transmitted by this queue. When fragmentation occurs on the egress interface, the first set of packet counters shows the postfragmentation values. The second set of packet counters (displayed under the <b>Packet Forwarding Engine Chassis Queues</b> field) shows the prefragmentation values.</p> <p><b>NOTE:</b> For Layer 2 statistics, see <a href="#">“Overhead for Layer 2 Statistics” on page 115</a></p>
<b>Transmitted Bytes</b>	<p>Number of bytes transmitted by this queue. The byte counts vary by interface hardware. For more information, see <a href="#">Table 8 on page 122</a>.</p> <p><b>NOTE:</b> On MX Series routers, this number can be inaccurate when you issue the command for a physical interface repeatedly and in quick succession, because the statistics for the child nodes are collected infrequently. Wait ten seconds between successive iterations to avoid this situation.</p> <p><b>NOTE:</b> For Layer 2 statistics, see <a href="#">“Overhead for Layer 2 Statistics” on page 115</a></p>
<b>Tail-dropped packets</b>	Number of packets dropped because of tail drop.
<b>RL-dropped packets</b>	<p>Number of packets dropped due to rate limiting.</p> <p>For rate-limited interfaces hosted on MICs or MPCs only, this statistic is not included in the queued traffic statistics. For more information, see <a href="#">“Additional Information” on page 117</a>.</p>
<b>RL-dropped bytes</b>	<p>Number of bytes dropped due to rate limiting.</p> <p>For rate-limited interfaces hosted on MICs or MPCs only, this statistic is not included in the queued traffic statistics. For more information, see <a href="#">“Additional Information” on page 117</a>.</p>

Table 7: show interfaces queue Output Fields (*continued*)

Field Name	Field Description
RED-dropped packets	<p>Number of packets dropped because of random early detection (RED).</p> <ul style="list-style-type: none"> <li>(M Series and T Series routers only) On M320 and M120 routers and the T Series routers, the total number of dropped packets is displayed. On all other M Series routers, the output classifies dropped packets into the following categories: <ul style="list-style-type: none"> <li><b>Low, non-TCP</b>—Number of low-loss priority non-TCP packets dropped because of RED.</li> <li><b>Low, TCP</b>—Number of low-loss priority TCP packets dropped because of RED.</li> <li><b>High, non-TCP</b>—Number of high-loss priority non-TCP packets dropped because of RED.</li> <li><b>High, TCP</b>—Number of high-loss priority TCP packets dropped because of RED.</li> </ul> </li> <li>(J Series routers and MX Series routers with enhanced DPCs, and T Series routers with enhanced FPCs only) The output classifies dropped packets into the following categories: <ul style="list-style-type: none"> <li><b>Low</b>—Number of low-loss priority packets dropped because of RED.</li> <li><b>Medium-low</b>—Number of medium-low loss priority packets dropped because of RED.</li> <li><b>Medium-high</b>—Number of medium-high loss priority packets dropped because of RED.</li> <li><b>High</b>—Number of high-loss priority packets dropped because of RED.</li> </ul> </li> </ul> <p><b>NOTE:</b> Due to accounting space limitations on certain Type 3 FPCs (which are supported in M320 and T640 routers), this field does not always display the correct value for queue 6 or queue 7 for interfaces on 10-port 1-Gigabit Ethernet PICs.</p>
RED-dropped bytes	<p>Number of bytes dropped because of RED. The byte counts vary by interface hardware. For more information, see <a href="#">Table 8 on page 122</a>.</p> <ul style="list-style-type: none"> <li>(M Series and T Series routers only) On M320 and M120 routers and the T Series routers, only the total number of dropped bytes is displayed. On all other M Series routers, the output classifies dropped bytes into the following categories: <ul style="list-style-type: none"> <li><b>Low, non-TCP</b>—Number of low-loss priority non-TCP bytes dropped because of RED.</li> <li><b>Low, TCP</b>—Number of low-loss priority TCP bytes dropped because of RED.</li> <li><b>High, non-TCP</b>—Number of high-loss priority non-TCP bytes dropped because of RED.</li> <li><b>High, TCP</b>—Number of high-loss priority TCP bytes dropped because of RED.</li> </ul> </li> <li>(J Series routers only) The output classifies dropped bytes into the following categories: <ul style="list-style-type: none"> <li><b>Low</b>—Number of low-loss priority bytes dropped because of RED.</li> <li><b>Medium-low</b>—Number of medium-low loss priority bytes dropped because of RED.</li> <li><b>Medium-high</b>—Number of medium-high loss priority bytes dropped because of RED.</li> <li><b>High</b>—Number of high-loss priority bytes dropped because of RED.</li> </ul> </li> </ul> <p><b>NOTE:</b> Due to accounting space limitations on certain Type 3 FPCs (which are supported in M320 and T640 routers), this field does not always display the correct value for queue 6 or queue 7 for interfaces on 10-port 1-Gigabit Ethernet PICs.</p>

Byte counts vary by interface hardware. [Table 8 on page 122](#) shows how the byte counts on the outbound interfaces vary depending on the interface hardware. [Table 8 on page 122](#) is based on the assumption that outbound interfaces are sending IP traffic with 478 bytes per packet.

Table 8: Byte Count by Interface Hardware

Interface Hardware	Output Level	Byte Count Includes	Comments
Gigabit Ethernet IQ and IQE PICs	Interface	<p>Queued: 490 bytes per packet, representing 478 bytes of Layer 3 packet + 12 bytes</p> <p>Transmitted: 490 bytes per packet, representing 478 bytes of Layer 3 packet + 12 bytes</p> <p>RED dropped: 496 bytes per packet representing 478 bytes of Layer 3 packet + 18 bytes</p>	<p>The 12 additional bytes include 6 bytes for the destination MAC address + 4 bytes for the VLAN + 2 bytes for the Ethernet type.</p> <p>For RED dropped, 6 bytes are added for the source MAC address.</p>
	Packet forwarding component	<p>Queued: 478 bytes per packet, representing 478 bytes of Layer 3 packet</p> <p>Transmitted: 478 bytes per packet, representing 478 bytes of Layer 3 packet</p>	—
Non-IQ PIC	Interface	<p>T Series, TX Series, T1600, and MX Series routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet.</li> <li>Transmitted: 478 bytes of Layer 3 packet.</li> </ul> <p>T4000 routers with Type 5 FPCs :</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes CRC + the full Layer 1 overhead 8 bytes preamble + 12 bytes Inter frame Gap.</li> <li>Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes CRC + the full Layer 1 overhead 8 bytes preamble + 12 bytes Interframe Gap.</li> </ul> <p>M Series routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet.</li> <li>Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead.</li> </ul> <p>PTX Series Packet Transport Routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes FCS + the full Layer 1 overhead of the MAC header DA + SA + EtherType (non-VLAN).</li> <li>Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead including 4 bytes CRC + the full Layer 1 overhead of the MAC header DA + SA + EtherType (non-VLAN).</li> <li>RED dropped: 478 bytes of Layer 3 packet + 22 bytes special header. To the TQ, this packet has 4 bytes more than queued or transmitted.</li> </ul>	<p>The Layer 2 overhead is 14 bytes for non-VLAN traffic and 18 bytes for VLAN traffic.</p>



Table 8: Byte Count by Interface Hardware (*continued*)

Interface Hardware	Output Level	Byte Count Includes	Comments
IQ and IQE PICs with a SONET/SDH interface	Interface	<p>Queued: 482 bytes per packet, representing 478 bytes of Layer 3 packet + 4 bytes</p> <p>Transmitted: 482 bytes per packet, representing 478 bytes of Layer 3 packet + 4 bytes</p> <p>RED dropped: 482 bytes per packet, representing 478 bytes of Layer 3 packet + 4 bytes</p>	The additional 4 bytes are for the Layer 2 Point-to-Point Protocol (PPP) header.
	Packet forwarding component	<p>Queued: 478 bytes per packet, representing 478 bytes of Layer 3 packet</p> <p>Transmitted: 486 bytes per packet, representing 478 bytes of Layer 3 packet + 8 bytes</p>	For transmitted packets, the additional 8 bytes includes 4 bytes for the PPP header and 4 bytes for a cookie.
Non-IQ PIC with a SONET/SDH interface	Interface	<p>T Series, TX Series, T1600, and MX Series routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet.</li> <li>Transmitted: 478 bytes of Layer 3 packet.</li> </ul> <p>M Series routers:</p> <ul style="list-style-type: none"> <li>Queued: 478 bytes of Layer 3 packet.</li> <li>Transmitted: 483 bytes per packet, representing 478 bytes of Layer 3 packet + 5 bytes</li> <li>RED dropped: 478 bytes per packet, representing 478 bytes of Layer 3 packet</li> </ul>	For transmitted packets, the additional 5 bytes includes 4 bytes for the PPP header and 1 byte for the packet loss priority (PLP).
Interfaces configured with Frame Relay Encapsulation	Interface	The default Frame Relay overhead is 7 bytes. If you configure the Frame Check Sequence (FCS) to 4 bytes, then the overhead increases to 10 bytes.	
1-port 10-Gigabit Ethernet IQ2 and IQ2-E PICs	Interface	<p>Queued: 478 bytes of Layer 3 packet + the full Layer 2 overhead including CRC.</p> <p>Transmitted: 478 bytes of Layer 3 packet + the full Layer 2 overhead including CRC.</p>	The Layer 2 overhead is 18 bytes for non-VLAN traffic and 22 bytes for VLAN traffic.
4-port 1G IQ2 and IQ2-E PICs	Packet forwarding component	Queued: 478 bytes of Layer 3 packet.	—
8-port 1G IQ2 and IQ2-E PICs		Transmitted: 478 bytes of Layer 3 packet.	

## Sample Output

### show interfaces queue (Rate-Limited Interface on a Gigabit Ethernet MIC in an MPC)

The following example shows queue information for the rate-limited interface ge-4/2/0 on a Gigabit Ethernet MIC in an MPC. For rate-limited queues for interfaces hosted on MICs or MPCs, rate-limit packet drops occur prior to packet output queuing. In the

command output, the nonzero statistics displayed in the **RL-dropped packets** and **RL-dropped bytes** fields quantify the traffic dropped to rate-limit queue 0 output to 10 percent of 1 gigabyte (100 megabits) per second. Because the RL-dropped traffic is not included in the **Queued** statistics, the statistics displayed for queued traffic are the same as the statistics for transmitted traffic.

```
user@host> show interfaces queue ge-4/2/0
Physical interface: ge-4/2/0, Enabled, Physical link is Up
  Interface index: 203, SNMP ifIndex: 1054
Forwarding classes: 16 supported, 4 in use
Egress queues: 8 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets          :          131300649          141751 pps
    Bytes            :          11287964840        99793248 bps
  Transmitted:
    Packets          :          131300649          141751 pps
    Bytes            :          11287964840        99793248 bps
    Tail-dropped packets :              0              0 pps
    RL-dropped packets  :          205050862        602295 pps
    RL-dropped bytes    :          13595326612      327648832 bps
    RED-dropped packets :              0              0 pps
      Low              :              0              0 pps
      Medium-low       :              0              0 pps
      Medium-high      :              0              0 pps
      High              :              0              0 pps
    RED-dropped bytes   :              0              0 bps
      Low              :              0              0 bps
      Medium-low       :              0              0 bps
      Medium-high      :              0              0 bps
      High              :              0              0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets          :              0              0 pps
    Bytes            :              0              0 bps
```

#### show interfaces queue (Aggregated Ethernet on a T320 Router)

The following example shows that the aggregated Ethernet interface, **ae1**, has traffic on queues **af1** and **af12**:

```
user@host> show interfaces queue ae1
Physical interface: ae1, Enabled, Physical link is Up
  Interface index: 158, SNMP ifIndex: 33 Forwarding classes: 8 supported, 8 in use
Output queues: 8 supported, 8 in use
Queue: 0, Forwarding classes: be
  Queued:
    Packets          :              5              0 pps
    Bytes            :              242              0 bps
  Transmitted:
    Packets          :              5              0 pps
    Bytes            :              242              0 bps
    Tail-dropped packets :              0              0 pps
    RED-dropped packets :              0              0 pps
    RED-dropped bytes   :              0              0 bps
Queue: 1, Forwarding classes: af1
  Queued:
    Packets          :          42603765          595484 pps
```

```

Bytes                :          5453281920          609776496 bps
Transmitted:
Packets              :          42603765           595484 pps
Bytes                :          5453281920          609776496 bps
Tail-dropped packets :              0              0 pps
RED-dropped packets  :              0              0 pps
RED-dropped bytes    :              0              0 bps
Queue: 2, Forwarding classes: ef1
Queued:
Packets              :              0              0 pps
Bytes                :              0              0 bps
Transmitted:
Packets              :              0              0 pps
Bytes                :              0              0 bps
Tail-dropped packets :              0              0 pps
RED-dropped packets  :              0              0 pps
RED-dropped bytes    :              0              0 bps
Queue: 3, Forwarding classes: nc
Queued:
Packets              :              45              0 pps
Bytes                :             3930              0 bps
Transmitted:
Packets              :              45              0 pps
Bytes                :             3930              0 bps
Tail-dropped packets :              0              0 pps
RED-dropped packets  :              0              0 pps
RED-dropped bytes    :              0              0 bps
Queue: 4, Forwarding classes: af11
Queued:
Packets              :              0              0 pps
Bytes                :              0              0 bps
Transmitted:
Packets              :              0              0 pps
Bytes                :              0              0 bps
Tail-dropped packets :              0              0 pps
RED-dropped packets  :              0              0 pps
RED-dropped bytes    :              0              0 bps
Queue: 5, Forwarding classes: ef11
Queued:
Packets              :              0              0 pps
Bytes                :              0              0 bps
Transmitted:
Packets              :              0              0 pps
Bytes                :              0              0 bps
Tail-dropped packets :              0              0 pps
RED-dropped packets  :              0              0 pps
RED-dropped bytes    :              0              0 bps
Queue: 6, Forwarding classes: af12
Queued:
Packets              :          31296413          437436 pps
Bytes                :          4005940864          447935200 bps
Transmitted:
Packets              :          31296413          437436 pps
Bytes                :          4005940864          447935200 bps
Tail-dropped packets :              0              0 pps
RED-dropped packets  :              0              0 pps
RED-dropped bytes    :              0              0 bps
Queue: 7, Forwarding classes: nc2
Queued:
Packets              :              0              0 pps
Bytes                :              0              0 bps

```

```

Transmitted:
Packets      :                0                0 pps
Bytes        :                0                0 bps
Tail-dropped packets :                0                0 pps
RED-dropped packets :                0                0 pps
RED-dropped bytes  :                0                0 bps

```

#### show interfaces queue (Fast Ethernet on a J4300 Router)

```

user@host> show interfaces queue fe-4/0/0.0
Logical interface fe-4/0/0.0 (Index 71) (SNMP ifIndex 42)
Forwarding classes: 8 supported, 8 in use
Output queues: 8 supported, 8 in use
Queue: 0, Forwarding classes: be
  Queued:
    Packets      :                5240762                3404 pps
    Bytes        :            3020710354            15934544 bps
  Transmitted:
    Packets      :                5240762                3404 pps
    Bytes        :            3020710354            15934544 bps
    Tail-dropped packets :                0                0 pps
    RED-dropped packets :                0                0 pps
    Low          :                0                0 pps
    Medium-low   :                0                0 pps
    Medium-high  :                0                0 pps
    High         :                0                0 pps
    RED-dropped bytes :                0                0 bps
    Low          :                0                0 pps
    Medium-low   :                0                0 pps
    Medium-high  :                0                0 pps
    High         :                0                0 pps
Queue: 1, Forwarding classes: af1
  Queued:
    Packets      :                2480391                1650 pps
    Bytes        :            1304685666            6945704 bps
  Transmitted:
    Packets      :                2478740                1650 pps
    Bytes        :            1303817240            6945704 bps
    Tail-dropped packets :                0                0 pps
    RED-dropped packets :                1651                0 pps
    Low          :                0                0 pps
    Medium-low   :                0                0 pps
    Medium-high  :                0                0 pps
    High         :                1651                0 pps
    RED-dropped bytes :                868426                0 bps
    Low          :                0                0 pps
    Medium-low   :                0                0 pps
    Medium-high  :                0                0 pps
    High         :                868426                0 pps

```

#### show interfaces queue (Gigabit Ethernet on a T640 Router)

```

user@host> show interfaces queue
Physical interface: ge-7/0/1, Enabled, Physical link is Up
Interface index: 150, SNMP ifIndex: 42
Forwarding classes: 8 supported, 8 in use
Output queues: 8 supported, 8 in use
Queue: 0, Forwarding classes: be
  Queued:

```

```

Packets          :          13          0 pps
Bytes            :          622          0 bps
Transmitted:
Packets          :          13          0 pps
Bytes            :          622          0 bps
Tail-dropped packets :          0          0 pps
RED-dropped packets :          0          0 pps
RED-dropped bytes  :          0          0 bps
Queue: 1, Forwarding classes: af1
Queued:
Packets          :      1725947945      372178 pps
Bytes            :      220921336960    381110432 bps
Transmitted:
Packets          :      1725947945      372178 pps
Bytes            :      220921336960    381110432 bps
Tail-dropped packets :          0          0 pps
RED-dropped packets :          0          0 pps
RED-dropped bytes  :          0          0 bps
Queue: 2, Forwarding classes: ef1
Queued:
Packets          :          0          0 pps
Bytes            :          0          0 bps
Transmitted:
Packets          :          0          0 pps
Bytes            :          0          0 bps
Tail-dropped packets :          0          0 pps
RED-dropped packets :          0          0 pps
RED-dropped bytes  :          0          0 bps
Queue: 3, Forwarding classes: nc
Queued:
Packets          :          571          0 pps
Bytes            :         49318        336 bps
Transmitted:
Packets          :          571          0 pps
Bytes            :         49318        336 bps
Tail-dropped packets :          0          0 pps
RED-dropped packets :          0          0 pps
RED-dropped bytes  :          0          0 bps

```

#### show interfaces queue aggregate (Gigabit Ethernet Enhanced DPC)

```

user@host> show interfaces queue ge-2/2/9 aggregate
Physical interface: ge-2/2/9, Enabled, Physical link is Up
Interface index: 238, SNMP ifIndex: 71
Forwarding classes: 16 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
Queued:
Packets          :      148450735      947295 pps
Bytes            :      8016344944    409228848 bps
Transmitted:
Packets          :      76397439       487512 pps
Bytes            :      4125461868    210602376 bps
Tail-dropped packets : Not Available
RED-dropped packets :      72053285      459783 pps
Low              :      72053285      459783 pps
Medium-low       :          0          0 pps
Medium-high      :          0          0 pps
High             :          0          0 pps
RED-dropped bytes :      3890877444    198626472 bps

```

```

Low : 3890877444 198626472 bps
Medium-low : 0 0 bps
Medium-high : 0 0 bps
High : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
Packets : 0 0 pps
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low : 0 0 pps
Medium-low : 0 0 pps
Medium-high : 0 0 pps
High : 0 0 pps
RED-dropped bytes : 0 0 bps
Low : 0 0 bps
Medium-low : 0 0 bps
Medium-high : 0 0 bps
High : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets : 410278257 473940 pps
Bytes : 22156199518 204742296 bps
Transmitted:
Packets : 4850003 4033 pps
Bytes : 261900162 1742256 bps
Tail-dropped packets : Not Available
RED-dropped packets : 405425693 469907 pps
Low : 405425693 469907 pps
Medium-low : 0 0 pps
Medium-high : 0 0 pps
High : 0 0 pps
RED-dropped bytes : 21892988124 203000040 bps
Low : 21892988124 203000040 bps
Medium-low : 0 0 bps
Medium-high : 0 0 bps
High : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets : 0 0 pps
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low : 0 0 pps
Medium-low : 0 0 pps
Medium-high : 0 0 pps
High : 0 0 pps
RED-dropped bytes : 0 0 bps
Low : 0 0 bps
Medium-low : 0 0 bps
Medium-high : 0 0 bps
High : 0 0 bps
Forwarding classes: 16 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort

```

```

Queued:
  Packets      :          76605230          485376 pps
  Bytes        :          5209211400       264044560 bps
Transmitted:
  Packets      :          76444631          484336 pps
  Bytes        :          5198235612       263478800 bps
Tail-dropped packets : Not Available
RED-dropped packets :          160475          1040 pps
  Low          :          160475          1040 pps
  Medium-low   :              0              0 pps
  Medium-high  :              0              0 pps
  High         :              0              0 pps
RED-dropped bytes  :          10912300       565760 bps
  Low           :          10912300       565760 bps
  Medium-low    :              0              0 bps
  Medium-high   :              0              0 bps
  High         :              0              0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
  Packets      :              0              0 pps
  Bytes        :              0              0 bps
Transmitted:
  Packets      :              0              0 pps
  Bytes        :              0              0 bps
Tail-dropped packets : Not Available
RED-dropped packets :              0              0 pps
  Low          :              0              0 pps
  Medium-low   :              0              0 pps
  Medium-high  :              0              0 pps
  High         :              0              0 pps
RED-dropped bytes  :              0              0 bps
  Low          :              0              0 bps
  Medium-low    :              0              0 bps
  Medium-high   :              0              0 bps
  High         :              0              0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
  Packets      :          4836136          3912 pps
  Bytes        :          333402032       2139056 bps
Transmitted:
  Packets      :          3600866          1459 pps
  Bytes        :          244858888       793696 bps
Tail-dropped packets : Not Available
RED-dropped packets :          1225034          2450 pps
  Low          :          1225034          2450 pps
  Medium-low   :              0              0 pps
  Medium-high  :              0              0 pps
  High         :              0              0 pps
RED-dropped bytes  :          83302312       1333072 bps
  Low          :          83302312       1333072 bps
  Medium-low    :              0              0 bps
  Medium-high   :              0              0 bps
  High         :              0              0 bps
Queue: 3, Forwarding classes: network-control
Queued:
  Packets      :              0              0 pps
  Bytes        :              0              0 bps
Transmitted:
  Packets      :              0              0 pps
  Bytes        :              0              0 bps
Tail-dropped packets : Not Available

```

RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

## Packet Forwarding Engine Chassis Queues:

Queues: 4 supported, 4 in use

Queue: 0, Forwarding classes: best-effort

## Queued:

Packets	:	77059796	486384 pps
Bytes	:	3544750624	178989576 bps

## Transmitted:

Packets	:	77059797	486381 pps
Bytes	:	3544750670	178988248 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 1, Forwarding classes: expedited-forwarding

## Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

## Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 2, Forwarding classes: assured-forwarding

## Queued:

Packets	:	4846580	3934 pps
Bytes	:	222942680	1447768 bps

## Transmitted:

Packets	:	4846580	3934 pps
Bytes	:	222942680	1447768 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps



```

      High : 0 0 pps
    RED-dropped bytes : 0 0 bps
      Low : 0 0 bps
    Medium-low : 0 0 bps
    Medium-high : 0 0 bps
      High : 0 0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Transmitted:
    Packets : 0 0 pps
    Bytes : 0 0 bps
    Tail-dropped packets : 0 0 pps
    RED-dropped packets : 0 0 pps
      Low : 0 0 pps
    Medium-low : 0 0 pps
    Medium-high : 0 0 pps
      High : 0 0 pps
    RED-dropped bytes : 0 0 bps
      Low : 0 0 bps
    Medium-low : 0 0 bps
    Medium-high : 0 0 bps
      High : 0 0 bps

```

#### show interfaces queue (Gigabit Ethernet IQ2 PIC)

```

user@host> show interfaces queue ge-7/1/3
Physical interface: ge-7/1/3, Enabled, Physical link is Up
  Interface index: 170, SNMP ifIndex: 70 Forwarding classes: 16 supported, 4 in use
  use Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets : 418390039 10 pps
    Bytes : 38910269752 7440 bps
  Transmitted:
    Packets : 418390039 10 pps
    Bytes : 38910269752 7440 bps
    Tail-dropped packets : Not Available
    RED-dropped packets : 0 0 pps
    RED-dropped bytes : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Transmitted:
    Packets : 0 0 pps
    Bytes : 0 0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets : 0 0 pps
    RED-dropped bytes : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Transmitted:
    Packets : 0 0 pps
    Bytes : 0 0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets : 0 0 pps

```

```

    RED-dropped bytes      :                0                0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets                :                7055             1 pps
    Bytes                  :            451552             512 bps
  Transmitted:
    Packets                :                7055             1 pps
    Bytes                  :            451552             512 bps
    Tail-dropped packets : Not Available
    RED-dropped packets   :                0                0 pps
    RED-dropped bytes     :                0                0 bps
Forwarding classes: 16 supported, 4 in use Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets                :                1031             0 pps
    Bytes                  :            143292             0 bps
  Transmitted:
    Packets                :                1031             0 pps
    Bytes                  :            143292             0 bps
    Tail-dropped packets : Not Available
    RL-dropped packets   :                0                0 pps
    RL-dropped bytes     :                0                0 bps
    RED-dropped packets   :                0                0 pps
    RED-dropped bytes     :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
  Transmitted:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
    Tail-dropped packets : Not Available
    RL-dropped packets   :                0                0 pps
    RL-dropped bytes     :                0                0 bps
    RED-dropped packets   :                0                0 pps
    RED-dropped bytes     :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
  Transmitted:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
    Tail-dropped packets : Not Available
    RL-dropped packets   :                0                0 pps
    RL-dropped bytes     :                0                0 bps
    RED-dropped packets   :                0                0 pps
    RED-dropped bytes     :                0                0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets                :                77009            11 pps
    Bytes                  :            6894286            7888 bps
  Transmitted:
    Packets                :                77009            11 pps
    Bytes                  :            6894286            7888 bps
    Tail-dropped packets : Not Available
    RL-dropped packets   :                0                0 pps
    RL-dropped bytes     :                0                0 bps
    RED-dropped packets   :                0                0 pps
    RED-dropped bytes     :                0                0 bps

```

## Packet Forwarding Engine Chassis Queues:

Queues: 4 supported, 4 in use

Queue: 0, Forwarding classes: best-effort

## Queued:

Packets	:	1031	0 pps
Bytes	:	147328	0 bps

## Transmitted:

Packets	:	1031	0 pps
Bytes	:	147328	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low, non-TCP	:	0	0 pps
Low, TCP	:	0	0 pps
High, non-TCP	:	0	0 pps
High, TCP	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low, non-TCP	:	0	0 bps
Low, TCP	:	0	0 bps
High, non-TCP	:	0	0 bps
High, TCP	:	0	0 bps

Queue: 1, Forwarding classes: expedited-forwarding

## Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

## Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low, non-TCP	:	0	0 pps
Low, TCP	:	0	0 pps
High, non-TCP	:	0	0 pps
High, TCP	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low, non-TCP	:	0	0 bps
Low, TCP	:	0	0 bps
High, non-TCP	:	0	0 bps
High, TCP	:	0	0 bps

Queue: 2, Forwarding classes: assured-forwarding

## Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

## Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low, non-TCP	:	0	0 pps
Low, TCP	:	0	0 pps
High, non-TCP	:	0	0 pps
High, TCP	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low, non-TCP	:	0	0 bps
Low, TCP	:	0	0 bps
High, non-TCP	:	0	0 bps
High, TCP	:	0	0 bps

Queue: 3, Forwarding classes: network-control

## Queued:

Packets	:	94386	12 pps
Bytes	:	13756799	9568 bps

## Transmitted:

Packets	:	94386	12 pps
Bytes	:	13756799	9568 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low, non-TCP	:	0	0 pps
Low, TCP	:	0	0 pps
High, non-TCP	:	0	0 pps
High, TCP	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low, non-TCP	:	0	0 bps
Low, TCP	:	0	0 bps
High, non-TCP	:	0	0 bps
High, TCP	:	0	0 bps

### show interfaces queue both-ingress-egress (Gigabit Ethernet IQ2 PIC)

```

user@host> show interfaces queue ge-6/2/0 both-ingress-egress
Physical interface: ge-6/2/0, Enabled, Physical link is Up
  Interface index: 175, SNMP ifIndex: 121
Forwarding classes: 8 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                254                0 pps
    Bytes        :            16274                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps
    RED-dropped bytes  :                0                0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      : Not Available
    Bytes        :                0                0 bps
  Transmitted:
    Packets      :                0                0 pps
    Bytes        :                0                0 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :                0                0 pps

```

```

    RED-dropped bytes      :                0                0 bps
Forwarding classes: 8 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets                : Not Available
    Bytes                  :                0                0 bps
  Transmitted:
    Packets                :                3                0 pps
    Bytes                  :               126                0 bps
    Tail-dropped packets   : Not Available
    RED-dropped packets    :                0                0 pps
    RED-dropped bytes      :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets                : Not Available
    Bytes                  :                0                0 bps
  Transmitted:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
    Tail-dropped packets   : Not Available
    RED-dropped packets    :                0                0 pps
    RED-dropped bytes      :                0                0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets                : Not Available
    Bytes                  :                0                0 bps
  Transmitted:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
    Tail-dropped packets   : Not Available
    RED-dropped packets    :                0                0 pps
    RED-dropped bytes      :                0                0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets                : Not Available
    Bytes                  :                0                0 bps
  Transmitted:
    Packets                :                0                0 pps
    Bytes                  :                0                0 bps
    Tail-dropped packets   : Not Available
    RED-dropped packets    :                0                0 pps
    RED-dropped bytes      :                0                0 bps
Packet Forwarding Engine Chassis Queues:
Queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets                :             80564692            0 pps
    Bytes                  :          3383717100            0 bps
  Transmitted:
    Packets                :             80564692            0 pps
    Bytes                  :          3383717100            0 bps
    Tail-dropped packets   :                0                0 pps
    RED-dropped packets    :                0                0 pps
    RED-dropped bytes      :                0                0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets                :             80564685            0 pps
    Bytes                  :          3383716770            0 bps
  Transmitted:
    Packets                :             80564685            0 pps

```

```

Bytes : 3383716770 0 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets : 0 0 pps
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets : 9397 0 pps
Bytes : 3809052 232 bps
Transmitted:
Packets : 9397 0 pps
Bytes : 3809052 232 bps
Tail-dropped packets : 0 0 pps
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps

```

#### show interfaces queue ingress (Gigabit Ethernet IQ2 PIC)

```

user@host> show interfaces queue ge-6/2/0 ingress
Physical interface: ge-6/2/0, Enabled, Physical link is Up
Interface index: 175, SNMP ifIndex: 121
Forwarding classes: 8 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 288 0 pps
Bytes : 18450 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available

```

```

RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps

```

### show interfaces queue egress (Gigabit Ethernet IQ2 PIC)

```

user@host> show interfaces queue ge-6/2/0 egress
Physical interface: ge-6/2/0, Enabled, Physical link is Up
Interface index: 175, SNMP ifIndex: 121
Forwarding classes: 8 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 3 0 pps
Bytes : 126 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets : Not Available
Bytes : 0 0 bps
Transmitted:
Packets : 0 0 pps
Bytes : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
RED-dropped bytes : 0 0 bps

```

```

Packet Forwarding Engine Chassis Queues:
Queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      80564692      0 pps
    Bytes        :      3383717100    0 bps
  Transmitted:
    Packets      :      80564692      0 pps
    Bytes        :      3383717100    0 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      0      0 pps
    RED-dropped bytes  :      0      0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets      :      80564685      0 pps
    Bytes        :      3383716770    0 bps
  Transmitted:
    Packets      :      80564685      0 pps
    Bytes        :      3383716770    0 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      0      0 pps
    RED-dropped bytes  :      0      0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
  Transmitted:
    Packets      :      0      0 pps
    Bytes        :      0      0 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      0      0 pps
    RED-dropped bytes  :      0      0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets      :      9538      0 pps
    Bytes        :      3819840      0 bps
  Transmitted:
    Packets      :      9538      0 pps
    Bytes        :      3819840      0 bps
    Tail-dropped packets :      0      0 pps
    RED-dropped packets :      0      0 pps
    RED-dropped bytes  :      0      0 bps

```

#### show interfaces queue remaining-traffic (Gigabit Ethernet Enhanced DPC)

```

user@host> show interfaces queue ge-2/2/9 remaining-traffic
Physical interface: ge-2/2/9, Enabled, Physical link is Up
  Interface index: 238, SNMP ifIndex: 71
Forwarding classes: 16 supported, 4 in use
Ingress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      :      110208969      472875 pps
    Bytes        :      5951284434    204282000 bps
  Transmitted:
    Packets      :      110208969      472875 pps
    Bytes        :      5951284434    204282000 bps
    Tail-dropped packets : Not Available
    RED-dropped packets :      0      0 pps
    Low          :      0      0 pps

```



```

Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
Queued:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Transmitted:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
Queued:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Transmitted:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps
High            : 0 0 bps
Queue: 3, Forwarding classes: network-control
Queued:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Transmitted:
Packets         : 0 0 pps
Bytes           : 0 0 bps
Tail-dropped packets : Not Available
RED-dropped packets : 0 0 pps
Low             : 0 0 pps
Medium-low      : 0 0 pps
Medium-high     : 0 0 pps
High            : 0 0 pps
RED-dropped bytes : 0 0 bps
Low             : 0 0 bps
Medium-low      : 0 0 bps
Medium-high     : 0 0 bps

```

```

        High : 0 0 bps
Forwarding classes: 16 supported, 4 in use
Egress queues: 4 supported, 4 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets : 109355853 471736 pps
    Bytes : 7436199152 256627968 bps
  Transmitted:
    Packets : 109355852 471736 pps
    Bytes : 7436198640 256627968 bps
  Tail-dropped packets : Not Available
  RED-dropped packets : 0 0 pps
    Low : 0 0 pps
    Medium-low : 0 0 pps
    Medium-high : 0 0 pps
    High : 0 0 pps
  RED-dropped bytes : 0 0 bps
    Low : 0 0 bps
    Medium-low : 0 0 bps
    Medium-high : 0 0 bps
    High : 0 0 bps
Queue: 1, Forwarding classes: expedited-forwarding
  Queued:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Transmitted:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Tail-dropped packets : Not Available
  RED-dropped packets : 0 0 pps
    Low : 0 0 pps
    Medium-low : 0 0 pps
    Medium-high : 0 0 pps
    High : 0 0 pps
  RED-dropped bytes : 0 0 bps
    Low : 0 0 bps
    Medium-low : 0 0 bps
    Medium-high : 0 0 bps
    High : 0 0 bps
Queue: 2, Forwarding classes: assured-forwarding
  Queued:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Transmitted:
    Packets : 0 0 pps
    Bytes : 0 0 bps
  Tail-dropped packets : Not Available
  RED-dropped packets : 0 0 pps
    Low : 0 0 pps
    Medium-low : 0 0 pps
    Medium-high : 0 0 pps
    High : 0 0 pps
  RED-dropped bytes : 0 0 bps
    Low : 0 0 bps
    Medium-low : 0 0 bps
    Medium-high : 0 0 bps
    High : 0 0 bps
Queue: 3, Forwarding classes: network-control
  Queued:
    Packets : 0 0 pps
    Bytes : 0 0 bps

```

```

Transmitted:
Packets          :                0                0 pps
Bytes            :                0                0 bps
Tail-dropped packets : Not Available
RED-dropped packets :                0                0 pps
  Low            :                0                0 pps
  Medium-low     :                0                0 pps
  Medium-high    :                0                0 pps
  High           :                0                0 pps
RED-dropped bytes  :                0                0 bps
  Low            :                0                0 bps
  Medium-low     :                0                0 bps
  Medium-high    :                0                0 bps
  High           :                0                0 bps

```

#### show interfaces queue (Channelized OC12 IQE Type 3 PIC in SONET Mode)

```

user@host> show interfaces queue t3-1/1/0:7
Physical interface: t3-1/1/0:7, Enabled, Physical link is Up

  Interface index: 192, SNMP ifIndex: 1948

  Description: full T3 interface connect to 6ce13 t3-3/1/0:7 for FR testing -
  Lam

  Forwarding classes: 16 supported, 9 in use

  Egress queues: 8 supported, 8 in use

  Queue: 0, Forwarding classes: DEFAULT

  Queued:

    Packets          :                214886                13449 pps
    Bytes            :                9884756                5164536 bps

  Transmitted:

    Packets          :                214886                13449 pps
    Bytes            :                9884756                5164536 bps
    Tail-dropped packets :                0                0 pps
    RED-dropped packets :                0                0 pps
      Low            :                0                0 pps
      Medium-low     :                0                0 pps
      Medium-high    :                0                0 pps
      High           :                0                0 pps
    RED-dropped bytes  :                0                0 bps
      Low            :                0                0 bps
      Medium-low     :                0                0 bps

```

Medium-high	:	0	0 bps
-------------	---	---	-------

High	:	0	0 bps
------	---	---	-------

Queue: 1, Forwarding classes: REALTIME

Queued:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
-------	---	---	-------

Transmitted:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
-------	---	---	-------

Tail-dropped packets	:	0	0 pps
----------------------	---	---	-------

RED-dropped packets	:	0	0 pps
---------------------	---	---	-------

Low	:	0	0 pps
-----	---	---	-------

Medium-low	:	0	0 pps
------------	---	---	-------

Medium-high	:	0	0 pps
-------------	---	---	-------

High	:	0	0 pps
------	---	---	-------

RED-dropped bytes	:	0	0 bps
-------------------	---	---	-------

Low	:	0	0 bps
-----	---	---	-------

Medium-low	:	0	0 bps
------------	---	---	-------

Medium-high	:	0	0 bps
-------------	---	---	-------

High	:	0	0 bps
------	---	---	-------

Queue: 2, Forwarding classes: PRIVATE

Queued:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
-------	---	---	-------

Transmitted:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
-------	---	---	-------

Tail-dropped packets	:	0	0 pps
----------------------	---	---	-------

RED-dropped packets	:	0	0 pps
---------------------	---	---	-------

Low	:	0	0 pps
-----	---	---	-------

Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 3, Forwarding classes: CONTROL

Queued:

Packets	:	60	0 pps
Bytes	:	4560	0 bps

Transmitted:

Packets	:	60	0 pps
Bytes	:	4560	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 4, Forwarding classes: CLASS\_B\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 5, Forwarding classes: CLASS\_C\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps

High	:	0	0 bps
------	---	---	-------

Queue: 6, Forwarding classes: CLASS\_V\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 7, Forwarding classes: CLASS\_S\_OUTPUT, GETS

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps

High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Packet Forwarding Engine Chassis Queues:

Queues: 8 supported, 8 in use

Queue: 0, Forwarding classes: DEFAULT

Queued:

Packets	:	371365	23620 pps
Bytes	:	15597330	7936368 bps

Transmitted:

Packets	:	371365	23620 pps
Bytes	:	15597330	7936368 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 1, Forwarding classes: REALTIME

Queued:

Packets	:	0	0 pps
---------	---	---	-------



Bytes	:	0	0 bps
Transmitted:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps
Queue: 2, Forwarding classes: PRIVATE			
Queued:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Transmitted:			
Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps

Medium-high	:	0	0 bps
-------------	---	---	-------

High	:	0	0 bps
------	---	---	-------

Queue: 3, Forwarding classes: CONTROL

Queued:

Packets	:	32843	0 pps
---------	---	-------	-------

Bytes	:	2641754	56 bps
-------	---	---------	--------

Transmitted:

Packets	:	32843	0 pps
---------	---	-------	-------

Bytes	:	2641754	56 bps
-------	---	---------	--------

Tail-dropped packets	:	0	0 pps
----------------------	---	---	-------

RED-dropped packets	:	0	0 pps
---------------------	---	---	-------

Low	:	0	0 pps
-----	---	---	-------

Medium-low	:	0	0 pps
------------	---	---	-------

Medium-high	:	0	0 pps
-------------	---	---	-------

High	:	0	0 pps
------	---	---	-------

RED-dropped bytes	:	0	0 bps
-------------------	---	---	-------

Low	:	0	0 bps
-----	---	---	-------

Medium-low	:	0	0 bps
------------	---	---	-------

Medium-high	:	0	0 bps
-------------	---	---	-------

High	:	0	0 bps
------	---	---	-------

Queue: 4, Forwarding classes: CLASS\_B\_OUTPUT

Queued:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
-------	---	---	-------

Transmitted:

Packets	:	0	0 pps
---------	---	---	-------

Bytes	:	0	0 bps
-------	---	---	-------

Tail-dropped packets	:	0	0 pps
----------------------	---	---	-------

RED-dropped packets	:	0	0 pps
---------------------	---	---	-------

Low	:	0	0 pps
-----	---	---	-------

Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 5, Forwarding classes: CLASS\_C\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 6, Forwarding classes: CLASS\_V\_OUTPUT

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps
High	:	0	0 bps

Queue: 7, Forwarding classes: CLASS\_S\_OUTPUT, GETS

Queued:

Packets	:	0	0 pps
Bytes	:	0	0 bps

Transmitted:

Packets	:	0	0 pps
Bytes	:	0	0 bps
Tail-dropped packets	:	0	0 pps
RED-dropped packets	:	0	0 pps
Low	:	0	0 pps
Medium-low	:	0	0 pps
Medium-high	:	0	0 pps
High	:	0	0 pps
RED-dropped bytes	:	0	0 bps
Low	:	0	0 bps
Medium-low	:	0	0 bps
Medium-high	:	0	0 bps

High : 0 0 bps

### show interfaces queue (QFX Series)

```

user@switch> show interfaces queue xe-0/0/15
Physical interface: xe-0/0/15, Enabled, Physical link is Up
Interface index: 49165, SNMP ifIndex: 539
Forwarding classes: 12 supported, 8 in use
Egress queues: 12 supported, 8 in use
Queue: 0, Forwarding classes: best-effort
  Queued:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
  Transmitted:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets: 0 0 pps
    Total-dropped bytes  : 0 0 bps
Queue: 3, Forwarding classes: fcoe
  Queued:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
  Transmitted:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets: 0 0 pps
    Total-dropped bytes  : 0 0 bps
0 bps
Queue: 4, Forwarding classes: no-loss
  Queued:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
  Transmitted:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets: 0 0 pps
    Total-dropped bytes  : 0 0 bps
Queue: 7, Forwarding classes: network-control
  Queued:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
  Transmitted:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
    Tail-dropped packets : Not Available
    Total-dropped packets: 0 0 pps
    Total-dropped bytes  : 0 0 bps
Queue: 8, Forwarding classes: mcast
  Queued:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
  Transmitted:
    Packets      : 0 0 pps
    Bytes        : 0 0 bps
    Tail-dropped packets : Not Available

```

Total-dropped packets:	0	0 pps
Total-dropped bytes :	0	0 bps

### show interfaces queue l2-statistics (lsq interface)

```

user@switch> show interfaces queue lsq-2/2/0.2 l2-statistics
Logical interface lsq-2/2/0.2 (Index 69) (SNMP ifIndex 1598)
Forwarding classes: 16 supported, 4 in use
Egress queues: 8 supported, 4 in use
Burst size: 0
Queue: 0, Forwarding classes: be
  Queued:
    Packets      :           1           0 pps
    Bytes        :        1001           0 bps
  Transmitted:
    Packets      :           5           0 pps
    Bytes        :        1062           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 1, Forwarding classes: ef
  Queued:
    Packets      :           1           0 pps
    Bytes        :        1500           0 bps
  Transmitted:
    Packets      :           6           0 pps
    Bytes        :        1573           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 2, Forwarding classes: af
  Queued:
    Packets      :           1           0 pps
    Bytes        :         512           0 bps
  Transmitted:
    Packets      :           3           0 pps
    Bytes        :         549           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
Queue: 3, Forwarding classes: nc
  Queued:
    Packets      :           0           0 pps
    Bytes        :           0           0 bps
  Transmitted:
    Packets      :           0           0 pps
    Bytes        :           0           0 bps
    Tail-dropped packets :           0           0 pps
    RED-dropped packets :           0           0 pps
    RED-dropped bytes  :           0           0 bps
=====

```

## CHAPTER 14

# Operational Mode Commands for Layer 2 Learning

## clear l2-learning mac-move-buffer

---

<b>Syntax</b>	<code>clear l2-learning mac-move-buffer</code> <code>&lt;active&gt;</code>
<b>Release Information</b>	Command introduced in Junos OS Release 13.2.
<b>Description</b>	Clear the MAC move buffer entries.
<b>Options</b>	<b>none</b> — Clear the MAC move buffer entries.  <b>active</b> — (Optional) Unblock the interfaces that were blocked by the MAC move action feature. This allows the user to keep the <b>reopen-time</b> configured to a large value, but when the looping error is fixed, the user can manually release the blocking.
<b>Required Privilege Level</b>	clear
<b>List of Sample Output</b>	<a href="#">clear l2-learning mac-move-buffer on page 154</a> <a href="#">clear l2-learning mac-move-buffer active on page 154</a>
<b>Output Fields</b>	When you enter this command, the MAC move buffer entries are deleted.

### Sample Output

#### clear l2-learning mac-move-buffer

```
user@host> clear l2-learning mac-move-buffer
```

#### clear l2-learning mac-move-buffer active

```
user@host> clear l2-learning mac-move-buffer active
```



## show l2-learning global-information

<b>Syntax</b>	<b>show l2-learning global-information</b>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Display Layer 2 learning process-related information for the entire router.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show l2-learning global-information on page 155</a>
<b>Output Fields</b>	<a href="#">Table 9 on page 155</a> describes the output fields for the <b>show l2-learning global-information</b> command. Output fields are listed in the approximate order in which they appear.

**Table 9: show l2-learning global-information Output Fields**

Field Name	Field Description
<b>MAC aging interval</b>	Configured timeout interval, in seconds, for all MAC table entries.
<b>MAC learning</b>	Status of MAC learning: <b>Enabled</b> or <b>Disabled</b> .
<b>MAC statistics</b>	Status of MAC accounting: <b>Enabled</b> or <b>Disabled</b> .
<b>MAC limit Count</b>	Configured maximum limit on the number of MAC addresses that can be learned.
<b>MAC limit hit flag</b>	Status of the learned MAC limit hit flag: <b>Enabled</b> (the learned MAC exceeds the global MAC limit) or <b>Disabled</b> (the learned MAC does not exceed the global MAC limit).
<b>MAC packet action drop</b>	Status of action to drop packets after the configured MAC address limit is reached: <b>Enabled</b> (packets are dropped) or <b>Disabled</b> (packets are forwarded).

## Sample Output

### show l2-learning global-information

```

user@host> show l2-learning global-information
Global Configuration:

MAC aging interval    : 300
MAC learning          : Enabled
MAC statistics         : Disabled
MAC limit Count       : 393215

```

MAC limit hit flag : Disabled  
MAC packet action drop: Disabled

## show l2-learning global-mac-count

---

<b>Syntax</b>	<code>show l2-learning global-mac-count</code>
<b>Release Information</b>	Command introduced in Junos OS Release 9.3.
<b>Description</b>	(MX Series routers only) Display the total number of dynamic and static MAC addresses learned for the entire router.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show l2-learning global-mac-count on page 157</a>
<b>Output Fields</b>	Displays the total number of dynamic and static MAC addresses learned for the entire router.

### Sample Output

`show l2-learning global-mac-count`

```
user@host> show l2-learning global-mac-count
100 dynamic and static MAC addresses learned globally
```

## show l2-learning instance

<b>Syntax</b>	<b>show l2-learning instance</b>
<b>Release Information</b>	(MX Series routers only) Command introduced in Junos OS Release 8.4.
<b>Description</b>	Display Layer 2 learning properties for all the configured routing instances.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show l2-learning instance on page 158</a>
<b>Output Fields</b>	<a href="#">Table 10 on page 158</a> describes the output fields for the <b>show l2-learning instance</b> command. Output fields are listed in the approximate order in which they appear.

Table 10: show l2-learning instance Output Fields

Field Name	Field Description
<b>Routing Instance</b>	Name of routing instance.
<b>Bridging Domain</b>	Name of bridging domain.  On MX Series routers you can use the <b>show l2-learning instance &lt;extensive&gt;</b> command option to display the Bridge Service-id information which includes the Config Service ID and the Active Service ID.
<b>Index</b>	Number associated with the routing instance or bridging domain.
<b>Logical System</b>	Name of logical system or <b>Default</b> if no logical system is configured.
<b>Routing instance flags</b>	Status of Layer 2 learning properties for each routing instance: <ul style="list-style-type: none"> <li>• <b>DL</b>—MAC learning is disabled.</li> <li>• <b>SE</b>—MAC accounting is enabled.</li> <li>• <b>AD</b>—Packets are dropped after MAC address limit is reached.</li> <li>• <b>LH</b>—The maximum number of MAC addresses has been learned on the routing instance. The routing instance is not able to learn any additional MAC addresses.</li> </ul>
<b>MAC limit</b>	Maximum number of MAC addresses that can be learned from each interface in the routing instance or bridging domain.

## Sample Output

### show l2-learning instance

```
user@host> show l2-learning instance
Information for routing instance:

Routing Instance flags (DL -disable learning, SE -stats enabled,
```

AD -packet action drop, LH -mac limit hit)

Routing Instance	Bridging Domain	Index	Logical System	Routing flags	MAC limit
__juniper_private1__		1	Default		5000
vs1	vlan100	3	Default		5120
vs1	vlan200	4	Default		5120

## show l2-learning interface

<b>Syntax</b>	<b>show l2-learning interface</b>
<b>Release Information</b>	Command introduced in Junos OS Release 8.4.
<b>Description</b>	(MX Series routers only) Display Layer 2 learning information for all the interfaces.
<b>Options</b>	This command has no options.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show l2-learning interface on page 160</a>
<b>Output Fields</b>	<a href="#">Table 11 on page 160</a> describes the output fields for the <b>show l2-learning interface</b> command. Output fields are listed in the approximate order in which they appear.

**Table 11: show l2-learning interface Output Fields**

Field Name	Field Description
<b>Logical interface</b>	Name of the logical interface.
<b>Index</b>	Index of the interface.
<b>Routing Instance</b>	Number of the routing instance to which the interface belongs.
<b>Interface device</b>	Value of the order in which the Junos OS finds and initializes the interface.
<b>Logical interface flags</b>	Status of Layer 2 learning properties for each interface: <ul style="list-style-type: none"> <li>• <b>DL</b>—MAC learning is disabled.</li> <li>• <b>SE</b>—MAC accounting is enabled.</li> <li>• <b>AD</b>—Packets are dropped after the MAC interface limit is reached.</li> <li>• <b>MAC limit</b>—Maximum number of MAC addresses that can be learned from the interface.</li> </ul>

## Sample Output

### show l2-learning interface

```
user@host> show l2-learning interface
Information for interface family:
```

```
Logical Interface flags (DL -disable learning, SE -stats enabled,
AD -packet action drop, LH -mac limit hit)
```

Logical interface	Index	Routing instance	Interface device	Logical Interface flags	MAC limit
ge-11/0/3.0	79	3	136		1024
ge-11/1/4.100	84	3	150		1024
ge-11/1/1.100	86	3	147		1024

ge-11/1/0.100	87	3	146	1024
xe-10/2/0.100	88	3	144	1024
xe-10/0/0.100	89	3	129	1024
ge-11/1/0.200	90	4	146	1024
ge-11/1/1.200	91	4	147	1024
ge-11/1/4.200	92	4	150	1024
xe-10/0/0.200	93	4	129	1024
xe-10/2/0.200	94	4	144	1024

## show l2-learning mac-move-buffer

---

<b>Syntax</b>	<b>show l2-learning mac-move-buffer</b> <b>&lt;brief   detail   extensive&gt;</b> <b>&lt;active&gt;</b>
<b>Release Information</b>	Command introduced in Junos OS Release 13.2.
<b>Description</b>	(MX Series routers only) Display action as a result of configuring the MAC address move feature.
<b>Options</b>	<b>none</b> — Display action as a result of the MAC address move feature.  <b>brief   detail   extensive</b> — (Optional) Display the specified level of output.  <b>active</b> — (Optional) Display the set of interfaces blocked as a result of the MAC address move action.
<b>Required Privilege Level</b>	view
<b>List of Sample Output</b>	<a href="#">show l2-learning mac-move-buffer active on page 162</a> <a href="#">show l2-learning mac-move-buffer extensive on page 162</a>
<b>Output Fields</b>	Display action as a result of the MAC address move feature.

## Sample Output

### show l2-learning mac-move-buffer active

```
user@host> show l2-learning mac-move-buffer active
MAC Address: 00:00:00:00:01:01, VLAN Id: 0
  Time Rec : 2012-06-25 06:23:41   Bridge Domain: bd10
  Prev IFL : ge-1/0/5.0             New IFL: ge-1/0/6.0
  IFBD      : ge-1/0/6.0:10         Blocked   : YES
```

### show l2-learning mac-move-buffer extensive

```
user@host> show l2-learning mac-move-buffer extensive | display xml
<l2ald-mac-move-buffer>
<l2ald-mac-move-entry junos:style="extensive">
<l2ald-mac-address>aa:00:00:00:02:00</l2ald-mac-address>
<l2ald-learn-vlan-id>0<l2ald-learn-vlan-id>
<l2ald-mac-move-time-rec>11:27:57</l2ald-mac-move-time-rec>
<l2ald-mac-move-bridge-domain>bd</l2ald-mac-move-bridge-domain>
<l2ald-mac-move-from-ifl>ge-1/0/5.200</l2ald-mac-move-from-ifl>
<l2ald-mac-move-to-ifl>ge-1/0/6.200</l2ald-mac-move-to-ifl>
<l2ald-mac-move-to-ifbd>ge-1/0/6.200</l2ald-mac-move-to-ifbd>
<l2ald-mac-move-is-blocked>Yes</l2ald-mac-move-is-blocked>
</l2ald-mac-move-entry>
```



## PART 4

# Index

- [Index on page 165](#)



# Index

## Symbols

#, comments in configuration statements.....	xii
( ), in syntax descriptions.....	xii
< >, in syntax descriptions.....	xii
[ ], in configuration statements.....	xii
{ }, in configuration statements.....	xii
(pipe), in syntax descriptions.....	xii

## B

bandwidth statement.....	85
usage guidelines.....	39
braces, in configuration statements.....	xii
brackets	
angle, in syntax descriptions.....	xii
square, in configuration statements.....	xii
bridge domain	
dual VLAN tags.....	71
Layer 2, displaying.....	99
routing interface.....	65
service identifier.....	66
VLAN identifier.....	68
VLAN identifier list.....	11, 12
bridge-domains statement.....	52
bridge-options statement.....	53

## C

clear bridge mac-table command.....	98
comments, in configuration statements.....	xii
conventions	
text and syntax.....	xi
CoS	
byte count by interface hardware	
displaying.....	121
curly braces, in configuration statements.....	xii
customer support.....	xiii
contacting JTAC.....	xiii

## D

documentation	
comments on.....	xiii
domain-type statement.....	54

## F

flooding	
Layer 2 bridging, displaying.....	101
font conventions.....	xi

## G

global-mac-limit statement.....	89
usage guidelines.....	42
global-mac-statistics statement.....	89
usage guidelines.....	42
global-mac-table-aging-time statement.....	90
usage guidelines.....	41
global-no-mac-learning statement.....	90
usage guidelines.....	43

## I

interface learning information	
Layer 2, displaying.....	160
interface statement	
bridge domain.....	55
virtual switch.....	55
interface-mac-limit statement.....	56, 75, 91
set of bridge domains	
usage guidelines.....	35
trunk port	
usage guidelines.....	35
usage guidelines.....	32
irb	
and mirroring.....	60

## L

l2-learning statement.....	88
Layer 2 bridging	
bridge domain, displaying.....	99
flooding, displaying.....	101
interface learning information, displaying.....	160
learning information, displaying.....	155, 157
learning properties, displaying.....	158
MAC address table, clearing.....	98
MAC address table, displaying.....	108
statistics, displaying.....	112
learning information	
Layer 2, displaying.....	155, 157
learning properties	
Layer 2, displaying.....	158

**M**

MAC address table	
Layer 2, clearing address information.....	98
Layer 2, displaying.....	108
mac-statistics statement.....	58, 77
set of bridge domains	
usage guidelines.....	37
trunk port	
usage guidelines.....	37
usage guidelines.....	33
mac-table-size statement.....	59, 78
set of bridge domains	
usage guidelines.....	36
trunk port	
usage guidelines.....	36
usage guidelines.....	31
manuals	
comments on.....	xiii
mirroring	
and irb.....	60

**N**

no-irb-layer-2-copy statement.....	60
no-mac-learning statement.....	61, 79
set of bridge domains	
usage guidelines.....	35
trunk port	
usage guidelines.....	35
usage guidelines.....	29

**P**

packet-action statement.....	63, 81, 93
parentheses, in syntax descriptions.....	xii

**R**

routing instances for VPLS	
VLAN identifier list.....	12
routing-interface statement.....	65

**S**

service-id statement.....	66
show bridge domain command.....	99
show bridge flood command.....	101
show bridge mac-table command.....	108
show bridge statistics command.....	112
show interfaces queue command.....	115
show l2-learning global-information	
command.....	155

show l2-learning global-mac-count	
command.....	157
show l2-learning instance command.....	158
show l2-learning interface command.....	160
static-mac statement.....	67
usage guidelines.....	30
statistics	
Layer 2 bridging, displaying.....	112
support, technical See technical support	
switch-options statement.....	74
syntax conventions.....	xi

**T**

technical support	
contacting JTAC.....	xiii
tunnel interfaces	
configuring, MX Series routers.....	39
tunnel-services statement.....	84
usage guidelines.....	39

**V**

virtual switch	
configuring.....	4, 25
dual VLAN tags.....	71
routing interface.....	65
VLAN identifier.....	68
with VPLS ports.....	22
virtual-switch statement	
usage guidelines.....	25
VLAN identifiers	
configuring.....	12
vlan-id statement.....	68
vlan-id-list	
usage guidelines.....	11
vlan-id-list statement.....	70
vlan-tags statement.....	71
VPLS ports in a virtual switch.....	22