

Chapter 1

Setting Up AIM Trap Destinations

This chapter describes how to set up Advanced Insight Manager (AIM) trap destination settings,

