

exceeded-drop-threshold

Syntax exceeded-drop-threshold *exceededDropThreshold*
 no exceeded-drop-threshold

Release Information Command introduced before JUNOS Release 7.1.0.

Description Configures the threshold above which exceeded-drop-events are logged. The **no** version removes the threshold.

Options ■ *exceededDropThreshold*—Bits per second in the range 0–1073741824

Mode Statistics Profile Configuration

Related Topics ■ Configuring Event Statistics

Published: 2010-01-12