

peak-burst

Syntax peak-burst *size* { millisecond *milliseconds* }
 no peak-burst

Release Information Command introduced before JUNOS Release 7.1.0.
 milliseconds variable added in JUNOS Release 8.1.0.

Description Sets the peak burst for a rate-limit profile. The **no** version restores the default value, 100 ms; if 100ms is less than 8K, then 8K (8192).

- Options** ■ *size*—Size in bytes in the range 1–4294967295
 ■ *milliseconds*—Milliseconds in the range 1–10000

Mode Rate Limit Profile Configuration

- Related Topics** ■ Creating a Two-Rate Rate-Limit Profile

Published: 2010-01-07