

## show aaa accounting interval

---

**Syntax** show aaa accounting interval [*filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays information about the user and service accounting interval.

**Options** ■ *filter*—See Filtering show Commands

**Mode** Privileged Exec

---

Published: 2010-01-07