

show aaa tunnel-parameters

Syntax show aaa tunnel-parameters [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays default tunnel parameters that are configured for tunnel definitions.

Options ■ *filter*—See Filtering show Commands

Mode Privileged Exec

Published: 2010-01-07