

show control-plane policer

Syntax show control-plane policer protocol *protocolValue*

Release Information Command introduced in JUNOS Release 8.0.0.

Description Displays control plane information for a specified protocol or for all protocols.

Options ■ *protocolValue*—Name of the protocol

Mode Privileged Exec, User Exec

Related Topics ■ Monitoring Control Plane Policer Information

Published: 2010-01-07