

## show ip demux interface

---

**Syntax** show ip demux interface *interfaceType interfaceSpecifier* [*filter*]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays information about a subscriber interface.

- Options**
- *interfaceType*—Interface type; see Interface Types and Specifiers
  - *interfaceSpecifier*—Particular interface; format varies according to interface type; see Interface Types and Specifiers
  - *filter*—See Filtering show Commands

**Mode** Privileged Exec

---

Published: 2010-01-07