

## show ipv6 dhcpv6-local prefix-lifetime

---

**Syntax**    show ipv6 dhcpv6-local prefix-lifetime [ *filter* ]

**Release Information**    Command introduced before JUNOS Release 7.1.0.

**Description**    Displays the DHCPv6 default prefix lifetime.

**Options**    ■    *filter*—See Filtering show Commands

**Mode**    Privileged Exec

**Related Topics**    ■    Monitoring DHCPv6 Local Server Prefix Lifetime

---

Published: 2010-01-07