

## show radius statistics

---

**Syntax** show radius [ *serverType* ] statistics [ delta ] [ *filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.  
**pre-authentication** keyword added in JUNOS Release 8.1.0.

**Description** Displays statistics for the RADIUS servers configured on the router.

- Options**
- *serverType*—One of the following RADIUS server types:
    - authentication—Displays authentication statistics only
    - accounting—Displays accounting statistics only
    - dynamic-request—Displays dynamic-request statistics only
    - pre-authentication—Displays preauthentication statistics only
  - delta—Displays baselined statistics
  - *filter*—See Filtering show Commands

**Mode** Privileged Exec

**Related Topics** ■ Monitoring RADIUS Dynamic-Request Server Information

---

Published: 2010-01-07