

## show redundancy srp

---

**Syntax** show redundancy srp [ brief | detail ] [*filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays redundancy information specific to SRP modules.

- Options**
- brief—Displays summary redundancy information for SRP modules
  - detail—Displays detailed information for SRP modules
  - *filter*—See Filtering show Commands

**Mode** Privileged Exec

---

Published: 2010-01-07