

committed-drop-threshold

Syntax committed-drop-threshold *committedDropThreshold*
no committed-drop-threshold

Release Information Command introduced before JUNOS Release 7.1.0.

Description Configures the threshold above which committed-drop-events are logged. The **no** version removes the threshold.

Options ■ *committedDropThreshold*—Bits per second in the range 0–1073741824

Mode Statistics Profile Configuration

Related Topics ■ [Configuring Event Statistics](#)

Published: 2010-01-12