

## committed-length

---

**Syntax** committed-length *minimumCommittedLength* [ *maximumCommittedLength* ]  
no committed-length

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Sets minimum and maximum constraints for the queue's committed lengths. The **no** version removes constraints on the queue's committed length.

- Options**
- *minimumCommittedLength*—Range 0–1073741824
  - *maximumCommittedLength*—Range 0–1073741824

**Mode** Queue Profile Configuration

**Related Topics**

- Configuring Queue Profiles to Manage Buffers and Thresholds

---

Published: 2010-01-12