

## conformed-threshold

---

**Syntax** conformed-threshold { percent *MinThresholdPercent* *MaxThresholdPercent* | *MinThresholdBytes* *MaxThresholdBytes* } *MaxDropProbability*

no conformed-threshold

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Specifies the conformed queue thresholds and maximum drop probability. The **no** version removes conformed threshold.

- Options**
- percent—Specifies conformed queue thresholds as percentages
  - *MinThresholdPercent*—Minimum queue threshold as a percentage of queue length
  - *MaxThresholdPercent*—Maximum queue threshold as a percentage of queue length
  - *MinThresholdBytes*—Minimum queue threshold in bytes
  - *MaxThresholdBytes*—Maximum queue threshold in bytes
  - *MaxDropProbability*—Maximum drop probability

**Mode** Drop Profile Configuration

- Related Topics**
- Configuring RED
  - Configuring WRED

---

Published: 2010-01-12