

exceeded-length

Syntax `exceeded-length minimumExceededLength [maximumExceededLength]`
`no exceeded-length`

Release Information Command introduced before JUNOS Release 7.1.0.

Description Sets minimum and maximum constraints for the queue's exceeded lengths. The **no** version removes constraints on the queue's exceeded length.

- Options** ■ *minimumExceededLength*—Range 0–1073741824
 ■ *maximumExceededLength*—Range 0–1073741824

Mode Queue Profile Configuration

- Related Topics** ■ Configuring Queue Profiles to Manage Buffers and Thresholds

Published: 2010-01-12