

ip pim dr-priority

Syntax ip pim dr-priority *priority*
no ip pim dr-priority

Release Information Command introduced in JUNOS Release 9.0.0.
Router Configuration mode added in JUNOS Release 10.0.0.

Description Assigns a priority for the interface to be selected as the designated router. An interface with a higher priority value is preferred as a designated router over an interface with a lower priority value. In Interface Configuration mode, the **no** version restores the value that is specified in Router Configuration mode. If the designated router priority is not specified in Router Configuration mode, then the default value of 1 is restored.



NOTE: You cannot configure the designated router priority on PIM dense mode interfaces.

Options ■ *priority*—Value in the range 1–254; default value is 1.

Mode Interface Configuration, Router Configuration

Published: 2010-01-11