

## qos-interface-superset

---

**Syntax** [ no ] qos-interface-superset *interfaceSupersetName*

**Release Information** Command introduced in JUNOS Release 9.2.0.

**Description** Configures a QoS interface superset and enters QoS Interface Superset Configuration mode. The **no** version deletes the interface superset.

**Options** ■ *interfaceSupersetName*—Name of the QoS interface superset

**Mode** Global Configuration

**Related Topics** ■ [Configuring Interface Supersets for QoS](#)

---

Published: 2010-01-07