

show aaa user accounting interval

Syntax show aaa user accounting interval [*filter*]

Release Information Command introduced in JUNOS Release 9.0.0.

Description Displays the default accounting interval for users attached to this virtual router.

Options ■ *filter*—See Filtering show Commands

Mode Privileged Exec

Published: 2010-01-07