

show radius servers

Syntax show radius [*serverType*] servers [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.
 pre-authentication keyword added in JUNOS Release 8.1.0.

Description Displays information about the RADIUS servers configured on the router.

- Options** ■ *serverType*—One of the following RADIUS server types:
- authentication—Displays authentication information only
 - accounting—Displays accounting information only
 - dynamic-request—Displays dynamic-request information only
 - pre-authentication—Displays preauthentication information only
- *filter*—See Filtering show Commands

Mode Privileged Exec

Related Topics ■ Monitoring RADIUS Dynamic-Request Server Information

Published: 2010-01-07