

tunnel group

Syntax tunnel group *tunnelGroupName*
 no tunnel group

Release Information Command introduced before JUNOS Release 7.1.0.

Description Assigns the specified tunnel group to the domain map. The **no** version deletes the tunnel group.



NOTE: By default, no tunnel group is assigned to the domain map. You can assign a tunnel group to the domain map only if tunnels are not currently defined for the domain map in Domain Map Tunnel mode.

Options ■ *tunnelGroupName*—String of up to 64 characters (no spaces)

Mode Domain Map Configuration

Published: 2010-01-07