

committed-threshold

Syntax committed-threshold { percent *MinThresholdPercent* *MaxThresholdPercent* | *MinThresholdBytes* *MaxThresholdBytes* } *MaxDropProbability*

no committed-threshold

Release Information Command introduced before JUNOS Release 7.1.0.

Description Specifies the committed queue thresholds and maximum drop probability. The **no** version removes committed threshold.

- Options**
- percent—Specifies committed queue thresholds as percentages
 - *MinThresholdPercent*—Minimum queue threshold as a percentage of queue length
 - *MaxThresholdPercent*—Maximum queue threshold as a percentage of queue length
 - *MinThresholdBytes*—Minimum queue threshold in bytes
 - *MaxThresholdBytes*—Maximum queue threshold in bytes
 - *MaxDropProbability*—Maximum drop probability

Mode Drop Profile Configuration

- Related Topics**
- Configuring RED
 - Configuring WRED

Published: 2010-04-09