

fabric-weight

Syntax fabric-weight *weight*
 no fabric-weight

Release Information Command introduced before JUNOS Release 7.1.0.

Description Specifies the relative weight for queues in the traffic class in the fabric. The **no** version sets the fabric weight to the default value.

Options ■ *weight*—Range 1–63; default value is 8

Mode Traffic Class Configuration

Published: 2010-04-09