

## peak-burst

---

**Syntax**    peak-burst *size* { millisecond *milliseconds* }  
              no peak-burst

**Release Information**    Command introduced before JUNOS Release 7.1.0.  
                              *milliseconds* variable added in JUNOS Release 8.1.0.

**Description**    Sets the peak burst for a rate-limit profile. The **no** version restores the default value, 100 ms; if 100ms is less than 8K, then 8K (8192).

- Options**    ■    *size*—Size in bytes in the range 1–4294967295  
              ■    *milliseconds*—Milliseconds in the range 1–10000

**Mode**    Rate Limit Profile Configuration

- Related Topics**    ■    Creating a Two-Rate Rate-Limit Profile

---

Published: 2010-04-08