

## ppp multilink multiclass

---

**Syntax**    ppp multilink multiclass [ multilink-classes *classNumber* ]  
              no ppp multilink multiclass [ multilink-classes ]

**Release Information**    Command introduced in JUNOS Release 11.1.0.

**Description**    Enables multiclass MLPPP on the router, and optionally creates a specified number of multilink classes. The **no** version without the **multilink-classes** keyword disables multiclass MLPPP on the router. The **no** version with the **multilink-classes** keyword restores the number of multilink classes to the default value, 1.

**Options**    ■    *classNumber*—Number of multilink classes that can be created in the range 1–8, with a default value of 1.

**Mode**    Interface Configuration, Profile Configuration, Subinterface Configuration

**Related Topics**    ■    Enabling Multiclass MLPPP  
                          ■    Configuring Multiclass MLPPP

---

Published: 2010-04-08