

qos-profile

Syntax [no] qos-profile *qosProfileName*

Release Information Command introduced before JUNOS Release 7.1.0.
Profile Configuration mode added in JUNOS Release 7.2.0.
QoS Interface Set Configuration and QoS Interface Superset Configuration modes added in JUNOS Release 9.2.0.

Description In Global Configuration mode, creates a QoS profile on the router and enters QoS Profile Configuration mode. The **no** version deletes the QoS profile.

In Interface Configuration mode, attaches a QoS profile to an interface. The **no** version detaches the QoS profile from the interface.

In Profile Configuration mode, adds a QoS profile command for use with Service Manager. When the service is activated, the QoS profile is created and attached to the subscriber interface. The **no** version removes the QoS profile from the profile.

In QoS Interface Set Configuration mode, attaches a QoS profile to the QoS interface set. The **no** version detaches the QoS profile from the interface set.

In QoS Interface Superset Configuration mode, attaches a QoS profile to the QoS interface superset. The **no** version detaches the QoS profile from the interface superset.

Options ■ *qosProfileName*—Name of the QoS profile

Mode Global Configuration, Interface Configuration, Profile Configuration, QoS Interface Set Configuration, QoS Interface Superset Configuration

Related Topics ■ Configuring a QoS Profile
■ Attaching a QoS Profile to an Interface
■ Configuring Shadow Nodes
■ Configuring a Basic Parameter Definition for QoS Administrators
■ Creating Parameter Instances
■ Attaching a QoS Profile to an Interface Superset or an Interface Set
■ Creating a QoS Parameter on an Interface Superset or Interface Set