

show aaa intf-desc-format

Syntax show aaa intf-desc-format

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays whether the router includes or excludes the subinterface number and adapter in the interface description that the router passes to RADIUS for inclusion in the NAS-Port-Id attribute

Mode Privileged Exec

Published: 2010-04-08