

show drop-profile

Syntax show drop-profile [*dropProfileName*] [brief | references] [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays information about the drop profile.

- Options**
- *dropProfileName*—Name for the drop profile
 - brief —Displays information in a condensed format
 - references—Displays QoS profiles which reference the drop profile
 - *filter*—See Filtering show Commands

Mode Privileged Exec

Related Topics ■ Monitoring Drop Profiles for RED and WRED

Published: 2010-04-08