

show ipv6 dhcpv6-local prefix-lifetime

Syntax show ipv6 dhcpv6-local prefix-lifetime [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays the DHCPv6 default prefix lifetime.

Options ■ *filter*—See Filtering show Commands

Mode Privileged Exec

Related Topics ■ Monitoring DHCPv6 Local Server Prefix Lifetime

Published: 2010-04-08