

show l2tp dial-out target

Syntax show l2tp dial-out target [*targetIpAddress targetIpAddressMask* | allVirtualRouters]
[detail] [state *operState*] [*filter*]

To display summary information:

show l2tp dial-out target summary [allVirtualRouters] [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays configured dial-out targets within the current virtual router context.

- Options**
- *targetIpAddress*—Trigger IP address for the target that you want to display
 - *targetIpAddressMask*—Mask for the trigger IP address
 - allVirtualRouters—Displays dial-out information for all virtual routers
 - detail—Displays configuration, state, and statistics
 - *operState*—One of the following operational states:
 - down
 - inService
 - inhibited
 - *filter*—See Filtering show Commands
 - summary—Displays aggregate counts for targets in each of the possible operational and administrative states

Mode Privileged Exec

Published: 2010-04-08