

## tunnel

---

**Syntax** [ no ] tunnel *tag*

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Specifies an L2TP tunnel and changes the mode to Domain Map Tunnel Configuration. In Domain Map Tunnel Configuration mode, you can set the attributes of the tunnel. The **no** version deletes the L2TP tunnel configuration from the router.

From Tunnel Group Configuration mode, adds up to 31 tunnel definitions to the L2TP tunnel group and changes the mode to Tunnel Group Tunnel Configuration mode. In Tunnel Group Tunnel Configuration mode, you can set tunnel attributes. The **no** version deletes the L2TP tunnel group configuration from the router.

**Options** ■ *tag*—Number in the range 1–31

**Mode** Domain Map Configuration, Tunnel Group Configuration

---

Published: 2010-04-08