

conformed-length

Syntax conformed-length *minimumConformedLength* [*maximumConformedLength*]
no conformed-length

Release Information Command introduced before JUNOS Release 7.1.0.

Description Sets minimum and maximum constraints for the queue's conformed lengths. The **no** version removes constraints on the queue's conformed length.

- Options**
- *minimumConformedLength*—Number in the range 0–1073741824
 - *maximumConformedLength*—Number in the range 0–1073741824

Mode Queue Profile Configuration

Related Topics

- Configuring Queue Profiles to Manage Buffers and Thresholds

Published: 2010-04-09