

## ip initial-sequence-preference

---

**Syntax**    ip initial-sequence-preference *preference*  
              no ip initial-sequence-preference

**Release Information**    Command introduced in JUNOS Release 8.1.0.

**Description**    Configures the warm restart replay preference for an IP interface after a high availability switchover. The **no** version restores the default value.

**Options**    ■    *preference*—Preference value, 0 or 1; 1 indicates highest preference; default value is 0

**Mode**    Subinterface Configuration

---

Published: 2010-04-09