

## show control-plane policer

---

**Syntax**    show control-plane policer protocol *protocolValue*

**Release Information**    Command introduced in JUNOS Release 8.0.0.

**Description**    Displays control plane information for a specified protocol or for all protocols.

**Options**    ■    *protocolValue*—Name of the protocol

**Mode**    Privileged Exec, User Exec

**Related Topics**    ■    Monitoring Control Plane Policer Information

---

Published: 2010-04-08