

## show ethernet oam lfm statistics

---

**Syntax** show ethernet oam lfm statistics *interfaceType interfaceSpecifier*

**Release Information** Command introduced in JUNOS Release 11.1.0.

**Description** Displays detailed information about the Ethernet OAM link-fault management packets that are processed by a particular interface.

- Options**
- *interfaceType*—One of the following interface types listed in Interface Types and Specifiers:
    - fastEthernet
    - gigabitEthernet
    - tenGigabitEthernet
  - *interfaceSpecifier*—Particular interface; format varies according to interface type; see Interface Types and Specifiers

**Mode** Privileged Exec, User Exec

- Related Topics**
- Monitoring OAM Link-Fault Management Statistics for an Interface

---

Published: 2010-04-08