

show ip demux interface

Syntax show ip demux interface *interfaceType interfaceSpecifier* [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays information about a subscriber interface.

- Options**
- *interfaceType*—Interface type; see Interface Types and Specifiers
 - *interfaceSpecifier*—Particular interface; format varies according to interface type; see Interface Types and Specifiers
 - *filter*—See Filtering show Commands

Mode Privileged Exec

Published: 2010-04-08