

show ip dhcp-local

Syntax show ip dhcp-local

Release Information Command introduced in JUNOS Release 7.2.0.

Description Displays DHCP local server configuration information, including the status of SNMP traps and client roaming support.

Mode Privileged Exec

Related Topics ■ [Monitoring DHCP Local Server Configuration](#)

Published: 2010-04-08